



Technical Documentation

VeriSens® ID- / CS- / XF- / XC-Series

Content

1	Welcome.....	8
2	Imprint.....	9
3	Safety instructions.....	10
4	Correct Use.....	14
5	Mode of operation.....	15
6	Installation and initial set-up	17
6.1	Mechanical set-up (image)	17
6.2	Mechanical set-up (heat dissipation)	21
6.3	IP protection classes	22
6.4	Electrical installation	23
6.5	Wiring.....	24
6.5.1	Notes on using an incremental encoder	25
6.6	Software installation	27
6.7	Initial set-up of the Ethernet interface on your computer	29
6.8	Notes on using gateways in a network.....	31
6.9	Important network terms.....	32
6.10	LED panel (device dependant)	33
6.11	LED panel (devices with integrated Industrial Ethernet)	34
7	Overview of the Application Suite.....	35
7.1	Operating modes of the device	36
7.2	Help, Info, Support and Notifications.....	37
8	Image display options	40
8.1	Images from PC.....	41
8.2	Defect images.....	42
8.3	Loading, saving and recording images.....	43
8.4	Job features.....	45
9	Creating a job	46
9.1	Adjusting the image (image focus)	46
9.1.1	Adjusting the image (additional parameters)	47
9.1.2	Coordinates (device dependant).....	52
9.1.3	Coordinates (with distortion correction enabled – device dependend).....	55
9.1.4	Focus	61
9.1.5	White balance (device dependant)	62
9.2	Checking features.....	63
9.3	Configuring interfaces.....	69
9.3.1	Occupancy of digital I/Os	69
9.3.2	Timing digital I/Os	73
9.3.3	Output Robotics (device dependent)	76
9.3.4	Output process interface (device dependant)	80
9.3.5	Input process interface (device dependant).....	84
9.3.6	Web interface	87
9.4	Device activation	88
9.4.1	Productivity / Statistics / Alarms	89

10 Device menu	91
10.1 Connect to device.....	92
10.2 Device settings... ..	97
10.2.1 Device name	98
10.2.2 Access rights (device dependant).....	99
10.2.2.1 Application Suite	99
10.2.2.2 Web interface	100
10.2.3 Web interface	101
10.2.3.1 Functions.....	101
10.2.3.2 Design	104
10.2.3.3 Security	105
10.2.4 Robotics (device-dependent).....	107
10.2.5 Digital I/Os.....	108
10.2.6 Alarm signal	110
10.2.7 IP address / network	111
10.2.8 Process interface (device dependant)	112
10.2.9 FTP / SFTP	115
10.2.10 Job management	118
10.2.11 Job selection / Teach.....	120
10.2.12 Distortion correction (device dependend)	121
10.2.13 Z calibration (device dependent).....	125
10.2.14 Shading correction (device dependend)	127
10.2.15 Illumination controller (device dependant)	129
10.2.16 Firmware update	132
10.3 Backup.....	134
10.3.1 Backup - using the PC... ..	135
10.3.2 Backup – using the FTP server.....	136
10.3.3 Backup – restoring from the PC.....	137
10.3.4 Backup - restoring from the FTP server.....	139
10.4 Digital I/O Assistant	140
10.5 Process interface assistant (device dependent)	142
10.6 Operating mode display.....	144
11 Job menu	145
11.1 Create new job	146
11.2 Load job from PC.....	147
11.3 Load job from device... ..	148
11.4 Save job to PC.....	149
11.5 Save to the device... ..	150
11.6 Test job... ..	151
11.6.1 Test Protocol – Overview	154
11.6.2 Test Protocol – Statistic.....	155
11.7 Result and user display	156
12 Feature checks	157
12.1 Part location.....	158
12.1.1 Part location on contours	158
12.1.2 Part location on edges	161
12.1.3 Part location on circle.....	164
12.1.4 Part location on text line	166
12.2 Geometry	168
12.2.1 Distance	168
12.2.2 Circle	171

12.2.3	Angle	174
12.2.4	Count edges	177
12.2.5	Point position	179
12.2.6	Edge characteristics	181
12.3	Feature comparison	187
12.3.1	Count contour points	187
12.3.2	Contour comparison	189
12.3.3	Colour identification	192
12.3.4	Brightness	197
12.3.5	Contrast	199
12.3.6	Area size	201
12.3.7	Area size (colour)	204
12.3.8	Colour positioning	209
12.3.9	Count areas	214
12.3.10	Count areas (colour)	217
12.3.11	Pattern comparison	222
12.3.12	Pattern comparison (older version)	225
12.3.13	Pattern comparison (colour)	227
12.3.14	Finding object positions	230
12.4	Identification	236
12.4.1	Barcode	236
12.4.2	Barcode (colour)	240
12.4.3	Matrix code	244
12.4.4	Matrix code (colour)	248
12.4.5	Text	252
12.4.6	Text (colour)	257
12.4.7	Appendix: Quality characteristics for barcodes and matrix codes	262
13	Digital interfaces	265
13.1	Explanation of terms from the timing diagram	265
13.2	Timing when an external trigger is used	266
13.3	Timing for continuous image acquisition	267
13.4	External Teach	268
13.5	Job switching	269
13.6	Job selection via digital inputs	270
13.6.1	Binary job selection	271
13.6.2	Bit serial job selection	272
13.7	Alarm signal	274
14	Web interface	275
14.1	Supported browsers	276
14.2	Connecting to the web interface	277
14.2.1	Connection to one device	277
14.2.2	Connection to multiple devices	279
14.3	Device specific functions	281
14.4	Job specific functions	283
14.4.1	Image acquisition	285
14.4.2	Part location	285
14.4.3	Geometry	286
14.4.4	Feature comparison	286
14.4.5	Identification	288
14.5	Functions selectable via the address bar	290
14.5.1	Language selection	290

14.5.2	Scaling down the transferred image	290
14.5.3	Live image.....	291
14.5.4	Defect images	292
14.5.5	Static images.....	293
14.5.6	Setting the display screen	295
15	Communication via the process interface (device dependent)	296
15.1	Process interface via TCP/UDP (device dependant)	296
15.1.1	Configuration of the Ethernet interface	296
15.1.2	Protocol structure – Ethernet	297
15.2	Process interface via RS485 (device dependant)	297
15.2.1	Configuration of the RS485 interface.....	297
15.2.2	Protocol structure – RS485.....	298
15.3	General Information	301
15.3.1	General description of data formats.....	301
15.3.1.1	Integer	301
15.3.1.2	Float	301
15.3.1.3	Text.....	301
15.3.1.4	Composite data type: Integer point	302
15.3.1.5	Composite data type: Float point	302
15.3.1.6	Composite data type: List.....	303
15.3.2	Numeric values in commands.....	303
15.3.3	Conversion Table Decimal ↔ Hexadecimal ↔ Character	304
15.3.4	Receipt timeout	305
15.3.5	Response delay	306
15.4	Available commands for TCP / UDP / RS485	307
15.4.1	CS command – reset statistics	307
15.4.2	Command DJ – delete job	308
15.4.3	Command GA – temperature alarm queries (only devices with integral Industrial Ethernet)	309
15.4.4	Command GB – access device backup	310
15.4.5	GD command – retrieve last result	311
15.4.6	Command GF – retrieve individual files from the device	314
15.4.7	GI command – access an image (only via Ethernet)	316
15.4.8	GM command – access information about the device	317
15.4.9	GP command – access the current configuration of the SP command	318
15.4.10	GS command – request status	319
15.4.11	GT command – request thermal condition (only devices with integral Industrial Ethernet).....	321
15.4.12	SJ command – change to a different job	322
15.4.13	SM command – change operating mode	323
15.4.14	SP command – set parameters for the feature checks.....	325
15.4.15	TE command – use next image for external teach	328
15.4.16	TR command – request image acquisition and response datagram	330
15.4.17	TI command - trigger immediately	331
15.4.18	TD command – request image acquisition and transfer data	332
15.4.19	UD command – transfer backup data (only for Ethernet)	333
15.4.20	UJ command – transfer a new job	335
15.4.21	VB command – restart device	336
15.5	Communication via Industrial Ethernet (device dependant).....	337
15.5.1	Mode of operation	337
15.5.2	Abbreviations for Industrial Ethernet.....	338
15.5.3	Timing diagrams.....	339
15.5.4	Data.....	350

15.5.4.1	Cyclical data	350
15.5.4.2	Group: Control and status	351
15.5.4.3	Group: Result data	355
15.5.4.4	Group: Parameters	356
15.5.4.5	Group: Trigger data	357
15.5.4.6	Handshake	358
15.5.4.6.1	Simple handshake	358
15.5.4.6.2	Handshake with acknowledgement	359
15.5.4.6.3	Data elements for handshake	360
15.5.5	PROFINET	362
15.5.5.1	LEDs on the Vision Sensor	362
15.5.5.2	Cabling	362
15.5.5.3	Connection to the PLC	363
15.5.5.3.1	Determining a permanent IP address and name for the Vision Sensor	363
15.5.5.3.2	Installation of the GSD file	366
15.5.5.3.3	Integration of the device into the PLC project	369
15.5.5.3.4	Configuring the Application Suite	373
15.5.5.4	Vision Sensor alarm	374
15.5.5.5	Depiction of the data elements on the PROFINET module	375
15.5.5.5.1	Module: Control and status	375
15.5.5.5.2	Module: Result data	376
15.5.5.5.3	Module: Parameters	376
15.5.5.5.4	Module: Trigger data	377
15.5.5.5.5	Example	378
15.5.6	EtherNet/IP™	379
15.5.6.1	LEDs on the Vision Sensor	379
15.5.6.2	Cabling	379
15.5.6.3	Ethernet/IP™ object classes and instances	380
15.5.6.4	Connection to the PLC	381
15.5.6.4.1	Determining a permanent IP address and name for the Vision Sensor	381
15.5.6.4.2	Installation with EDS file	383
15.5.6.4.3	Integration of the Vision Sensor into the PLC project	386
15.5.6.4.4	Configuring the Application Suite	388
15.5.6.5	Additional data elements	389
15.5.6.6	Depiction of the data elements on the assembly instances	390
16	Use with UR (Universal Robots)	393
16.1	Installation	394
16.2	Quick installation	398
16.3	Installation instructions	400
16.3.1	Preparation: UR and vision sensor	400
16.3.1.1	Preparation of the UR - installation of the URCap	400
16.3.2	Mount the vision sensor on the robot or stationary on the machine	403
16.3.3	Installing and commissioning the vision sensor	405
16.3.4	Activating robotics mode in the vision sensor	406
16.3.5	Shading correction (optional)	406
16.3.6	Distortion correction (optional)	407
16.3.7	Z calibration (optional)	407
16.3.8	Set-up	408
16.3.9	Coordinate alignment	410
16.4	Messages	414
16.5	Programming the UR with vision sensor	415

16.5.1	Node for job execution	415
16.5.2	Node for finding waypoints	417
16.5.3	"Pick & Place" node	421
16.6	Example programs for the robot controller	421
16.6.1	Pick & Place	421
16.6.2	Quality control	424
16.6.3	Applications with heights as well as relative object positions	426
16.6.3.1	Option 1 – simply create several jobs	426
16.6.3.1.1	Applications	426
16.6.3.1.2	Advantages and disadvantages of the option	427
16.6.3.1.3	Installation and calibration	427
16.6.3.1.4	Image processing job and robot program	427
16.6.3.2	Option 2 – Movement affected by the robot program	428
16.6.3.2.1	Applications	428
16.6.3.2.2	Advantages and disadvantages of the option	428
16.6.3.2.3	Installation and calibration	428
16.6.3.2.4	Image processing job and robot program	429
16.6.3.3	Programming example 1 – winner's podium	430
16.6.3.3.1	Description of the application	430
16.6.3.3.2	Creating the variables	430
16.6.3.3.3	Creating the program	431
16.6.3.4	Programming example 2 – four screws depending on a variable position	434
16.6.3.4.1	Description of the application	434
16.6.3.4.2	Creating the variables	434
16.6.3.4.3	Creating the program	435
17	Cleaning	440
18	Excess temperature behaviour (only devices with integral Industrial Ethernet)	441
19	Technical data	442
19.1	Overview of feature checks	442
19.2	Overview Features	443
19.3	Technical drawing (except XC series)	444
19.4	Technical drawing (XC series only)	445
19.5	Technical drawing (only devices with protection class IP 69K)	446
19.6	Fastening bracket, 90 degree (VS mounting adapter)	447
19.7	Fastening bracket, 90 degree	448
19.8	Fastening bracket, straight	449
19.9	Technical data	450
19.10	Electrical Connection (View on Device)	452
19.11	Power Cable M12 / 12-pin	453
20	Conformity	454
20.1	CE	454
20.2	RoHS (restriction of hazardous substances)	454
20.3	UL	454
20.4	UR	454
20.5	KC (Korean Conformity)	455

1 Welcome

Welcome to this Help Guide.



Please read these operating instructions carefully and observe the safety instructions!

Target group:

These operating instructions are intended for users that want to perform feature checks with the Vision Sensor.

2 Imprint

© Baumer Optronic GmbH

Badstraße 30
DE-01454 Radeberg

Phone: +49 (0)3528 4386-845

Fax: +49 (0)3528 4386-86

Email: support.verisens@baumer.com

Version 2.12.0

04/2025 Issue

VeriSens®, *VeriFlash®*, *FEX®*, *FEXLoc®* and *Color FEX®* are registered trademarks of Baumer Optronic GmbH.

All other product and company names mentioned are trademarks or registered trademarks of their respective owners.

All rights reserved. Reproduction of this document in whole or in part is only permitted with previous written consent from Baumer Optronic GmbH.

Revisions in the course of technical progress and possible errors reserved.

Find the latest information about Baumer *VeriSens®* at <https://www.baumer.com/verisens>.

3 Safety instructions

Explanations of safety instructions

**NOTE**

Gives helpful notes on operation or other general recommendations.

**ATTENTION!**

Indicates a possibly dangerous situation. If this is not avoided, slight or minor injury could result or the device may be damaged.

**WARNING!**

Indicates an immediate imminent danger. If this is not avoided, death or serious injury may occur.

General notes / Safety instructions for the Vision Sensor

**NOTE**

There is a scratch-resistant foil on the glass cover of the tube for devices with interchangeable lenses. Remove the foil before carrying out inspection tasks.

**NOTE**

For UL-compliant installations, the cables used must meet the following requirements:

- Shielding for optimum interference immunity
- IP67 protection
- UL approval
- Dielectric strength in line with the operating voltages used
- Temperature resistance in the specified device temperature range
- Minimum cross-section of the cable in line with the max. output current

NOTE


Networking problems can occur for a number of different reasons, such as power saving modes on portable computers, defective cables or other defective components, or incorrect settings on the PC. Should an error occur, contact a technician to locate the source of the problem.

NOTE


Characters allowed in file names and job names:

0123456789ABCDEFGHIJKLMNOPQRSTUVWXYZabcdefghijklmnopqrstuvwxyz
 ÀÁÂÃÄÅÈÉÊËÌÍÎ
 àáâãäåèéêëìíî
 ÐÑÒÓÔÕÖÙÚÛÜÝß
 ðñòóôõöùúûüýÿÇ,
 !"#\$%&'+-÷×±,.
 i@_`(){}«»~

ATTENTION!


Connection, installation and initial set-up may only be carried out by specialized personnel.
 Protect optical areas from moisture and dirt.

ATTENTION!


The IP protection class is only valid if **all** connectors are connected as described in the technical documentation and, for devices with protection class IP 69K, if the sealing screw on the lens setting opening is correctly screwed in.

ATTENTION!


Disconnection of power to the device during booting can result in damaged files.
 Never disconnect the power supply during booting. Booting is finished when intermittent blinking of the PASS / FAIL – LED or blinking of the POWER LED has stopped.

ATTENTION!

The device may become very warm during operation. High temperatures may damage the device. Ensure that any heat generated is dispersed by installing it with the rear to a good heat conductor (aluminium).

Direct mounting on a solid metal (aluminium) object without using a retaining bracket is required when operated in the limit zone (e.g. full load on the flash controller and utilisation of the maximum operating temperature)!

For devices with integrated Industrial Ethernet only:

These devices are equipped with an internal temperature monitor for built-in protection.

There may be a warning message or emergency shutdown if the device is operated outside its specified range.

ATTENTION!

Incorrect supply voltage will destroy the device!

Pin 1: Power ($\approx 24\text{ V} \pm 25\%$)

Pin 2: Ground

ATTENTION!

The device can become damaged by strong radiation or electrical fields. For this reason, never place the device near strong radiation sources or strong electrical fields. These can occur in close proximity to lasers, for example.

ATTENTION!

The Vision Sensor is a class A device (DIN EN 55022:2011). It can cause radio interference in residential environments. Should this happen, you must take reasonable measures to eliminate the interference.

WARNING!

The device emits bright, pulsed light (Risk group 1, low risk, EN 62471:2008). Bright, pulsed light can cause damage to the eyes and seizures.

Never look directly into the pulsed light from the LEDs!



NOTE**For devices with infra-red illumination**

The devices use LED illumination of the risk group RG 0 (exempt group, no risk) as per IEC/EN 62471.

The radiation of the LEDs does not pose a hazard to the human eye if the devices are used for their intended purpose.

Even so, do not look directly into the light source – there is a danger of dazzle and irritation. Mount the devices so that it is not possible to look directly into the light source.

4 Correct Use

Depending on the device, the Vision Sensors in combination with the Application Suite software are used to monitor and verify:

- Completeness
- Presence
- Position
- Correct position
- Barcode and matrix code
- Numbers and characters
- Colour features

e.g. for objects passing the Vision Sensor on conveyor belts.

The vision sensors have a compact, industrial-grade housing and are designed exclusively for indoor use. Use in wet areas is permissible under consideration of the IP protection class.

You can find an overview as to which Vision Sensors check which features under: *Technical Data (Overview of feature checks)*.



NOTE

The colour devices are suitable for tasks such as sorting objects by colour. They are not suitable for measuring colours or determining colour deviations (ΔE).



NOTE

These devices are not suitable for use in the food sector as per EN 1672-2.



ATTENTION!

Only use the devices for its intended purpose! The guarantee becomes void in the case of any application not described in the technical documentation!

If the equipment or device is used in a manner not specified by the manufacturer, the protection provided by the equipment or device may be affected.

The device may only be connected to in-factory Ethernet networks and not be exposed to Telecom Network Voltages (TNVs).


5 Mode of operation

In contrast with conventional photoelectric sensors, this sensor operates with digital images and is capable of conducting several feature checks with parameters set by the software.

The strength of the device lies in the detection of contours. With the procedure, differences in brightness can be optimally tolerated, as contours are usually independent of the absolute brightness (e.g. variations in illumination).


Because a test object can normally be definitively described by its relevant contours, the device provides powerful tools to check their presence, position, completeness or colour. The high quality of the method ensures that a reliable result is always achieved even with a rapid sequence of objects.

The diagram shows the schematic mode of operation with the corresponding parts of the sensor.



Here, each inspection task ("*job*") is divided into several *feature checks*. Each feature check executes one task and returns an associated pass/fail result or the associated measured values. For this purpose, a field of view must be defined that is either circular, an arc, rectangular or polygonal. The contours can be given via search arrows for geometrical feature checks.

Then you can link the results from the feature checks into one result and output it via a digital interface. With the device, the stored jobs can be selected via external switching inputs.



The device operates in two operating modes:

- *Activated*
- *Configuration*

In *activated* mode, the inspection task is conducted. The device operates autonomously in this mode and can communicate directly with a PLC. The device receives all commands such as trigger or job number from the external control system and mainly returns a pass or fail result. In activated mode you can also use the Application Suite to monitor your inspection tasks.

In the Configuration mode you can configure and set the parameters for the jobs and features to be checked. This is conducted using the *Application Suite*.

Because a high-quality digital image provides many means of visual inspection, the parameters of the jobs have to be set according to the inspection task and the application. For this purpose, the *Application Suite* provides a pre-configured input mask for each feature to be checked, which supports the determination of the optimum settings.


6 Installation and initial set-up

6.1 Mechanical set-up (image)

You can operate the device in any position.

Attach the device to the M4 screws provided for this purpose.

Tightening torque: max. 3 Nm.



Align the device so that the image centre indicated below points directly at the object to be inspected.

The device should be installed so that it vibrates as little as possible during operation to avoid negative influences on the image quality (blurred images).

Install the device so that there are no obstacles between the sensor and the object that could block the view or cause reflections. Ensure that the device is protected as well as possible against dust.

Devices and its built-in lens can inspect fixed areas at fixed distances.





NOTE

The field of view and minimum module size for devices with interchangeable lenses depends on the lens installed.











Obtain the depth of field and the area in focus from the following diagrams:

Devices without Industrial Ethernet / focal distance 10 mm / aperture 5.6





Devices without Industrial Ethernet / focal distance 16 mm / aperture 5.6



Devices with Industrial Ethernet / focal distance 8 mm / aperture 1.8

Devices with Industrial Ethernet / focal distance 12 mm / aperture 1.8

Devices with Industrial Ethernet / focal distance 16 mm / aperture 1.8


Refer to the diagrams below for the maximum fields of view and minimum module size:



⁶⁾ Working distances > 400 mm possible

6.2 Mechanical set-up (heat dissipation)

ATTENTION!

The device may become very warm during operation. High temperatures may damage the device. It is vital to ensure that heat is dissipated by appropriate assembly.




Direct mounting on a solid metal (aluminium) object without using a retaining bracket is required when operated in the limit zone (e.g. full load on the flash controller and utilisation of the maximum operating temperature)!

If there is a protective foil on the back of the vision sensor, it must be removed during the final integration into the machine at the latest so that there is sufficient heat transfer to the metallic connection!


The following are our recommendations for installation of the device to dissipate heat:

- Install the mounting bracket across the full surface of the device and also across the full surface onto heat conductive material on the system (aluminium profile 60 mm x 60 mm). In the case of devices with integrated Industrial Ethernet, the offered mounting bracket should consist of 12 mm thick aluminium; or a rear bracket at least comparable in rear attachment and heat dissipation capacity should be used.
- Avoid mounting onto stainless steel. Stainless steel has a roughly 10-fold lower thermal conductivity compared to aluminium.
- Do not install the device at the end of a profile; this will allow heat to dissipate on both sides (higher temperature drops over a larger area)!
- Matt coated surfaces (irrespective of colour) and anodised surfaces dissipate heat better than bare metal surfaces (heat radiation). Use coated or anodised profiles for installing the device.
- Every form of convection around the device and mounting helps reduce temperature. Prevent heat from becoming trapped!
- Do not operate other devices in close proximity to the Vision Sensor. Their waste heat could additionally heat the Vision Sensor.

Temperature measurement point



Mounting bracket (aluminium)



6.3 IP protection classes

The devices continue working in an industrial environment to meet the requirements of various protection classes.

IP protection classes

IP 67 (all devices)	Sealed against dust, protection against short-term submersion
IP 69K (only stainless steel)	Sealed against dust, protection against jets of water. Although you should avoid cleaning with a pressure washer.

ATTENTION!




The respective IP protection class is only valid if **all** connectors are connected as described in the technical documentation and, for devices with protection class IP 69K, if the sealing screw on the lens setting opening is correctly screwed in.

The supplied protective caps must be installed on unused electrical screw connections.

The electrical hose connections on the device must be tightened with a torque of 0.4 Nm.

The tube on devices with replaceable lens must be screwed without a gap as depicted in the figure below in order to achieve the stated protection class.



6.4 Electrical installation

For initial set-up, you will require:

- the Vision Sensor,
- the *Application Suite* (download at: www.baumer.com/vs-sw)
- a M12-connecting cable (not supplied)
- an Ethernet cable (not supplied)
- a normal PC with Ethernet interface (not supplied).



NOTE

For optimum electrical noise immunity, the use of shielded cables is recommended. The appropriate cables can be obtained from the manufacturer.



ATTENTION!

The IP protection class is only valid if all connectors are connected as described in the technical documentation and, for devices with protection class IP 69K, if the sealing screw on the lens setting opening is correctly screwed in.



ATTENTION!

When connecting the power, ensure that all cables are connected correctly according to their colour codes!

You will find the voltages necessary, the pin assignment and the corresponding electrical power under *Technical Data*.

Screw the 12-pin power cable with M12 plug onto the power supply connection on the device.




NOTE


After installing the software, you can check the correct assignment of the digital connections in the menu: *Device* → *Digital I/O-Assistant*.

6.5 Wiring


Input



Encoder



Output



6.5.1 Notes on using an incremental encoder

You have two options for operating the device with an encoder:

NOTE




After installation, the inputs must be defined in the software using:

Device → *Device settings* → *Digital I/Os / Inputs* tab

- **1-channel operation (CH-A)** In this mode, every **rising edge** of the signal corresponds to one pulse for the timing control of the device.
It is not possible to detect the travel direction of the belt.

The maximum frequency of 500 kHz should not be exceeded for reliable operation.





Pin assignment of
the power cable

Connect the encoder CH-A to pin 11 (IN 5; grey-pink).

- **2-channel operation (CH-A and CH-B)** In this mode, every **rising and falling edge** of the signal corresponds to one pulse for the timing control of the device. The signals must alternate for the CH-A and CH-B channels.
It is possible to detect the travel direction of the belt.

The maximum frequency of 500 kHz/channel should not be exceeded for reliable operation.



6.6 Software installation

The following is a list of system requirements necessary for a proper operation of the *Application Suite*:

- **Operating system:** Microsoft® Windows® Vista (32 bit / 64 bit), Microsoft® Windows® 7 (32 bit / 64 bit), Microsoft® Windows® 8 (32 bit / 64 bit), Microsoft® Windows® 10 (32 bit / 64 bit)
- **Processor:** min. 500 MHz, 2 GHz recommended
- **Memory:** min. 512 MB RAM, > 1 GB recommended
- **Hard disk:** min. 150 MB of free disk space; including examples, about 400 MB
- **Display:** Resolution min. 1024 x 768 pixel, true colour recommended
- **Network:** Network connection for 10 Base-T / 100 Base-TX or faster



NOTE

Please note that you will require administrator rights to install the *Application Suite* and device drivers; alternatively, you can use the version which does not require installation.

Connect the device to the Ethernet interface of your computer or connect the device and your computer in a common network:



1. Download the *Application Suite* (www.baumer.com/vs-sw).
2. Unzip the downloaded file.
3. Start the set-up program and follow the installation instructions.
→A link will be created on your desktop.
4. Double-click the generated link to start the *Application Suite*.



5. Check the *network settings* to connect to the device.

NOTE

Further documents and information about the vision sensor can be found at:

www.baumer.com/vs-docs

When the device has been correctly connected and the software is successfully installed, the Vision Sensor can be commissioned using the software.

NOTE

You can launch the *Application Suite* using a command line parameter and automatically connect to the device via an IP address.

Example: `appsuite2.exe /ip=192.168.0.250` (default IP adresse)

There is also the option to launch the *Application Suite* in different languages using a command line parameter.



`/l=de` (German)
`/l=en` (English)
`/l=fr` (French)
`/l=es` (Spanish)
`/l=zh` (Chinese)
`/l=ja` (Japanese)
`/l=ko` (Korean)
`/l=it` (Italian)
`/l=th` (Thai)

Example: `appsuite2.exe /ip=192.168.0.250 /l=en`
(Start the *Application Suite* in English with the default IP address)

6.7 Initial set-up of the Ethernet interface on your computer

1. Assigning an IP address

To use the device in your network, you must assign a unique IP address to the device. Below is the default factory configuration:

1. If you have a DHCP server integrated into your network, the IP address is requested from this server. No additional manual actions are necessary on your part.
2. If a valid IP address cannot be obtained within 15 seconds, the default IP address of **192.168.0.250** (subnet mask: 255.255.255.0) is used.



NOTE


To avoid network malfunctions, ensure that each IP address is unique within your network and has not already been assigned!

Now, link your PC into the same network as the device. Under certain circumstances, you may need to configure the IP address of your PC for this purpose. With Microsoft® Windows® 7, proceed as follows:

1. Open: Start menu → System controller → Network and Internet (display network status and tasks) → Amend adapter settings



2. Select your network (e.g., "Local Area Connection") and then the "Properties" entry in the context menu.
3. Select the "Internet protocol version 4 (TCP/IPv4)" entry in the list of elements and then click the **Properties** button below the selection list. The following dialogue box opens:



Activate the **Use the following IP address** option and select an address in the range **192.168.0.xxx** that has not yet been used for the IP address. Enter **255.255.255.0** for the subnet mask and confirm these settings.

NOTE

For device communication via Ethernet, the following ports are used:



- *Application Suite:* 51972 (default setting, programmable)
- Web interface: 80 („HTTP“)
- Process interface: 23 (default setting, programmable)
- Cockpit: 8080
- FTP: 21 (default setting, programmable)
- SFTP: 22 (default setting, programmable)
- DHCP 67
- SNMP 161, 162
- SSL 443
- Ethernet/IP 2222, 44818

These ports must not be occupied by other programs or used for communication by the process interface!

Check that these ports are enabled in your firewall! You can find details on this topic in the firewall manufacturer's documentation.

6.8 Notes on using gateways in a network


With this device, it is possible to establish a connection and to configure the device by way of a gateway.

NOTE



The public IP address of the device must be known in order to communicate across gateway boundaries. Automatic detection of the device is only possible in the local network.

To establish the connection, use the options in the selection list of available devices.



To do this, set your PC and the *device* as follows:

- **PC:** The gateway of the PC's local network (Gateway 1) must be set in the configuration of the network adapter.
- **Device:** The gateway of the device's local network (Gateway 2) must be set in the network configuration.

The following items must be kept in mind when an address conversion using NAT (Network Address Translation) is being used for at least one of the gateways:

- To connect the device using the *Application Suite*, you must specify the public address and port number of the **gateway** to which the device is connected (Gateway 2).
- A separate port for communications must be used in the device settings. You can find this setting under *Device* → *Device settings* → *IP address / Network*. Change the **Port** setting from *Standard* to the *desired port number*.
- Keep in mind that changes to the network settings of the device are only valid in the local network. If necessary, make sure that the NAT settings of the gateway are also configured to make communication possible.

6.9 Important network terms

Term	Meaning
ActiveX	Software technology from Microsoft® to extend programs with additional functions.
DHCP	<i>(Dynamic Host Configuration Protocol)</i> Protocol for automatic assignment of the IP addresses.
Ethernet	Wired data network technology for local data networks.
Firewall	Software that checks and prevents access via the network.
HTML	<i>(Hypertext Markup Language)</i> Document language describing the formatting of text and graphics.
IP address	"Mailing address" of a device in a network
JavaScript	Programming language for websites allowing, among other features, dynamic actions within websites.
MAC address	<i>(Media Access Control)</i> 6-byte address, hardware identification number for network devices unique throughout the world.
Ping	Program for determining whether a computer is available in a network.
Port	(Additional) address of data packets in a network Describes the Internet services used, e.g., 21 – FTP, 25 – e-mail, 80 – websites (HTTP).
TCP	<i>(Transmission Control Protocol)</i> Reliable protocol for data transfer All data packets are transferred in the proper sequence
UDP	<i>(User Datagram Protocol)</i> Faster but less reliable protocol for data transfer. Under certain circumstances, data packets may be lost or received in a different sequence
Domain name	arbitrary address that you enter into the address line of a browser in place of the IP.

6.10 LED panel (device dependant)



A screw and 5 LEDs are located on the Vision Sensor for displaying the various states.

Image focus setting screw: Used to set the image focus.



NOTE

For devices with interchangeable lenses, the image focus is set on the installed lens.

LED	Meaning
POWER	Indicates that the Vision Sensor is being supplied with electricity.
LINK	Indicates that the Vision Sensor is connected to a network.
DATA	Indicates that data is being transferred.
FAIL	Lights up when a feature check has been failed.
PASS	Lights up when a feature check has been passed.



NOTE

Pass/Fail flash quickly and alternately: Vision Sensor starts

Pass/Fail flash simultaneously: Vision Sensor is in Recovery mode

6.11 LED panel (devices with integrated Industrial Ethernet)



A screw and 5 LEDs are located on the Vision Sensor for displaying the various states.

Image focus setting screw: Used to set the image focus.



NOTE

For devices with interchangeable lenses, the image focus is set on the installed lens.

LED	Meaning
POWER	Indicates that the Vision Sensor is being supplied with electricity.
LINK / ACT	Indicates that the Vision Sensor is connected to a network. - On: Network connection established - Blinking: Data traffic active
NET RUN	Indicates that data is being transferred via Industrial Ethernet. - Off: Industrial Ethernet will not be used - Long blinking: Waiting for the first cyclical connection - On: Cyclical connection active - Short blinking: Cyclical connection ended (waiting for next connection) 3 seconds of regular blinking: Device identification in the system
FAIL	Lights up when a feature check has been failed.
PASS	Lights up when a feature check has been passed.




NOTE

POWER blinking: Vision Sensor starts

Pass/Fail flash simultaneously: Vision Sensor is in Recovery mode

7 Overview of the Application Suite

The *Application Suite* is used for the initial set-up, job creation, configuration, service and maintenance of the device. You can monitor the progress of the job in the *Activated* mode.




- 1 Image display options
- 2 Display screen
- 3 Help, info and support window
- 4 Job bar
- 5 Device menu / Operating mode display
- 6 Job menu / Result and user display
- 7 Parametrization area
- 8 Status bar

7.1 Operating modes of the device

The device has two operating modes which differ mainly in the allocation of the priorities:

	Mode	Priority	Job processing	I/Os
1	Activated	Trigger (Image transfer only when permitted by the processing time)	on the Vision Sensor	active
2	Configuration	Image transfer (trigger is ignored if necessary)	to the computer	inactive

7.2 Help, Info, Support and Notifications



On the *Help* tab, there is a corresponding online help page for each dialogue.

The *Info* tab displays information about the system.

The image is an example and does not correspond to the current version of the software!

Help Info **Support**

Company:
Name:
Address:
Phone:
Description of problem

Attachment (images, jobs, logfile)

Logfile...

Send

Save

Help Info **Support** **Notifications**


Firmware update available
A firmware update is available for the connected device.
Current version:
New version:

Install

On the Support tab, there is a form for online support. You can attach images, jobs or log files to your support request.

The *Notifications* tab notifies you, for example, when more up-to-date firmware is available than is installed on the device, when additional language packs can be installed, or when the daylight saving time changes.



With this button you have the option to hide the help.



With this button, you can show the hidden Help again.

**NOTE**

To improve clarity, the Help window is shown lightly greyed out when the mouse pointer is not over it.

8 Image display options

The following display options are available:



You can zoom into or out of the displayed image using the magnifier and adjust the image to fit the window.

If the image has been enlarged and can no longer be seen as a whole, you can select another clip by moving the area marked in red. The overview is only displayed if the entire image is not visible.

These buttons can be used to switch on and off:



the clockwise rotation of the image by 90° (angle of rotation is displayed in the status bar)



the contour points display



the field of view display



the model display




and the cross-hair display.




Click on this button to display the current Vision Sensor image.

8.1 Images from PC

Here you can load images for evaluation that you have saved previously from your computer. Click on *Images from PC*.



Click on the green tick to hide the selection.



Click on Browse to select the directory that contains the images.

Choose the directory where the images are located and click OK.



You can view the images that you have loaded here.

8.2 Defect images

The device can store up to 32 defect images in *Activated* mode, depending on the device model. The last defect images to occur are stored.



Click on defect images to load the fault images.



You can see the last fault images to occur.



Use this button to save the single exposure currently being displayed to your PC.



Use this button to save all defect images to your PC.

8.3 Loading, saving and recording images




Use this button to load images saved on your computer for further processing.



Use this button to save the image currently being displayed to your PC.



Use this button to record live images. The "Record images" dialogue box opens after clicking.




Make the settings required for the image series in this dialogue box.

Use the *Single image* button to save just one image in the selected directory. Use the *Acquisition* button to keep acquiring images until you click on *Stop* or have limited image acquisition.



You can configure the structure of the file name.



The file name configuration gives you the option to freely arrange up to seven entries. You can also define separation markers.

The entry options for the device are:

- The chosen name of the image series
- Sequential numbers generated by the system (00000001 – 99999999)
- The result of the analysis
- The job name
- The job number
- a time stamp (time is taken from the connected PC)

8.4 Job features

The *Application Suite* helps you to create, manage and test jobs and to configure them for operation. Each inspection task is processed by the device in the course of a job. For each job required an image will be acquired in which you mark the features to be checked. A pass/fail result will then be determined.

The following individual steps are used to create a job:



1. Adjust image

1. **Adjusting the image:** Each inspection with the device is based on image data. The image quality depends on the internal camera settings, the illumination settings and lens adjustments. Here, you can set all parameters concerned with the primary image acquisition and its control.



2. Check features

2. **Checking features:** Checking the features is the actual evaluation. Each feature check operates in a field of view, determines one or more values and compares the result with preset switching points. In a second step, you can link the results of the sensor tasks to produce a result.



3. Configure interfaces

3. **Configure interface I/Os:** This includes settings for digital outputs (output time and duration of output, among other settings) and configuration for datagrams of the process interface.

You can also set which feature checks and their functions can be operated via the web interface. This information is saved separately for each job, while pin assignment for the digital I/Os is set in the device settings.

9 Creating a job

Jobs are created in three main steps, using the *Job bar*. The individual parameters can be set in this bar.



9.1 Adjusting the image (image focus)

To implement reliable inspection with the Vision Sensor, the features to be inspected must be clearly visible.

Set the image focus directly on the Vision Sensor installed at the check location using an Allen key.



ATTENTION!

On devices with protection class IP 69K, the setting screw is protected from moisture by a sealing screw.

Do not remove the sealing screw in damp rooms and only remove it for a short amount of time as there are drying capsules on the inside that absorb moisture and may become saturated.

Reseal the setting screw with the sealing screw once you have configured the image focus!



For devices with interchangeable lenses, the image focus is set on the installed lens.

9.1.1 Adjusting the image (additional parameters)

Image acquisition

Coordinates

Focusing

Exposure time:

4051 μ s

Gain (0%):



[Automatically generate suggestion...](#)

Image acquisition:

Continuous

Resolution:

Full resolution

Edge detection sensitivity:

25 %

☒ Limit to:

5 Images/s

☒ Activate internal illumination

☐ Activate external illumination

☐ Use gamma correction

Image capture

Coordinates

Exposure time:

27634 μ s

Set the exposure time for image acquisition.

NOTE



Please be aware that, if exposure time is extended, images may become blurred because of movement of the object. In this case, decrease the exposure time until the object appears sharp, and increase the value for the amplification.

(device dependant)

NOTE



For technical reasons, if the exposure time is the same, the *Reduced Resolution* (Binning) setting will detect higher grey values than at full resolution.

Gain (14%):



The image can also be brightened using the control gain (Amplification).

NOTE




Higher amplification values result in increased image graininess and make stable analysis more difficult. If sufficient image brightness is not achieved, use external illumination.

(device dependant)

[Generating automatic suggestion...](#)

Click on *Generating automatic suggestion...* to view a suggestion for illumination settings.



Enter the speed of the objects, and their distance from the camera, during inspection. The *Application Suite* automatically calculates the associated parameters. If the image is then still too dark or bright, you can adjust this using the control gain (*Amplification*).

Image acquisition

Continuous

☐ Limit to: 1 Images/s

(device dependant)

NOTE



Depending on the form of construction, devices with CMOS sensors may experience brightness deviations during the first images taken after a longer break in image exposure and the associated variations in temperature.

This is not an issue in Run mode (*Continuous*), since images are taken continuously.


In Trigger mode (*External trigger*), however, the device only records an image after a trigger event.

Longer breaks between triggers should be avoided to prevent brightness deviations.

Continuous: A new image acquisition is made as soon as an image analysis is complete. You can also limit the number of images depending on the exposure time.

External trigger: A new image is acquired upon the occurrence of a corresponding external event.

If an encoder is connected, you can also specify the delay time or distance (ft = feet) between the trigger signal and the actual image acquisition. Any other trigger signals received during this period are ignored! If necessary, activate the "invalid trigger" entry (trigger during image acquisition or job switching) in Device settings, so that the alarm output is activated in such cases.



(device dependant)

[Configure external illumination...](#)

Click on *Configure external illumination...* to make the settings for a connected external illumination system or a flash controller.

(device dependant)

Resolution:

Full resolution	▼
Full resolution	
Reduced, max. speed	
Reduced, max. brightness	

You can choose between two resolutions for the device, for the reduced resolution, additional profiles optimised for speed or brightness are available.

NOTE



The reduced setting will always detect 2 x 2 pixels and only one in four pixels will be read out. By using the "Reduced, max. speed" setting, the image acquisition time is reduced. By using the "Reduced, max. brightness" setting, a much brighter image can be acquired with the same length of exposure.

This is particularly useful with fast moving objects. Choose the mode in which the feature to be checked appears most clearly. Due to the smaller image size, image processing will generally be faster in both cases.

- ☐ Activate internal illumination
- ☐ Activate external illumination

With the illumination settings, you can switch off the internal illumination and possibly activate external illumination with the *Flash sync output*. If you wish to use the external *Flash sync output*, this must be chosen accordingly in the *Digital I/O* menu. You can also activate both type of illumination.

The *Flash Sync Signal* is located parallel to the exposure time on the digital I/Os. The exception to this is the 4-pin connection on devices with interchangeable lenses. Here the signal is available at a maximum of 1 metre per second if the operating mode *Activate external flash controller* (max. 1 ms) is selected.

(device dependant)

☒ **Activate distortion correction** ...

This function enables a previously calibrated lens distortion correction to be activated or the configuration page to be opened.



NOTE

Only use contour recognition sensitivity when all of the other image settings have been performed successfully.

(device dependant)

Edge detection sensitivity:



To ensure consistent evaluation, all contours must be calculated consistently. This means that the image is sharply focused and no over biases occur.


For critical objects, it may be appropriate to adjust the sensitivity of edge detection manually. Set the Edge detection sensitivity to a value where the feature to be inspected is clearly recognizable.

Make sure that the contours of the test object are consistently obtained and that not too many "pseudo-contours" are created.


You can make the contours visible using the following button from the image display options:



Example images of contours



Too few contours
(contour recognition sensitivity must be decreased)



Good contours
(optimum contour recognition sensitivity)



Too many contours
(contour recognition sensitivity must be increased)

NOTE

Error message: "Too much contour points! Please reduce the number of contour points."

You may avoid this error with the following corrective actions:



- Adjust the application set-up:
 - For example, change the position of the object being examined so that interfering structures that create unnecessary contour points are outside of the image area
 - Cover up the interfering structures.
- Adjust the edge detection sensitivity.
- Reduce the image noise using lower amplification and correspondingly longer exposure or stronger illumination.

(device dependant)

☐ Use gamma correction

Activate the function "Use gamma correction" if you wish to emphasize contours in dark areas of the image. This option may also be appropriate to reduce the effects of reflections when the image is acquired. This makes the sensitivity of the acquisition non-linear, brightening darker areas of the image and diminishing the contrast of brighter areas of the image.

NOTE


When using gamma correction, the "Reference surface" function can only be used to a limited extent for individual feature checks (e.g. Brightness etc.)!

(device dependant)

☐ Use shading correction [...](#)

This function enables a previously calibrated shading correction to be activated or the configuration page to be opened.

The following value can be set via the process interface:

Entry value	Data type	Range of values	Unit
Exposure time	Integer	device dependent	µs
Amplification	Integer	0 – 100	
Edge sharpness	Integer	5 – 100	
Trigger mode	Integer	1 – continuously 4 – external trigger	
Trigger delay	Integer	0 – 6000	ms

9.1.2 Coordinates (device dependant)

NOTE



Depending on the device, automatic variants are available for converting the internal image coordinate system (which has the unit pixel) into a user-defined coordinate system using calibration templates.


To do this, activate the distortion correction on the *Image capture* tab.

With the Vision Sensor, there is an option to convert the internal image coordinate system (which uses pixel as its unit) to a user-defined coordinate system (e.g. using millimetres). To do this, it is necessary to specify the real coordinates for a few data points in the image referenced to a world coordinate system in order to teach the Vision Sensor the distance in your unit.



☐ Convert image coordinates to world coordinates

If you want to convert the coordinates, activate this option. Following configuration, the unit you have defined can be selected as the [Units] option for the corresponding feature checks.



Process


1. Place a defined test image of your choice (e.g. graph paper) into the field of view of the sensor.
2. Activate: *Convert image coordinates to world coordinates*.


- Mark at least four coordinates on the image with defined distances between them. Base this on your defined test image. The order is not important.

To achieve high conversion accuracy, ensure that the marked coordinates:

- are positioned in the image as precisely as possible,
- are uniformly distributed throughout the image,
- do not lie on one line.

	X in [Units]	Y in [Units]	
1	0,00	0,00	
2	30,00	0,00	
3	0,00	20,00	
4	30,00	20,00	





- Enter the values for the marked coordinates. In this example, it is millimetres. Keep in mind that the coordinates must be specified with respect to a right-handed coordinate system (X towards the right, Y towards the top). The *Application Suite* suggests values for you, correct them if necessary.




- During the coordinate conversion process, the individual points are checked for validity. Points whose coordinates deviate too greatly from the calculated position following conversion are marked in yellow or red.

In this case, check all points for the correctness of position and of the coordinates. If necessary, shift the points or adjust the entered coordinates. A small line indicates the direction in which the point should be shifted.

If you now allow the results of the corresponding feature checks to be given in [Units], the value produced conforms with your defined coordinates in millimetres.

There is an option to define more than four coordinates. Having more coordinates makes the conversion more precise. To do this, use the following buttons.



Use the *Add* button to add additional coordinates to increase the accuracy of the conversion.



Delete individual points using the *Delete* button.



The *Delete all* button deletes all coordinates.

☐ Correct lens distortion

To increase the precision of the calculated coordinates, you can also correct for the distortion of the camera lens. In this case, you will need at least eight coordinates.

9.1.3 Coordinates (with distortion correction enabled – device dependend)

When distortion correction is enabled there is an option to convert the internal image coordinate system (which uses pixel as its unit) to a user-defined coordinate system.

This requires the real coordinates in the image to be calibrated to a world coordinate system with a calibration template or manually.

NOTE



A calibration template is required for calibration using the *Point*, *Target grid* and *SmartGrid* methods.

After successful installation, the calibration templates can be found in the directory:


<installation path>\AppSuite\calibration

on your PC.

NOTE



The Image recording tab has to be used to activate *Enable distortion correction...* to allow configurations to be entered here.




Procedure (coordinates X, Y)

There are three methods for determining coordinates:

- **Point and target grid** (automatic version that orients itself to the target grid)
- **Point & point** (manual version without target in which two reference points are established)
- **SmartGrid** (automatic variant based on *SmartGrid*, where the reference point, orientation and units are learned)

Point and target grid



The screenshot shows the 'Coordinates' tab with the following settings:

- Convert image coordinates to world coordinates:** ☒
- 1. Select method:**
 - ☒ Point & target grid (with 'Teach' button)
 - ☐ Point & point
 - ☐ SMARTGRID
- 2. Set target parameters:**
 - Reference point: X: 0.00 [Units], Y: 0.00 [Units]
 - Grid: 5.00 [Units]
- Orientation:**
 - ☒ Right-handed
 - ☐ Left-handed
 - 0°
- Buttons: 'Apply on Device' and 'Cancel'

1. Place the desired target grid with world coordinate system orientation into the Vision Sensor's field of view. If a *SmartGrid* is used for this purpose, only the chessboard pattern is used; other information (reference point, orientation, units) is ignored.
2. Press the *Edit* button.
3. Select the *Point and target grid method*.
4. Press the *Teach* button.

→ The grid points will be programmed and marked with a small orange cross. A reference point will also be inserted.

NOTE



Should this teaching fail, a user defined coordinate system could be programmed. Causes could be:

- The target squares are too small (minimum size 20 x 20 pixels)
- There are too few squares in the field of view (at least 5 x 7 squares are required, preferably more)
- The target is partially covered

5. Drag the reference point onto a grid point of your choice.

6. Set the target parameters. Assign coordinates to the reference point. Determine the units for the grid.
7. Determine the orientation for the coordinate system (left-handed / right-handed).

**NOTE**

The overlaid coordinate system only specifies the orientations (X,Y) and does not necessarily show the zero point!

8. Determine a main orientation for the coordinate system. These orientations will be aligned to the target grid. Rotation is thus only possible in steps of 90°.
9. Press the *Transfer to device button*.
→ The programmed coordinates will be transferred to the Vision Sensor.

**NOTE**

A reference point cannot be moved once it has been programmed. Renewed teaching is required to determine a new reference point.

Point & point




Image acquisition | **Coordinates** | Focusing

☒ Convert image coordinates to world coordinates

1. Select method:

- ☐ Point & target grid
- ☒ Point & point
- ☐ SmartGrid

2. Set target parameters:

	Reference point 1	Reference point 2
X:	0.00 [Units]	10.00 [Units]
Y:	0.00 [Units]	0.00 [Units]

Orientation:

- ☒ Right-handed
- ☐ Left-handed

Apply on Device
Cancel

1. Place the desired target grid with world coordinate system orientation into the Vision Sensor's field of view. If a *SmartGrid* is used for this purpose, only the chessboard pattern is used; other information (reference point, orientation, units) is ignored.
2. Press the *Edit button*.
3. Select the *Point and point method*.
4. Now move both reference points to a mark of your choice.
5. Assign coordinates to each of the reference points.
6. Determine the orientation for the coordinate system (left-handed / right-handed).



NOTE

The overlaid coordinate system only specifies the orientations (X,Y) and does not necessarily show the zero point!

7. Press the *Transfer to device button*. The programmed coordinates will be transferred to the Vision Sensor.

SmartGrid




Image acquisition | **Coordinates** | Focusing

☐ Convert image coordinates to world coordinates

1. Select method:

- ☐ Point & target grid
- ☐ Point & point
- ☒ *SmartGrid*

2. Set target parameters:

Reference point

X: 0.00 [Units]

Y: 0.00 [Units]

Grid

5.00 [Units]

Orientation:

- ☒ Right-handed
- ☐ Left-handed

0°

Teach

Apply on Device

Cancel

1. Place the *SmartGrid* with world coordinate system orientation into the Vision Sensor's field of view.
2. Press the *Edit button*.
3. Select the *SmartGrid* method.
4. Press the *Teach* button.

→ The grid points will be programmed and marked with a small orange cross. Furthermore, a representative reference point is inserted and the alignment is determined according to *SmartGrid*. The reference point can optionally be moved by mouse, the corresponding coordinates are displayed in the greyed out Reference Point field.

NOTE



Should this teaching fail, a user defined coordinate system could be programmed. Causes could be:

- The SmartGrid squares are too small (minimum size 20 x 20 pixels)
- There are too few squares in the field of view (at least 6 x 8 related squares are required, preferably more)


NOTE



The overlaid coordinate system only specifies the orientations (X,Y) and does not necessarily show the zero point!

5. Press the *Transfer to device button*.
 → The programmed coordinates will be transferred to the Vision Sensor.

Z correction (device dependent)



Coordinates (X,Y)

World Coordinates are available from *SmartGrid*/calibration (09.09.2019 14:22). [Units] = mm

☒ Convert image coordinates to world coordinates Edit

Z Correction ⓘ

Z Calibration is available (08.10.2019 13:00).

☒ Use Z Correction

Distance object to reference level

Diagram: Object (6.0 mm) | SmartGrid (3.0 mm) | Reference level

Here you have the option of adjusting the X, Y coordinates to a different height Z. This may be necessary if the distance set during the distortion correction (*SmartGrid* surface to the reference plane) deviates from the current height.




NOTE

A *distortion correction* and *Z-calibration* must be performed before the Z-correction can be performed.

1. Set the checkmark for *Convert image coordinates to world coordinates*
2. Set the checkmark for *Apply Z Correction*.
3. Enter the desired distance for *Distance object to reference plane*.

9.1.4 Focus

The focus option uses a graphical display to help you focus the Vision Sensor.



Focussing the Vision Sensor

1. Point the device's field of view towards a model piece. Limit the field of view as required.
2. Now adjust the focus on the Vision Sensor. To do this, use the focus setting screw and the installed lens.

→ You will see how the focus changes. The best value may also increase.
3. Adjust the focus until you have achieved the optimum result (highest focus value).

Reset best value: Use this to reset the best value to the current focus value.

Limit field of view: Use this function to limit the field of view, otherwise the entire image area will be used to calculate the focus.


9.1.5 White balance (device dependant)

The white balance adjusts the colour sensitivity of the device to the current lighting situation. The white balance setting is stored in the respective job.



NOTE

If the white balance has not yet been carried out, an exclamation mark is shown on the tab above.



Run white balance

1. Direct the device's field of view onto a white surface (e.g. white paper) or limit the field of view to a white area in the image.
2. Now click on the *Image acquisition* tab and change the exposure time to create an image that is as homogeneous as possible and slightly grey.
3. Click on the *White balance* tab again and then on the Run button. The three RGB values should now be similar to one another, see the status bar below.

Once the white balance has been run, you can reconfigure the exposure time on the *Image acquisition* tab to suit your requirements.


Run: Run white balance with currently displayed image.

Reset to standard: reset to the factory white balance setting.

Limit field of view: Limit the area used for the white balance. This may be necessary if only part of the image is suitable for white balancing.

9.2 Checking features

The features to be checked are composed and their parameters set in this step.



NOTE




Please note that even the best feature check can only calculate a satisfactory result if the associated feature is clearly visible in the image.

If necessary, check the parameters for the image exposure again to obtain an optimum image quality for your task!


NOTE



As each inspection task has tolerances with regard to the position of the test object, most jobs begin with part location. The part location feature searches for the reference edges of the test object and aligns all subsequent feature checks according to these reference edges.



Add opens the New feature check dialogue. In this, a list of all available feature checks is presented. When a feature to be checked has been selected, this appears automatically in the feature list, with its current result and the associated status.




A previously selected feature check is edited here.



Deletes a selected feature check from the list of features.



Deletes all feature checks from the list of features.




Each feature is optimized for just one inspection task and supplies a Pass or Fail result. Partial results (e.g. brightness - mean brightness) can also be delivered via the process interface.

Show older versions: This function shows you versions of feature checks from earlier releases (labelled accordingly) along with the current ones, e.g. to use in already successfully implemented applications. We recommend that you use the current feature checks. It is not possible to convert from an older to a newer version.



NOTE

The results of the feature checks can be connected at a later stage (device dependant).






Right click on a configured feature check to access further functions.


Example: Feature comparison brightness with part location on contours

Part location on contours:

With this feature check, the position of an object is determined using contours.



- Choose the shape of the area from which the contours are adopted.



Adopt the contours by pressing "Teach". A search is then made for the object in the entire image.



- The match of the contours with the found object in the image is displayed here.
- Using the appropriate switching points, set how good the match must be so that the object is found. The button on the extreme right inverts the set point.




- **Contrast:** Set the minimum contrast of the contours that should be adopted in the model.
- **Form:** Select the shape of the contour that corresponds to the test object and that should be adopted in the model. (Limiting the angular range reduces processing time.)
- **Mode:** Set the amount of detail to be used in the inspection. (The more detailed the mode, the higher the processing time.)
- **Max. rotation:** If you want to find the object only in a limited angular range, you may specify the maximum rotational position here.

☐ Limit search area

- If you do not wish to search for the object in the entire image, set the tick and then limit the detection area.

Model editor tab



- With the displayed model, you can now use the mouse to delete contour points which clearly do not belong to the reference object.



- Use this button to restore the model to its original state.



- You can use these two buttons to enlarge or reduce the model.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

Feature check Brightness

This sensor task measures the mean brightness in a field of view and compares the result with the specified switching points.

This feature check supports external Teach. The switching points are adjusted as an absolute to the current measured value.

Process "Brightness 1"


Brightness:  Min Max 

Reference area:

Form:

Track position on:

External teach:



Form:

- Select the shape of the field of view. A circle, a rectangle and a freely definable polygon, a circular ring and a circular ring sector are available.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.

Brightness:  Min Max 

- The current result for brightness is shown as a mean grey scale value. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Track position on:

Position tracking on contours 1 ▼

External teach:

- Do not use - ▼

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.

Reference area: Do not use ▼ Apply reference value

In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.

- **Use, do not carry reference area:** Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.
- **Use, carry reference area:** This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.

The mean brightness in the field of view of the reference area should exceed a grey scale value of 128 to ensure reliable operation.



NOTE

If "Use, carry area" cannot be selected, then you have not defined part location.

✓ OK
✗ Cancel

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



NOTE

Once installation is complete, you will find a range of application examples that provide you with typical solutions for various inspection tasks and for the use of the individual feature checks. After successful installation, the examples can be found in the subdirectory:

`<installation path>\AppSuite\Samples`

9.3 Configuring interfaces

9.3.1 Occupancy of digital I/Os

You can adjust the settings for the digital interface on this dialogue page.

Occupancy of digital I/Os		Timing digital I/Os	Output proc
	Output 1: Total result	Signal for	
	Output 2: Partial result 1	Signal for	
	Output 3: - not configured -	Signal for	
	Output 4: - not configured -	Signal for	
	Output 5: - not configured -	Signal for	

NOTE



Please keep in mind that, during job switching, the device is not active and the "Camera Ready" output is deactivated. Please wait with the next image analysis operation until the "Active" state is displayed again by this signal. If the switch could not be performed, for example, because the job number was invalid, an alarm signal is also output until the next trigger.

Output 1-5

Enter how the outputs are to be activated here. You can choose between these three options: Total result, Partial result, Alarm. For the results output, you may also choose whether you want a signal to switch for a pass or a fail result.


You may output the Total result and the Partial results via the digital interfaces. To do so, configure the required output in *Device menu*.

Flexible result conjunction (device dependant)

Result conjunction		Nominal result	Actual result
☒ Total result ☐ Partial result 1 ☐ Partial result 2 ☐ Partial result 3			
& AND		 OK	 OK
[1] Part location on contours 1		 OK	 OK
[2] Text 1		 OK	 OK

In this dialogue, you can specify how the feature check results are to be logically linked together to produce the result of the job.


You can specify one Total result and several Partial results for each job. In addition, it is possible to use the Partial results for the configuration of the Total result.



It is possible to link the results with the following operations for configuration:

- AND ("The results of all feature checks are OK.")
- OR ("The result of at least one feature check is OK.")

You can also invert and ignore the result of a link by selecting the entry "NOK" or "Ignore" in column "Nominal result".



It is possible to nest the links to any desired depth to achieve even more complex expressions. You can insert new levels by selecting the "Insert expression" value in the context menu and then the appropriate type of link. For each sub-link, you can now select the corresponding feature checks to be used for the evaluation. Each feature check can appear any number of times in the overall expression, but only once at each level.

Example

(Brightness 1 OR Contrast 1) AND (Brightness 2 OR Contrast 2)

☒ Total result ☐ Partial result 1 ☐ Partial result 2 ☐ Partial result 3 ◀ ▶		
Result conjunction	Nominal result	Actual result
AND	OK	OK
OR	OK	OK
[1] Brightness 1	OK	OK
[2] Contrast 1	OK	OK
OR	OK	OK
[3] Brightness 2	OK	OK
[4] Contrast 2	OK	OK

Part location on edges 1 AND (Contour comparison 1 OR Count contour points OR Brightness 1)

☒ Total result ☐ Partial result 1 ☐ Partial result 2 ☐ Partial result 3 ◀ ▶		
Result conjunction	Nominal result	Actual result
AND	OK	OK
OR	OK	OK
[2] Brightness 1	OK	OK
[3] Contour comparison 1	OK	OK
[4] Count contour points 1	OK	OK
[1] Part location on edges 1	OK	OK

NOT (Brightness 1 AND Contrast 1) OR (Brightness 1 AND Area size 1 AND Contour comparison 1)

☒ Total result ☐ Partial result 1 ☐ Partial result 2 ☐ Partial result 3 ◀ ▶		
Result conjunction	Nominal result	Actual result
OR	NOK	NOK
AND	OK	NOK
[1] Brightness 1	OK	NOK
[2] Contrast 1	OK	OK
AND	OK	NOK
[1] Brightness 1	OK	NOK
[3] Contour comparison 1	OK	OK
[4] Area size 1	OK	OK

Digital inputs in results conjunction (device dependent)

You can also include the states of the digital inputs in the total result. They can be nested just like the other feature checks.

The states of the digital inputs are captured at the trigger point.


The states of the digital inputs alone cannot be linked; there must be at least one feature check!

NOTE



To use the digital inputs in the result conjunction, you must select the relevant *External Sensor* input in the device settings.

Device → Device Settings → Digital I/Os



9.3.2 Timing digital I/Os

Occupancy of digital I/Os
Timing digital I/Os
Output process interface
Input process

Processing time

Duration: Do not limit 10 ms

Output


Time: Immediately after image evaluation 62 ms

Output forerun: 0 ms

Duration: Until next result 20 ms

[Configured outputs dissenting...](#)

In this dialogue, you can define when the output time is reached and how long the output is to be. The timing diagram displays the process visually and you can mouse over various positions to bring up further details.



Following image acquisition, the *Image trigger permitted* signal is deactivated. The *Image trigger permitted* signal is activated again at the end of image acquisition and another image acquisition operation is possible immediately.

The Pass/Fail signal then switches at the set output time even if additional analyses have already been performed. The Result *valid* signal is active during this time.

A maximum of 64 results can be temporarily saved.

NOTE



If the set output time has been reached prematurely, the calculation in the Vision Sensor is aborted. The result and all partial results are then NOK.

The duration of the output signal is used to specify for how long the output signal (Result valid, Pass/Fail, Alarm) should be produced. Depending on the settings, the signal will either be reset once the set pulse has elapsed, or reset with the next result.

NOTE



If you have connected an encoder, you may set output time and duration as a distance.

In addition, you can specify an "output run-up" in milliseconds to activate the Pass/Fail signal before reaching a specific position.

This option is available if an exact output time has been specified (identical earliest and latest output times) and this is specified as a distance.

Keep in mind that, in this case, the conveyor speed must be constant!

There is also the option to set different times for individual outputs.

[Configured outputs dissenting...](#)


In the drop-down menu, different individual timings can now be set for outputs with a result. These are selected with the checkbox.

Use dissenting settings for ...

☐	Output 1 (Result : - not configured -)	Time:				Forerun:		Duration:		
☐	Output 2 (Result : Partial result 1)	Time:	Immediately	62	ms	Forerun:	0 ms	Duration:	Until next result	20 ms
☒	Output 3 (Result : Partial result 3)	Time:	Always after	70	ms	Forerun:	0 ms	Duration:	Until next result	20 ms
☐	Output 4 (Result is valid)									
☐	Output 5 (Camera Ready)									

In this example, only output 3 has a different output time, although output 2 is also in use. They both follow the general output time.


The different settings can be viewed in the timing diagram once you have left the menu.



Conveyor speed:

9.3.3 Output Robotics (device dependent)

In this dialogue, you can configure the data outputs for the Robotics.




NOTE

You can configure the activation of this interface in the *Device settings*.
Device → Device settings → Robotics

Waypoint feature: Select the feature check for the waypoints of the robot. The first robot-compatible feature check that has been configured is entered automatically. If no robot-compatible feature check is selected, then no waypoint coordinates determined by the image processing can be used.



NOTE

To be able to select a feature check on *Feature by Waypoint*, the *distortion correction* and *Z calibration* must be configured. Furthermore, *Convert image coordinates to world coordinates* must be activated.

With the **+** and **-** buttons, you may add a new line or erase the currently selected line, respectively. Each line contains one feature to be transferred.



NOTE

For the robotics-supported image-based feature check of objects to function properly, at least one of the following configurations must be made:

1. define a characteristic for waypoint
2. create result data as a variable

Without one of these settings, it is not possible to activate the job on the robot.

Data table settings

The following items are selected in the table:

Column	Meaning
Active	If this entry is marked, the selected value for the robot control is entered in the datagram.
Feature	The setting or the feature check from which a value is to be transferred is selected here.
Value	The result of the feature check that is to be transferred is selected here. The "Result" option (for the OK/NOK result of the feature check) is always available. All other results depend on the relevant feature check or setting.
Variable name	Here you can specify a variable name. This is freely selectable, but is automatically prefixed VSV_. You can add 11 additional characters. If nothing is entered, it is automatically numbered (VSV_Var1, VSV_Var2, VSV_Var...) These variables are then available in the robot controller. NOTE  Using the same variable names in different jobs can lead to problems if the data type (integer, float string) of the variable value changes. Assign job-specific variable names if the data type changes!

The following table explains the meaning of various settings for features and values.

Parameters		Meaning
Feature	Value	
Time	Image acquisition	Provides the time of the image acquisition in milliseconds since the device was switched on. A 32-bit wide counter (0 - 4294967295) is used, which starts again at 0 after reaching the maximum.
Result	Total result	If this selection is activated, the total result or the partial result of the job is transferred. Result (2 characters): - Characters: "P" or "F" for a Pass or Fail result - Characters: "A" or space for "Alarm triggered" or "No alarm triggered". Partial result (1 character): "P" or "F" for a Pass or Fail result "I" if the partial result was not output during the job
Result	Partial result	
Statistics	Total result	If this option is activated, the statistics for the result are included. The total number of images, the number of OK images and the number of images for the total result that triggered an alarm are all transferred, with the individual values separated with a separator.
Statistics	Partial result	

Parameters		Meaning
Feature	Value	
Trigger	Additional data trigger	If this selection is activated, the string transferred via the TD command is mirrored back as a control option.
Trigger	Image counter	If this selection is activated, a 16 bit wide counter (0-65535) is used. This increases by 1 with each image acquired and resets to 0 once it reaches 65535.


NOTE

Following the descriptions of the individual feature checks, there is a table containing the values which can be output via the process interface.

Example output robotics

Transfer of the determined coordinates of the feature check *Find object positions* to the robot controller.

1.	Configure the <i>Find object positions</i> feature check.	
2.	With <i>Feature for Waypoint</i>, the configured feature check is now automatically selected. The preview window <i>Data view</i> shows you how the data is output to the robot controller via the process interface.	



NOTE


The further configuration then takes place on the robot controller.

9.3.4 Output process interface (device dependant)

In this dialogue, you can configure the data outputs via the process interface.

A detailed description of the process interface can be found in the section *Communications via the process interface*.

You can configure the technical parametrization of this interface in the *Device settings*.



The length of the datagram includes the header and end identifier.

You may select as many entries for the transfer as you wish in the table.

With the **+** and **-** buttons, you may add a new line or erase the currently selected line, respectively. Each line contains one feature to be transferred. Using the arrow keys, the currently selected line can be moved upward or downward thereby changing the data sequence in the data packet.

General settings

Parameters	Meaning
Start	Character string as a start sequence preceding the data block. This character string is freely selectable (e.g. <Start>).
Separator	Character string included as a delimiter between each individual result of the feature check (e.g.)
End	Character string as an end sequence concluding the data block. This character string is freely selectable (e.g. <End>).

NOTE



To enter binary characters, you may use the `\` symbol in the text. The value can then be specified in hexadecimal format. To add a backslash, enter `\\`. The character `\00` cannot be used.

Example:

`\\09` corresponds to a tab
`\0D\0A` corresponds to <CR><LF>

Data table settings

The following items are selected in the table:

Column	Meaning
Active	If this entry is marked, the selected value is entered in the datagram.
Feature	The setting or the feature check from which a value is to be transferred is selected here.
Value	The result of the feature check that is to be transferred is selected here. The "Result" option (for the OK/NOK result of the feature check) is always available. All other results depend on the relevant feature check or setting. Should a value consist of multiple components (e.g. a point consists of the X and Y coordinates), these are separated with the separator set within the general configuration.
Start	This character string prefixes the result to be transferred and can make it easier for the receiver to interpret or make the data packet readable for human users.  NOTE Amendment option device dependant.
Format	The format used to represent the data to be transferred is set here. The options provided depend in principal on the values available. Customarily, the following possible options are offered: • ASCII (2 decimal places) • ASCII (Exponent) • Decimal • Binary (Little Endian) • Binary (Big Endian)  NOTE This means that the data packet can contain characters that are normally used as control characters for serial interfaces or in the protocol. This setting is only recommended if the operating conditions are appropriately secured!  NOTE Amendment option device dependant.
Min. length	The minimum length of the values is adjusted here. - Should the value be larger than the set minimum length, the length will be exceeded accordingly - Modifications of the length depend on the data type, for example, a binary value is 4 bytes long - The modification is carried out by prefixing or suffixing with zeros or spaces (depending on the data type)  NOTE Amendment option device dependant.

The following table explains the meaning of various settings for features and values.

Parameters		Meaning
Feature	Value	
Time	Image acquisition	Provides the time of the image acquisition in milliseconds since the device was switched on. A 32-bit wide counter (0 - 4294967295) is used, which starts again at 0 after reaching the maximum.
Result	Total result	If this selection is activated, the total result or the partial result of the job is transferred. Result (2 characters): 1. Characters: "P" or "F" for a Pass or Fail result 2. Characters: "A" or space for "Alarm triggered" or "No alarm triggered". Partial result (1 character): "P" or "F" for a Pass or Fail result "I" if the partial result was not output during the job
Result	Partial result	
Statistics	Total result	If this option is activated, the statistics for the result are included. The total number of images, the number of OK images and the number of images for the total result that triggered an alarm are all transferred, with the individual values separated with a separator.
Statistics	Partial result	
Trigger	Additional data trigger	If this selection is activated, the string transferred via the TD command is mirrored back as a control option.
Trigger	Image counter	If this selection is activated, a 16 bit wide counter (0-65535) is used. This increases by 1 with each image acquired and resets to 0 once it reaches 65535.



NOTE

Following the descriptions of the individual feature checks, there is a table containing the values which can be output via the process interface.


Example

Output via the process interface of the data read from the Spacing feature check.




NOTE

The preview window on the right shows you in real time how your settings affect the data to be transferred.

1.	Configure the <i>Distance</i> feature check.															
2.	Go to the <i>Configure interface</i> → <i>Output process interface</i> step.															
3.	Configure all of the settings in the overview for the data output (see Data table settings). (1) Select the feature check / setting to be output. (2) Select the value to be output. (3) Set the start character, separator and end character for the datagram.															
Occupancy of digital I/Os Timing digital I/Os Output process interface Input process interface Start: <Start> Separator: End: <End> <table><thead><tr><th></th><th>Active</th><th>Feature</th><th>Value</th><th>Start</th><th>Format</th><th>Min. length</th></tr></thead><tbody><tr><td>1</td><td>☒</td><td>Distance 1</td><td>Distance</td><td></td><td>ASCII (2 decimal places)</td><td>0</td></tr></tbody></table> 1 2 3				Active	Feature	Value	Start	Format	Min. length	1	☒	Distance 1	Distance		ASCII (2 decimal places)	0
	Active	Feature	Value	Start	Format	Min. length										
1	☒	Distance 1	Distance		ASCII (2 decimal places)	0										
4.	Now the preview window on the right will show how the data will be output via the process interface. The RD (R esponse D ata) and the number of characters (4 byte ASCII-Hex) will still be prefixed (see RD Reply).	<Start>186.00<End>														
5.	In this case the device would send to the controller:	RD0013<Start>186.00<End> (Note: 0013 _{HEX} = 19 _{DEC} , length is therefore 19 characters)														

9.3.5 Input process interface (device dependant)

Via the *input process interface* it is possible to set, for example, the expected values of the identification (barcode, matrixcode, text) sensors using the SP ("Set Parameter") command. You can also set parameters for image acquisition.



The length of the datagram includes the header and end identifier.

You may select as many entries for the transfer as you wish in the table.

With the **+** and **-** buttons, you may add a new line or erase the currently selected line, respectively. Each line contains one feature to be transferred. Using the arrow keys, the currently selected line can be moved upward or downward thereby changing the data sequence in the data packet.

General settings

Parameters	Meaning
Start	Character string as a start sequence preceding the data block. This character string is freely selectable (e.g. <Start>).
Separator	Character string included as a delimiter between each individual result of the feature check (e.g.)
End	Character string as an end sequence concluding the data block. This character string is freely selectable (e.g. <End>).

NOTE



To enter binary characters, you may use the \ symbol in the text. The value can then be specified in hexadecimal format. To add a backslash, enter \\. The character \00 cannot be used.

Example:

\\09 corresponds to a tab
 \0D\0A corresponds to <CR><LF>

Data table settings

The following items are selected in the table:

Column	Meaning
Active	If this entry is marked, the desired value is entered in the datagram.
Feature	The setting or the feature check from which a value is to be transferred is selected here.
Value	The result of the feature check that is to be transferred is selected here. The results depend on the relevant feature check.
Start	This character string prefixes the result to be transferred and can make it easier for the receiver to interpret or make the data packet readable for human users.
Format	The format used to represent the data to be transferred is set here. The options provided depend in principal on the values available. Customarily, the following possible options are offered: • ASCII (2 decimal places) • ASCII (Exponent) • Decimal • Binary (Little Endian) • Binary (Big Endian) NOTE  This means that the data packet can contain characters that are normally used as control characters for serial interfaces or in the protocol. This setting is only recommended if the operating conditions are appropriately secured!
Fixed length	The length of the expected values is adjusted here. Missing characters are filled with zeros (numbers) or spaces (text).



NOTE

Following the descriptions of the individual feature checks, there is a table containing the values which can be input via the process interface.


Example

Setting an expected value for the *Text* feature check via the process interface and determining the required command.




NOTE

The preview window on the right shows you in real time how your settings affect the data to be sent.

1.	Configure the <i>Text</i> feature check.	
2.	Go to the <i>Configure interface</i> → <i>Input process interface</i> step.	
3.	Configure all of the settings in the overview for the data input (see Data table settings). - Select the feature check / setting to be set. - Select the value to be output. - Set the start character, separator and end character for the datagram.	
		
4.	You will now see the current set value in the preview window on the right. The SP (Set Parameter) and the number of characters (4 byte ASCII-Hex) will also be prefixed (see SP command)	<Start>17.03.2014<End> NOTE If no value is set as "expected" during configuration of the feature check, no value will be shown in the preview window!
5.	The command to set the expected value for the device to this date is therefore:	SP0017<Start>17.03.2014<End> (Note: 0017_{HEX} = 23_{DEZ}, length is therefore 23 characters)

9.3.6 Web interface

In this step, there is the option to assign functions to the upper 9 buttons of the web interface view.



You can assign configured feature checks and the *Parameters for image acquisition* button to the 9 buttons.

Configurable parameters for 'Distance 1':

	User	☒ Profi	
Working area edge/circle A	☐	☒	
Working area edge/circle B	☐	☒	
Distance	☐	☒	

Once a button has been assigned a function, you can set which parameters for these functions can be configured in the web interface by which user profiles.

If no user profile is used, only the "Expert" column will be used and the "Operator" column will be greyed out.



If you assign this function to a button, you can set parameters for image acquisition (exposure time, amplification, edge sharpness, gamma correction) via the web interface.

9.4 Device activation



Click on *Activate device*.

Confirm the question with Yes.



The device is now in *Activated* mode and processes the created job. The tabs *Productivity / Statistics and Alarms* are displayed on the right in the configuration area.

NOTE



While the Vision Sensor is processing the job, you may continue to retrieve defect images and to save images.


There is also the option to save the current job and all jobs to the PC via the Job menu.




Click on *Switch job...*, to change to a different job stored in the Vision Sensor.



Click on *Configure Device* to return to *Configuration* mode and to make new settings.



Click on *Delete defect images* to delete stored defect images (button only appears when you click on *Defect images* in the display options).




Click on *Reset statistics* to reset the statistics values (number of parts, number OK, NOK, number of alarms).

9.4.1 Productivity / Statistics / Alarms

The three tabs *Productivity*, *Statistics* and *Alarms* provide the following information.

Productivity



The productivity window displays the following values:

- Total number of parts tested; part per second (throughput)
- Overall device computing time in ms (image capture + job evaluation)

The time progression for image capture and job evaluation is displayed graphically.

Breakdown of computing times

- **1** Total time for image capture in ms
- **1a**: Image capture proportion
- **1b**: Trigger delay proportion (if set)
- **2**: Total time for job evaluation in ms
- **2a**: Job evaluation proportion
- **2b**: Proportion of computing time not job-dependent

The total job evaluation time can be reduced by restricting feature tests (e.g. restricting the angular range for part location to contours).

A tool tip with more information will be displayed if you hold the mouse pointer over the bar.

NOTE

The throughput denotes how many items the device is processing per second.

Throughput is higher than the response time suggests. This is because the device is already loading the next image during result calculation and is thus working faster when viewed across all items.



Optimisation:

Parallel processing can be optimised by reducing the time-consuming activity as necessary. Device internal waiting times are avoided if image loading and result calculation have the same duration.

Disadvantage for devices without integral Industrial Ethernet: The device communication response time can be delayed in the case of absolutely parallel execution, since the device is already fully occupied by image processing.

Statistics

Statistics		
Number of parts:	465	5.1 parts/s
Number of OK:	465	100.00%
Number of NOK:	0	0.00%
Number of alarms:	0	0.00%

The statistics window displays the following values:

- Total number of parts tested; part per second
- Number of passed parts (OK) (number/percent)
- Number of failed parts (NOK) (number/percent)
- Number of alarms (number/percent)

Alarms

Alarms		
Alarm details:		
Invalid trigger:	0	0.00%
Evaluation cancelled:	0	0.00%
Job selection error:	0	0.00%
Error on process interface:	0	0.00%
FTP error:	0	0.00%

The Alarms window displays the following values:

- Invalid trigger: Alarms due to mistimed triggering (number/percent)
- Analysis aborted: Aborted operations due to processing timeout (number/percent)
- Error in job selection: Alarm during job selection (number/percent)
- Errors at process interface: Errors at process interface (number/percent)
- FTP error: Error during transfer via FTP (number / percent)

10 Device menu

In the device menu, the basic parameters are set which apply equally to all jobs.

You can find the device menu when you click on *Device*.



NOTE

Please observe that it may be necessary to configure the stored jobs if you change these settings.


10.1 Connect to device...



Click on *Connect to the device*. Now you can see a list of all located devices on the Devices tab. If a device's device settings contain the location, the corresponding devices will be displayed as a topology ("device tree"). This makes it easier to manage even larger installation bases.

The operating mode and connection status to an *Application Suite* are displayed with a pictogram.

If you move your cursor over the respective device, you will see a tool tip with further information.



Options: Here you have the option of limiting the address area in which devices are searched for and of selecting an alternative port for communication. You can also activate the *User-defined list of known devices*.

User-defined list of known devices

The *User-defined list of known devices* allows you to manage devices from one central location. Different users thus have easy access to the same pool of recorded devices or can view their status (e.g. all those in the same plant) without a device disappearing from view or from the access bar due to an amended IP address or a power failure, for instance.

All devices saved here correspond to the devices with bookmarks. If a bookmark is placed against a device, it is automatically adopted into the list and if the bookmark is deleted it is removed from the list.



NOTE

Make security copies of this list on a regular basis.

Process

1. Save a file ending in .txt (e.g. *knownDevices.txt*) on a drive to which all required users have access.
2. Place a check against *Options* → *User-defined list of known devices*
3. Use *Search* to select the .txt file saved as per 1. above.
4. Confirm the entries made with *OK*.

→ All bookmarked devices will now be listed by name and serial number in the saved file and be displayed in the connection dialogue.

Manual IP address: This is where you can call up a device directly via its known IP address or place a bookmark.



NOTE

Once a device is installed in a machine it is typically assigned an IP address. When using PROFINET, the IP address is usually assigned by the PROFINET master.


In the event of temporary access via an external PC from another sub-network (e.g. for resetting parameters) the IP address is temporarily amended when connection is established.

In order for the machine to be able to access the device as usual again after the temporary amendment in IP address, it needs to recognise the previous IP address again.

This occurs by means of a device restart. Please therefore confirm the corresponding question with *Yes*.

Connection: Create a connection to the selected device.

	The Vision Sensor is in the <i>Activated</i> operating mode.
	The Vision Sensor is in the <i>Configuration</i> operating mode.
	The Vision Sensor is in <i>Restore</i> mode.
	The Vision Sensor is not connected to an <i>Application Suite</i> .
	The Vision Sensor is connected to an <i>Application Suite</i> .
	Mark the Vision Sensor as a favourite. Now it will remain in the list even if it is temporarily unavailable.
	Here you have the option to hide devices. You can reveal hidden devices with the <i>Display hidden devices</i> function.



On the *Simulators* tab, you can connect with one of the simulators to simulate a device and modify job settings and device settings without having to connect to an actual device.

Select the desired simulator and click on *Connect*.



NOTE

The device names and device location can be edited under *Device* → *Device settings* → *Device name*.

NOTE

You can launch the *Application Suite* using a command line parameter and automatically connect to the device via an IP address.

Example: `appsuite2.exe /ip=192.168.0.250` (default IP adresse)

There is also the option to launch the *Application Suite* in different languages using a command line parameter.



`/l=de` (German)
`/l=en` (English)
`/l=fr` (French)
`/l=es` (Spanish)
`/l=zh` (Chinese)
`/l=ja` (Japanese)
`/l=ko` (Korean)
`/l=it` (Italian)
`/l=th` (Thai)

Example: `appsuite2.exe /ip=192.168.0.250 /l=en`
(Start the *Application Suite* in English with the default IP address)

NOTE

Should the device no longer be reachable due to adverse factors (e.g. corrupt job data), and cannot be rebooted into Recovery mode independently, it can normally be forced to start in Recovery mode by starting the *Application Suite* with the following command line parameters:



`appsuite2.exe /ip=<device IP address> /rebootrecovery`

This process normally takes a little over a minute. Once complete, the device will be in Recovery mode and jobs can be deleted, device settings can be changed or new firmware can be loaded.

NOTE

Simultaneous connection from the *Application Suite* to the device and a connection via PROFINET or EtherNet/IP to the device is possible.

10.2 Device settings...



The following generally applicable settings are made under the menu option *Device settings*.

10.2.1 Device name

Device name

Device type:

Serial number: 51974313


Device name:

User-defined topology

Device location:

Example: /Factory1/Hall2/Island5

Preview:



☒ Domain name

Name:

Domain: my-device.local

Device type: The device type is permanently stored in the device and is only displayed.

Serial number: The serial number is permanently stored in the device and is only displayed.

Device name: You can assign a name to the device. This is then shown in the device status.

User-defined topology

Device location: You can enter the device location here. The preview changes as you enter the details.

Domain name: Activate this function if you wish to enter a device domain name for your Vision Sensor. This means that you will not only be able to enter the device's IP address to access it via the browser, but also be able to use a preset domain name (e.g. <http://my-device.local>), which has the advantage of being a fixed URL.

NOTE



Several devices with the same domain name in the network could lead to problems. This could occur if the same backup is transferred to several devices. Give each device a unique domain name!

10.2.2 Access rights (device dependant)

10.2.2.1 Application Suite



ATTENTION!

An assigned password cannot be reset without providing the assigned password.

Please remember your passwords!

Three user levels are available for you to avoid unauthorized changes on the device. The individual privileges for these levels are set as follows:

Function	Operator	Expert	Administrator
Activate / deactivate device	+*	+	+
Change the active job	+	+	+
Store and transfer the job to the device		+	+
Process interface assistant		+	+
Change device settings		+	+
Firmware update			+
Backup / restore device			+
Password management / encryption			+

*) if activated

Access rights

Application Suite
Web interface

☒ Restrict access rights for certain user profiles



User

☒ May change jobs, but may not transfer any new jobs.

☐ May change jobs and activate or deactivate the device respectively, but may not transfer any new jobs.

Change...



Profi

May transfer jobs to the device, but may not make any device-related changes.

Change...



Administrator

Has full access to all device functions.


Change...

Activate the option *Restrict access rights for certain user profiles* for using user profiles.

10.2.2.2 Web interface

Two user levels are available for you to use to avoid unauthorized changes being made via the web interface.

The user levels for the web interface can be configured independently and differently to the *Application Suite* user levels. All functions of the web interface are therefore deactivated under factory settings.



Access rights

Application Suite Web Interface

☒ Restrict access rights for certain user profiles

	Operator Functions according to button configuration.	Change...
	Profi Functions according to button configuration.	Change...

Activate the option *Restrict access rights for certain user profiles* for using user profiles.

NOTE




The rights to change individual functions relating to a job can be set during job creation as part of the *Configure interface* → *Web interface* step.

Rights for device-specific functions are set under *Device* → *Device settings* → *Configure web interface*.

10.2.3 Web interface

10.2.3.1 Functions

In this dialogue, you have the option to assign device-specific functions to the three lower buttons in the web interface view.



Icon	Description
	Button has not been assigned a function
	Device info and status
	Statistics
	Processing time
	Change job
	Defect images
	Job management
	Backup
	Language
	Device-specific functions (provides access to all device-specific functions via an additional menu level.)

Configuration of device specific functions:

	User	☒ Profi	
Device info and status	☐	☒	
Statistics	☐	☒	
Processing time	☐	☒	
Switch job	☐	☒	
Defect images	☐	☒	
Job management	☐	☒	
Backup	☐	☒	
Language	☐	☒	



NOTE

Setting web interface access rights: *Device* → *Device settings* → *Access rights / Web interface*

Furthermore, you can define the rights for the different user groups for selected device-specific functions under "*Device-specific function configuration*".

Language settings

Language:  German 

☒ Save selection by web interface

Language: Select the language for the web interface here


Save the selection via the web interface: Activate this function if you wish to save the changes you have made to the language via the web interface. It will then be active immediately when you next start the web interface. You can only save this setting if a language has been set.

Offer continuous image acquisition ☒ For User☒ For Profi**ATTENTION!**

The live image function puts the device into "free running" mode, i.e. it runs without the external trigger signal. Please be aware of the effects this may have on later processes.

No live image will be available in the web interface when reconfiguring feature checks in the web interface for trigger-controlled image acquisition and stationary analysis.

Here, you can set the user level that has the access rights to temporarily set image acquisition to continuous rather than trigger-controlled using the *Live image* button.




Using this button, you can restore the original settings.

10.2.3.2 Design

Logo



Color scheme



 Please click a design element to configure it's color scheme.

Button labelling

☒ Always mask sub-menu functions on buttons




In this dialogue, you have the option to adjust the colour representation of the web interface to suit you, and to integrate your own logo (max. 184 x 23 pixels) into the interface.

Click on the design element you wish to adjust and use the controls to adjust the colour.

In Expert mode, you have the option to enter colour values using hex format (RGB).

Button labels: Activate this function if you do not wish the second row of the buttons to be displayed in the web interface. This is particularly useful for smaller monitors.




Using this button, you can restore the original settings.

10.2.3.3 Security

There is a secure communication option of using SSL/TLS encryption to transmit data between the Vision Sensor web server and the web browser (device dependent).

There is also the option of completely disabling the web interface.



The screenshot shows the 'Security' tab of the Vision Sensor web interface. It contains three checked checkboxes: 'Enable HTTP', 'Enable HTTPS', and 'Automatic redirect from HTTP to HTTPS'. Below these is an information icon followed by the text: 'To be able to use HTTPS the *Root Certificate* must be installed on every client browser.' This is followed by a paragraph: 'You can use the URL `http:// [IP address] /?installCertificate` or [click here](#) to install it in your Browser. Refer to the help for any further information.' A note at the bottom states: 'Note: HTTP must be active to use the above URL or Link.'

HTTP activation: Enable this function to transmit the data in unencrypted form.

HTTPS activation: Enable this function to encrypt the data. Installation of the respective SSL root certificate is required for activation (device dependent).



NOTE

The web interface on the Vision Sensor will be disabled if neither of these two options is enabled.

Automatic switching from HTTP to HTTPS: The address in the browser can start as usual with `[http://...]` if this function is enabled. The browser will automatically switch to `[https://...]` if it supports it (device dependent).

Click *OK* to restart the Vision Sensor and import the settings.

The use of HTTPS requires installation of the SSL root certificate in each browser used. Follow the instructions below to install the certificate for your browser.

Installation of the SSL root certificate



NOTE

HTTP must be active on the device to enable installation of the certificate.

1. Launch the browser on your device. (`http://[IP address] /?installCertificate`)
2. Confirm that you want to install a certificate.
→ The certificate is downloaded from the device.
3. Open the certificate from the folder in which it was downloaded.
4. Click *Certificate installation...*
→ The *Certificate import wizard* will be launched.
5. Click *Continue*.
6. Select *Save all certificates in the following memory*.
7. Click *Search*.
8. Select *Trusted root certification location*. Confirm with *OK*.
9. Click *Continue*.
10. Click *Finish*.
11. Confirm the Security warning with *Yes*.
12. Close and restart your browser.

10.2.4 Robotics (device-dependent)

You can switch the vision sensor to Robotic mode here. This makes it possible to retrofit robots with image processing.

Image processing supports the following use cases:

- the robot-based image-based feature check of objects
- the image-based finding of objects and transmission of the coordinates to the robot through the feature checks, *Part location on contours*, *Point position* and *Find object positions*.



NOTE

An active Robotic mode changes the settings of the process interface. This is now used exclusively for communication with the robot.

Robotics

Mode:  Universal Robot ▼



An active robotics mode changes the process interface settings.
The process interface will be used by the robot only.



In order to provide robot coordinates as waypoint, Distortion correction and Z Calibration are required.


Les modèles suivants d'Universal Robot sont pris en charge :

- UR3e
- UR5e
- UR10e
- UR16e

10.2.5 Digital I/Os

You can adjust the settings for the digital interface on this dialogue page. You can also configure an incremental encoder and specify the polarity of the digital inputs and outputs.

Inputs



Digital I/Os

Inputs Outputs Rotary encoder

☐	Input 1: Trigger	⌋⌋ Rising edge
☐	Input 2: Binary job selection - Bit 0	⌋⌋ High active
☐	Input 3: Binary job selection - Bit 1	⌋⌋ High active
☐	Input 4: Binary job selection - Bit 2	⌋⌋ High active
☐	Input 5: Binary job selection - Bit 3	⌋⌋ High active


Input 1 is reserved for the trigger. For other inputs you can specify how you want to switch the active job. It is also possible to connect an incremental encoder to the Inputs 5 (CH-A) and 4 (CH-B).

Outputs

i

NOTE

The number of configurable outputs is device dependant.



Digital I/Os

Inputs Outputs Rotary encoder

☐	Output 1: Result	⌋⌋ High active
☐	Output 2: Result	⌋⌋ High active
☐	Output 3: Result	⌋⌋ High active
☐	Output 4: Result is valid	⌋⌋ High active
☐	Output 5: Camera Ready	⌋⌋ High active

Enter how the outputs are to be activated here. Hardware signals (image trigger permitted, result valid, result, alarm, flash sync, device activated, heat warning, heat shutdown) can be issued for each output or the output configured for issuing job results.

Encoder

Digital I/Os

Inputs
Outputs
Rotary encoder

Conversion impulses to distance
Number of impulses: 1000 Pulses
Distance: 10,0 mm
☒ Invert rotating direction

Calculate values
Select the size known in advance to calculate the values for conversion automatically.

Known size: Belt speed
Value: 10,0 mm / s Start

Test settings

If an incremental encoder is connected, you must also set the factor between the distance travelled and the number of pulses from the encoder.

To determine this factor, either you must know the conveyor speed or you must move the conveyor belt over a defined distance.

Determine the conversion factor as follows:

- Select the known quantity and set the corresponding value.
- Activate pulse measurement by pressing the *Start* button.
- Move the conveyor belt by the set value.
- Terminate the measurement using the *Stop* button.

Press the Test configuration button to check the current setting.

NOTE



All specifications during configuration refer to the forward motion of the conveyor belt. If necessary, reverse the direction of rotation to allow the device to function correctly.

Make sure that Inputs 4 and 5 are set up correctly if you are using an encoder. If not, operation of the device may be impaired.

10.2.6 Alarm signal

Alarm signal

Alarm, if...


- ☒ Invalid trigger (trigger during image capture or job change)
- ☒ Evaluation cancelled prematurely (output time exceeded)
- ☒ Job selection error (invalid job number)
- ☒ Error on process interface
- ☒ FTP client could not send all files

You can define the conditions which cause an alarm to be initiated here. Alarm signals indicate that an irregularity has occurred in the sensor.

The following causes may trigger the alarm:

Invalid trigger	Trigger during image acquisition, job switching or during parameter setting via the process interface ("SP"-Datagram)
Evaluation cancelled prematurely	The result of computing was not present at the latest output time.
Error in job selection	Invalid job number or job could not be loaded, e.g. because it is not correctly configured.
Error at process interface	An error occurred during data transfer to the process interface, e.g. an invalid command is received.
FTP client could not send all files	An error occurred while transferring the images via the FTP client. Possible causes could include: Device or server overloaded, incorrect access details or server cannot be reached.

10.2.7 IP address / network



IP address / network

☒ Use static IP address

IP address:

Subnet mask:

Gateway:

☐ Use DHCP

Timeout:

After DHCP error:

IP address:

Subnet mask:

Gateway:

Alternative port for communication with Application Suite:

Current IP address: 172.20.20.59 Subnet mask: 255.255.0.0

Gateway: MAC address: 00:06:BE:80:03:68

Set the IP address of the device here. There are two choices for this.

- **Static IP address**
The device uses a set IP address.
- **DHCP (Dynamic Host Configuration Protocol)**
If you have integrated a DHCP server in your network, the IP address is obtained there. If this does not happen within a specific time and a timeout occurs, you can choose whether:
 - the last IP address obtained via DHCP is used
 - another fixed IP address is set

If the port 51.972 (standard) is already being used in your network, you may specify a different port for communication between the connection of the device and the *Application Suite*.



NOTE

This port must also be set in the dialogue *Connect to device - Options*, in order to create a connection.

10.2.8 Process interface (device dependant)

Process interface

Protocol
 Type: TCP

Transmission channel
 Port: 23
 End identifier: <CR>
 Receive timeout: 10 ms
 Connection timeout: Deactivated

Data telegram (RD)
 Time:
☐ Automatically after image evaluation
☒ GD command via process interface
 Structure:
☒ send with command identifier (RD) and length
☐ send result data only ⓘ

Here, you will find all parameters which can be used to configure data exchange via the interfaces.

Protocol

Type: Set the protocol here. The selection shown is dependant on the device.

Port: Set the port for the device's Ethernet interface here.

End identifier: Shows which control character is expected or sent at the end of each datagram.

Receipt timeout: Here, you can set the time after which receipt is stopped.

Connection timeout: The connection is closed if no contact is received within a given time.

NOTE



A TCP/IP connection can be monitored, for example for when the PLC cyclically sends the "GS" command. If the connection is broken, this is shown on the Vision Sensor page and the connection is reset.

Protocol (RS485) (device dependant)

Here, you will find all parameters which can be used to configure data exchange via the RS485 interface. Select device number 1 and the "Bus (without checksum)" protocol type and adjust the other parameters as necessary.

Baud rate: Speed of data transfer (bit/s).

Data bits: Number of bits per character

Device number: If you have multiple devices on one RS485 bus, each device must be assigned a number. (1-254)

Receipt timeout: Here, you can set the time after which receipt is stopped.

Response delay: Duration between reception of a command and transmission of the response

RS485 terminating resistor: Disable the terminating resistor if more than 6 devices are being operated on an RS485 bus.

Parity: Control of the parity bit

Stop bits: Number of stop bits as end code (1)

Protocol: Protocol type (point-to-point, bus without checksum, bus with checksum)

Protocol (PROFINET) (integrated, device dependant)

Here you will find all parameters which can be used to configure data exchange directly over the embedded PROFINET interface. As a rule this generally only relates to changing the IP address to 0.0.0.0. There is also the option of editing the device's PROFINET name. Although this should be assigned using the PROFINET tool and not edited on the device.

NOTE



Once the request has been confirmed and the IP address and subnet mask have been set to 0 . 0 . 0 . 0 the device can never again be accessed via the *Application Suite* and can no longer be reconfigured in this manner. The FTP connection and web interface communication will also be set.

The device can only be accessed via the Application Suite again if a PROFINET tool is used to reconfigure it to an IP address other than 0 . 0 . 0 . 0

Device name: The device name is usually assigned by the PROFINET tool. There is the option here for changing the device name in exceptional cases.

Datagram (RD)

Time:

Automatically following image analysis: the device sends the datagram independently

GD command via process interface: the device's result is requested with the GD command

Structure:

Send with command designator (RD) and length: the device also sends the RD command designator and the length of the result data (prefixed as a header)

Send result data only: the device only sends the result with no additional information. One suitable use for this would be if the application only requires the result data from the device (without header information).

10.2.9 FTP / SFTP

Using the FTP - / SFTP function, you can save selected images on an FTP server during production. This data can be transmitted in encrypted form (SFTP) depending on your device and your server.

It is also possible to save backups of the device to FTP servers and to access them up from there.

NOTE



Please check whether the current status of the *wolfSSL* license meets your security requirements. The license details can be found in the info window of the *Application Suite* (button: *Licenses*).

FTP / SFTP

FTP server

Protocol: SFTP

IP address:

User name: anonymous

Port: 22

Password: ••••••••

Save images on FTP server

Save images: None

☐ Number limitation: 31

Image directory on FTP server: Browse... ...

Name of image series: .bmp ...

Preview: /Image_00000001_OK.bmp

Backup by FTP

Directory for Backup: Browse...

Test connection...

FTP server

Protocol: SFTP (device dependent, encrypted data transmission) / FTP (unencrypted data transmission)

IP address: IP address of the FTP servers

User name: Enter the user name for FTP access.

Port: Port number of the FTP servers

Password: Enter the password for FTP access.

NOTE



To use the FTP server successfully, the device requires read, write and delete access. The device and the FTP server must also be located in the same subnetwork.

The FTP server must support encryption to be able to use SFTP.

Do not save the images and backup file to the same directory on the FTP server. This can lead to long load times.

Saving images to the FTP server

Saving images: Select the images to be stored on the FTP server.

(NOK only = all images with the total result of "Fail", OK only = all images with the total result of "Pass")

Number limit: Use this function to limit the number of images stored. If the limit is reached, the older images will be overwritten.

Image directory on the server: Select a directory on the FTP server where images are to be stored.



Optionally, the structure of the sub directory name can be configured.

The configuration of the sub directory name offers the option of freely arranging up to seven entries, and separators can also be defined.

The device offers the following entries:

- Result
- Result data configured in the output PIF (RD command)
- Additional data transferred to the image via TD command
- Job name
- Job number
- Device name
- Serial number
- Date (Local)
- Year (Local)
- Month (Local)
- Day (Local)
- Hour (Local)
- Date (UTC)
- Year (UTC)
- Month (UTC)
- Day (UTC)
- Hour (UTC)

Name of image series: Provide a name for the image series and set the desired image format. This allows you to influence the amount of memory required per image.



You can configure the structure of the file name.

The file name configuration gives you the option to freely arrange up to seven entries. You can also define separation markers.

The entry options for the device are:


- The chosen name of the image series
- Sequential numbers generated by the system (00000001 – 99999999)
- The result of the analysis
- The additional data applied to the image using the TD command
- The job name
- The job number
- A time stamp (local): FTP server time similar to Time stamp (*UTC*), although here a local offset can additionally be configured under Time zone (*local*). This value consists of the chosen time zone and – if selected – the consideration of summer time. Switching between summer time and winter time then occurs automatically within the device and matches the chosen time zone.
- A time stamp (UTC): Time from the FTP server (the Vision Sensor time is synchronised with the FTP server every time it is restarted).

Backup via FTP

Directory for backup: Select a directory on the FTP server where the backups are to be stored.

10.2.10 Job management

With this dialogue, you can easily and conveniently copy your jobs between a folder on your computer and the Vision Sensor.



Choose the folder on your computer with:  off. The jobs available in this folder are then displayed on the left hand side.

On the right hand side you will see the jobs on the device and their job numbers, as well as remaining storage space available for jobs on the device.



NOTE

Even if no job is available, part of the storage space is occupied by internal files.

Observe that the job number directly corresponds to the binary code with which the jobs are selected in Real time mode via the Job selection via digital inputs.

Power on job: Here you can also choose which job will be loaded when the Vision Sensor is switched on. This job is then marked with this symbol. 


When jobs are switched by the binary method via the digital inputs, no job is active when the device is switched on. In this case, the desired job is selected using the levels present at the inputs.

Save after job selection: Activate this function if you would like the most recently active job to be activated the next time the device is started.

Transfer the jobs using the horizontal arrows and move jobs to the corresponding storage locations in the device with the vertical arrows. You can also use the bottom button to enter the target position for the job directly.

Use the cross to delete jobs.

10.2.11 Job selection / Teach



Job selection / Teach

Job selection via: ☒ Application Suite / web interface
☐ Digital inputs
☐ SJ command via process interface

Parameters after external teach / SP command

☐ save to device ⓘ Changes made via the web interface will always be saved

Here you can basically set how you want to make the job selection.

Job selection via:

Application Suite / Web interface: The job can only be changed manually via the *Application Suite* or via the web interface.

Digital inputs: Jobs are selected via the digital inputs.

Command SJ via process interface: Jobs are selected via the process interface.

Parameters following external teach / SP command

If the "save to device" option is activated, changes resulting from external teach or process interface commands in the job are saved to the device. If this option is not activated, changes are discarded when the device is rebooted. In this case, the originally saved job is executed.

10.2.12 Distortion correction (device dependend)

The recorded images can be contorted by lens distortion or inclined positioning of the Vision Sensor.

The *Distortion correction* function can be used to compensate for these distortions.

The location of the lens will determine the degree to which the image can be compensated for such inclined positioning of the Vision Sensor. A value of around 30° to the ideal location (Vision Sensor is parallel to the object surface) can be assumed as a "rule of thumb", whereby both non-achievement and exceedance of this value is possible.

NOTE

A *SmartGrid* or target is required for calibration of this function.




After successful installation, the *SmartGrids* can be found in the directory:

<installation path>\AppSuite\calibration


on your PC.

You can also open the folder directly from the dialogue.

Distortion Correction



Sensor image



Visible image (with distortion correction)

1. Device calibration:



No calibration available!

Start calibration

Delete

No appropriate target found. [PDF](#)

2. Visible image adjustment:









Definition of reference level Z (optional):

Distance Surface *SmartGrid* to reference level

Import/Export of adjustment:

Export

Import

Requires calibration with SmartGrid.

Performing distortion correction

1. Print the required *SmartGrid* (PDF). Alternatively, ready-made *SmartGrids* are offered.

Requirements

- The *SmartGrids* must have a minimum size of 20 x 20 pixels
- At least 6 x 8 squares are required in the Vision Sensor's field of view, preferably more

2. Place the *SmartGrid* as straight as possible in the entire field of view of the vision sensor. Use the Refresh button to renew the sensor image as necessary. Any image display options, such as a preset rotation, will be ignored.

3. Press *Start calibration*.

→ Distortion correction is performed and coordinates are learned. The yellow light will flash on the display whilst calibration is being performed. Successfully calibrated distortion correction and learned coordinates are indicated by a green light on the display. The date and time of calibration are also displayed.

NOTE

A constant red light means that distortion correction could not be successfully performed.



Causes could be:

- The *SmartGrid* squares are too small (minimum size 20 x 20 pixels)
- There are too few squares in the field of view (at least 6 x 8 squares are required, preferably more)
- the *SmartGrid* is partially covered

4. The preview images will now display the used image area (left pane) and the resulting image (right pane) with a red frame. The generated image will be rotated to match the target's orientation, as long as this rotation lies within the range supported by the Vision Sensor. If you performed the calibration with a *SmartGrid*, you will also be shown the reference point.

You will see a tool tip with accuracy specifications if you move your cursor over the right pane.

5. You can adjust the automatically determined image area if you wish (vertical shift, horizontal shift, magnification and rotation).


NOTE




The larger the corrective rotation, the lower the maximum frame rate to be achieved and thus the part throughput for jobs!

6. Press *OK* to transfer the distortion correction to the Vision Sensor.

Distortion Correction



Sensor image



Visible image (with distortion correction)

1. Device calibration:



SmartGrid Calibration is available (09.09.2019 14:22).

Start calibration
Delete

 A recalibration may require a job adjustment.

Definition of reference level Z (optional): 

Distance

Surface *SmartGrid* to reference level

2. Visible image adjustment:









Import/Export of adjustment: 

Export
Import

NOTE



This function can increase the Vision Sensor's start-up time.

You can reduce the start-up time by pressing *Delete* if this function is not required.

Disabling the function within image settings is not sufficient for this!

Import / export of the customisation

These functions allow you to export visible image settings and transfer them to another device by importing. This makes it easy to change devices.

After import, the visible image shows the same image detail as before during export.

**NOTE**

Importing and exporting only work with coordinates learned by *SmartGrid*.

Reference level Z (optional, device-dependent)

Here, you can enter the distance between the surface of the *SmartGrid* and the reference level (contact surface) during calibration of the distortion correction.

The setting is required if Z calibration is to be used with coordinates at different heights or planes (Z) in the depth of field. A reference plane may be, for example, the machine table and facilitates the handling of the various Z-levels. If the *SmartGrid* is on the machine table, then the value corresponds to the thickness of the *SmartGrid* (e.g. 3 mm for a finished *SmartGrid*).

10.2.13 Z calibration (device dependent)

Image processing is two-dimensional. However, in robotics, the Z-axis (depth) must also be taken into account, because robotics typically works in space. The Z-calibration allows the world coordinates of the vision sensor to be adjusted to a height Z and further processed by a robot.

This function performs the spatial calibration of the captured image.

NOTE

A *SmartGrid* is required for calibration of this function.



After successful installation, the *SmartGrids* can be found in the directory:

<installation path>\AppSuite\calibration


on your PC.

You can also open the folder directly from the dialogue.

NOTE



To demonstrate the movement of the *SmartGrid*, a short tutorial is shown upon activation, which can be repeated via *Play tutorial again*.



Performing Z calibration (device dependent)



NOTE

A *distortion correction* must be performed before the Z-calibration can be performed.

1. Print the required *SmartGrid* (PDF). Alternatively, ready-made *SmartGrids* are also provided.

Requirements


- The *SmartGrid* squares must be a minimum size of 20 x 20 pixels
 - At least 6 x 8 squares are required in the Vision Sensor's field of view, preferably more
2. For *View*, select the angle at which you see the vision sensor. This is for better orientation with permanently installed vision sensors.
 3. Press *Start calibration*.
 4. It is helpful, but not necessary, to place a thin object (such as a nut) in the centre of the vision sensor's field of view, making it easier to tilt the *SmartGrid* in all directions. Use the Live View for placement.
 5. Place the *SmartGrid* onto the placed object, in the complete field of vision of the vision sensor.
 6. Now tilt the *SmartGrid* in all directions.

→ The learning progress is displayed as a percentage. If there are enough calibrated positions, the successful completion of the calibration is displayed.

10.2.14 Shading correction (device dependend)

Uneven lighting can result in some areas of the image being darker than others.

Shading correction provides the option to compensate for brightness irregularities in the image.



Performing shading correction

1. Use the *Image recording* tab to first configure the lighting situation as it will be for the planned feature checks. Activate the internal lighting, for example.
2. Place an homogeneous white or grey template in the Vision Sensor's field of view. Any image display options, such as a preset rotation, will be ignored.
3. Press the *Teach* button.

→ Shading correction will be performed. The teaching of shading correction is performed on the original sensor image and is applicable with or without distortion correction.
4. The gain factor for the individual image areas will be displayed in the preview window for the original sensor image.



NOTE



It may not be possible to fully offset all differences in brightness if the maximum gain factor (3.0) is reached in many areas of the image.

Please check the lighting situation and the homogeneity of the template and perform shading correction again.

5. Press *OK*. The programmed shading correction is saved on the Vision Sensor.

NOTE



This function can increase the Vision Sensor's start-up time. You can reduce the start-up time by pressing *Delete* if this function is not required.

Disabling the function within image settings is not sufficient for this!

10.2.15 Illumination controller (device dependant)



ATTENTION!

Erroneous settings can destroy the illumination! Please follow the information in the data sheets for your illumination. Contact the manufacturer of the illumination if you are unsure about admissible parameters.

Illumination controller

Profile: User defined...
Save as new profile

Operating mode: Flash illumination

Operating voltage of illumination: 12 VDC, flash 24 VDC

Limit the current to: 0.80 A

Maximum flash duration: 1000 µs

Duty Cycle: 10%

Signal assignment

- Output 1: not used
- Output 2: +24V, max. 0.80 A
- Output 3: Ground
- Output 4: not used

Test illumination

Signal sequence on output 2




Warning: Incorrect settings can destroy the illumination! Please follow the information in the data sheets for your illumination. Contact the manufacturer of the illumination if you feel unsafe about admissible parameters.

Using the illumination controller, you can make the settings at the outputs of the illumination port.

You can also use a direct "flash" (flash controller function) alongside directly controlling external illumination. Alternatively, an unamplified signal can be output to an external flash controller.

To use the illumination controller, the device must be in *Configuration* mode. If the menu item is not visible, your device does not support this function.




As soon as you have saved a profile that you created, it is available here.



If you have made your own settings, you may save them as a new profile.




Using this function, you can delete a profile that you created.



You have various operating modes available.

Operating Mode	Description
Deactivate illumination	No settings possible / illumination port deactivated
Steady light illumination	Settings possible (limit operating voltage/current)
Flash illumination	All settings possible
Control the external flash controller	No settings possible, flash sync active
Control the external flash controller (max. 1 ms)	No settings possible, flash sync active (max. 1 ms)
Control the external flash controller (without limit)	No settings possible, flash sync synchronous to exposure active




Here, you can define settings in the current operating mode.

Function	Setting Possibilities
Operating voltage of illumination:	12VDC/24VDC
Limit the current to:	<u>Steady light illumination</u> 0.1A...0.8A (increments of 0.1A) <u>Flash illumination</u> 0.1A...4.0A (increments of 0.1A)
Maximum flash duration:	1µs...1000µs
Duty Cycle:	1%...10%

Signal assignment

	Output 1:	not used
	Output 2:	+24V, max. 0.80 A
	Output 3:	Ground
	Output 4:	not used

This view shows how the signals at the 4 outputs of the illumination port are connected for the current settings.



This diagram shows the current waveform at output 1 and output 2.


10.2.16 Firmware update

NOTE



During restoration of a backup or firmware, the operation of the device by uninvolved programme components (web interface, *Application Suite* or process interface) is not blocked. This means it is possible to interrupt these during the restoration process.

Do not undertake any other actions during the restoration process!



Firmware update

Active version: 10.0.0.0 (10.0.0.0) (10.0.0.0)

Transfer new version

File name:


New version: 10.0.0.0 (10.0.0.0) (10.0.0.0)

This dialogue provides support in the installation of new firmware.


ATTENTION!



Only use the most recently released version of the firmware for updating. You may wish to ask the Support before updating firmware. Create a device backup of your Vision Sensors before updating firmware!



Click on the button *Browse* and select the firmware file to be transferred.
 (File extension *.vsf).




Click on the button *Transfer* to carry out the update.

Factory settings

The *Factory settings* button permits the factory settings to be restored. The current firmware will be retained.

**NOTE**

Restoring the factory settings deletes all of your previous settings and jobs.



Confirm the request with Yes to restore the sensor to the factory settings.

Reboot device

Use the *Restart device* button to restart the device. The functionality is equivalent to switching the power supply off and back on.

Confirm the request with Yes to restart the sensor.

10.3 Backup


NOTE



During the creation and restoration of a backup or firmware, the operation of the device by uninvolved programme components (web interface, *Application Suite* or process interface) is not blocked. This means it is possible to interrupt these during the restoration process.


Do not undertake any other actions during the creation and restoration process!

10.3.1 Backup - using the PC...




This dialogue page supports you in making a complete device backup of your device on the PC. Here device settings, jobs and firmware are saved in a file.

Activate the option "Encrypt backup file with a password" if the backup file is to be stored in protected mode.




NOTE

The device backup cannot be reloaded without knowing the password!




Specify a storage path and a file name for the backup file or click on *Search*. The file extension must be *.vsb.




Click on **OK**. The required file is created. During this process, all device settings and jobs are transferred. This process may take a few minutes.

10.3.2 Backup – using the FTP server...



This dialogue page allows you to create a complete device backup of your device on the FTP. Here device settings, jobs and firmware are saved in a file.

The backup file cannot be protected with a password, and a file name for it cannot be assigned manually.




NOTE




Do not save the images and backup file to the same folder on the FTP server. This can lead to long load times.

FTP settings: *Device* → *Device settings* → *FTP*





Click on **OK**. The required file is created. During this process, all device settings and jobs are transferred. This process may take a few minutes.

10.3.3 Backup – restoring from the PC...



Use this dialogue to transfer a device backup file from the PC to the device.



Specify the storage path of the backup file or click on *Browse*. The file extension must be *.*vsb* .

If this is a protected backup file, you must then enter the password.

Restore following elements:

☒ Device settings
Name of device:
Network settings:

☒ Jobs

☒ Firmware

Here you select what components are to be transferred during the restore process.

**NOTE**

If you restore the factory settings of the Vision Sensor, all unsaved files will be lost!


Now transfer the selected settings and jobs to the device with *OK*. This process may take a few minutes.

(device dependant)

**NOTE**



If the device backup contains a calibrated lens distortion or shading correction, then the backup will only be completed when the device has been switched to set-up mode after recovery (*Device configuration*).

10.3.4 Backup - restoring from the FTP server



Use this dialogue to transfer a device backup file from the FTP server to the device.

With this dialogue, you can transfer a complete device backup from the FTP server to the device. Device settings, jobs and firmware are all restored.



Specify the storage path of the backup file or click on *Browse*. The file extension must be *.vsb .



NOTE

If you restore the factory settings of the Vision Sensor, all unsaved files will be lost!

Now transfer the selected settings and jobs to the device with *OK*. This process may take a few minutes.

(device dependant)



NOTE

If the device backup contains a calibrated lens distortion or shading correction, then the backup will only be completed when the device has been switched to set-up mode after recovery (*Device configuration*).

10.4 Digital I/O Assistant



With the Digital I/Os assistant, you can test whether all cables are connected correctly to the digital inputs and outputs. To use the illumination controller, the device must be in Configuration mode.

If the menu option is still greyed, your device may have the wrong firmware version.

ATTENTION!



If your Vision Sensor has already been permanently integrated into your system, it is advisable during initial testing to check the outputs with a meter. Keep in mind that switching of the outputs will be transmitted to any connected controllers!


NOTE



If encoders are defined for the inputs 4 and 5, you cannot test these using this assistant! You can change the settings under:

Device → Device settings → Digital I/Os.


Example using outputs



Set the appropriate output on or off using the Low/High button.

In the example, Output 1 and Output 3 are set. This means that power is now applied to Output 1 and Output 3.

Example using inputs



In the example, applied power is registered on Input 1 and Input 4.

10.5 Process interface assistant (device dependent)



You can use the process interface assistant to check what data is being sent and received via the device process interface. It appears in chronological order in the *Device communication* field.


This window is updated immediately when a datagram is transferred through the process interface, regardless of whether it was sent from your PLC or PC.

You can use the corresponding buttons to pause the window, resume a paused image and delete.



You can also use this dialogue page to send commands without connecting a physical PLC.

To do this, click the *Simulate PLC...* button.




On the right, you will now see buttons to select common commands, a field to amend the commands or enter your own, and a protocol field showing the data transfer for the simulation.

You can use the *Command...* button to select your chosen command from a list, and then add arguments before using the Send button to transfer it to the connected device.

You can also access data (images, jobs, backups) and select where they should be stored. To do this, activate the option *Store files under:*

10.6 Operating mode display



The current operating data of your Vision Sensor are displayed here:


- Device name
- Operating mode (*Configuration, Activated*)



NOTE

Clicking on the relevant displays allows you to change operating modes in the same way as the buttons.

11 Job menu



Actions are performed in this menu that affect jobs. Here you can create new jobs and load and save jobs from different sources. You can also test jobs.

NOTE




Use job management to copy jobs between your computer and the device. This is found under

Device menu → Device settings → Job management.

11.1 Create new job




This menu option is used for creating a new job.



Decide whether you want to save the current job.


Select a new name of the job and save it.



Click on Save.

You can now configure the job.

11.2 Load job from PC...



This menu option is used for loading jobs that have already been saved from the PC for processing.

Select the saved file and click on *Open*.




NOTE


Password protected files cannot be loaded if the password is not known!

You can now process the loaded job.

11.3 Load job from device...



This menu option is used to load a job that has already been saved on the device for processing in the *Application Suite*.



 This pin shows that the job is active at power on.


Select the job and click on *Load*.




NOTE

Password protected files cannot be loaded if the password is not known!

11.4 Save job to PC...



This menu option is used to save a job created with the *Application Suite* to the PC.



NOTE

The job name including the file extension ".app" can be a maximum of 31 characters.


Use *Browse* to select a directory where you would like to save the job.

Activate the option *Encrypt with password* if the file is to be saved in protected mode.




NOTE

The file cannot be reloaded afterwards without knowing the password!




Click on *Save* to create the file.

11.5 Save to the device...



This menu option is used to save a job created with the *Application Suite* to the device.



Enter a name for the job into the Job Name field and click on Save.



NOTE

The job name including the file extension ".app" can be a maximum of 31 characters.

Encrypt with password: Activate this option if the file is to be saved in protected mode.

Activate when switching the device on: Activate this option if you want to activate the saved job when you switch on the Vision Sensor.




This pin shows that the job is active at power on.

11.6 Test job...




Here, you can test your job using live images or images from one or more sample directories.



If you wish to use images from a folder for the test, you must select the appropriate folder with *Browse*.


Using *Add an additional directory...* you may add additional directories containing images to be tested. You may remove the added directories again by clicking on the X icon.



During the test you have the option of saving only certain images. This is related to the results of the sensor tasks. Choose between "NOK only, OK only and All".

Specify the directory where the pre-selected images will be saved by using *Browse*.


Give a name to the image series to be recorded.



You have the option of recording the output of the process interface. Select a directory using **Browse** to determine where the file will be saved.

Record results only: If you only want to save the actual result data, select this option.

Record all actual data traffic: check this option if you want to record all data traffic. Here all data that is actually transferred is recorded and the file will remain empty if no data is transferred!



You can limit the duration of the test. Select a value and choose between seconds and images. You can also activate or deactivate the outputs.




NOTE

If you do not limit the test sequence you may terminate the test at any time using the *Finish* button.



ATTENTION!

If your Vision Sensor is already integrated in your machine, it is often advisable to deactivate the outputs during the first tests to avoid incorrect behaviour of your machine.



The test is activated with the *Start test* button. In the list of features you will see the current results of the feature checks and the statistics window will give an overview of the results.

End test

No.	Name	Result	Number OK / NOK
1	 Position tracking on contours 1	● OK	4 / 0 (100,00 %)
2	 Area size 1	● OK	4 / 0 (100,00 %)

End test

Statistics
Current job:

Lebkuchenjob.app


Number of parts:	4	--
Number of OK:	4	100,00%
Number of NOK:	0	0,00%
Number of alarms:	0	0,00%

Click on *End test* when you want to end the test.

11.6.1 Test Protocol – Overview

When the test has been completed, the results are displayed in a test protocol, which you can save and print.

When you have completed the test with pictures from different directories, in the test protocol are indicated in different colours.




11.6.2 Test Protocol – Statistic

On the Statistics tab, you can even evaluate the job just tested using its individual feature checks according to various criteria. The results are displayed graphically using a histogram.

The currently displayed result can be exported as a *.csv or *.txt file.

Under *Feature*, select the feature of the tested job or the entire job (number of OK/NOK) to be evaluated. Under *Value*, you may evaluate the numerical results of the feature check (the angle of the object's rotation in the event of a part location).



Minimum: Set the minimum of the range of values here.

Number of classes: You can set the scaling between the Minimum and Maximum here.

Maximum: Set the maximum of the range of values here.

If you move the mouse pointer over the histogram, a tool tip appears containing the values of the current mouse pointer position.

The average and the standard deviation of the evaluation are displayed in the lower region.

11.7 Result and user display



The current job information for your Vision Sensor is displayed here. The information consists of:

- Job name
- OK, NOK or Alarm
- Current user (device dependant)

12 Feature checks

All feature checks are described below. Note that not all feature checks are supported by all devices.

You can find an overview as to which Vision Sensors check which features under: *Technical Data (Overview of feature checks)*.

NOTE



Once installation is complete, you will find a range of application examples that provide you with typical solutions for various inspection tasks and for the use of the individual feature checks. After successful installation, the examples can be found in the subdirectory:

<installation path>\AppSuite\Samples

NOTE



Jobs are compatible between devices if they work with at least the same feature checks and identical functions for the same field of view.

Feature checks from the *identification* area are not compatible between those devices with and without Industrial Ethernet. *Part location on contours* is supported as an *older version* on devices with integrated Industrial Ethernet.

NOTE



Most feature checks support the *Teach* function. Initially, the contours / edges of the sample piece will be learned or switching thresholds set absolutely or as a percent ($\pm 10\%$) to the actually determined value. A relative amendment will be retained if possible when the switching thresholds are altered manually.

The corresponding expected values will be imported during *Teach* in the case of identification feature checks.

NOTE



Older graphics cards, such as the on-board Intel HD 3000, do not fully support OpenGL in our experience. This can for instance result in 3D-view presentation problems with interactive colour assistants.

NOTE






Automatic configuration of the area limits occurs with higher resolution than the display in pixels would suggest. Rounding can result in the limit and specified value being exceeded by one pixel in limit cases.

This can be prevented by manual configuration or readjustment of the limit areas.


12.1 Part location

12.1.1 Part location on contours

With this feature check, the position of an object is determined using contours.



- Choose the shape of the area from which the contours are adopted.



Press *Teach* to search for new contours if you move the area.



- The match of the contours with the found object in the image is displayed here.
- Using the appropriate switching points, set how good the match must be so that the object is found. The button on the extreme right inverts the set point.




- **Contrast:** Set the minimum contrast of the contours that should be adopted in the model.
- **Form:** Select the shape of the contour that corresponds to the test object and that should be adopted in the model.
- **Mode:** Set the amount of detail to be used in the inspection. (The more detailed the mode, the higher the processing time.)
- **Max. rotation:** If you want to find the object only in a limited angular range, you may specify the maximum rotational position here. (Limiting the angular range reduces processing time.)

☐ Limit search area

- If you do not wish to search for the object in the entire image, set the tick and then limit the detection area.

Model editor tab



- You can use these two buttons to enlarge or reduce the model.



- You can gradually undo or redo the changes using these buttons.




- With the displayed model, you can use the mouse to delete contours which clearly do not belong to the reference object. Select the required tool strength to do this.

Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. The location of the detection area will be refreshed when this is activated. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.




- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Conformity	Integer	Match of the model (%)
Centre of object	Float point	Position of the object in the image (px)
Angle of object's rotation	Float	Angle of the object (degrees)


12.1.2 Part location on edges

This feature check localizes an object using edges. The detected position is used as a reference for the subsequent feature checks. In this way, tilted or displaced objects can also be examined. All fields of view and search beams for which part location is activated are corrected according to the current position of the test object.

This feature check does not support external teach. If a teach procedure is still executed, the parameters set will be maintained.




In this example, two edges of a test object are found, with a horizontal and a vertical search line, and the reference point for part location is determined at the intersection of the detected edges.



- If you wish to change the reference position of the part location, press the *Teach* button and the new position will be adopted.

Configuring of the part location as follows:




- **Determine alignment for:** Select the type of part location. You can determine either offset and rotation on two edges, offset and rotation on three edges, only horizontal or only vertical offset. A shorter processing time is required with fewer edges.
- Depending on whether you wish to align to one or two edges, you must then draw the search lines directly in the image using the mouse. Hold the left mouse button depressed during this.
- Position the search lines such that the sought contour is intersected as closely as possible to the middle. The first contour is detected which intersects the search line along the search axis. You can correct the positioning at any time.
- With long edges it is advisable to search the main reference edge with two search lines.

Conditions for Edge A		Conditions for Edge B	
Min. edge length:	 Short	Min. edge length:	 Short
Transition:	 Both directions	Transition:	 Both directions
Minimum contrast:	 Low contrast	Minimum contrast:	 Low contrast

Enter the criteria:

- **Min. edge length:** You must also specify whether a short, medium or long edge is to be sought. Using *User defined*, you may manually enter the length of an edge (5-1000 pixels).
- **Transition:** You must specify whether each edge can progress from bright to dark or from dark to bright (device dependant).
- **Minimum contrast:** Specify whether you are searching for an edge with sharp or weak contrast.




- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Centre of object	Float point	Position of the object in the image (px)
Angle of object's rotation	Float	Angle of the object (degrees)
Edge A (2)	Float	Coordinates (1) of the found edge A: Start point X – separator Start point Y – separator Rising of edge Δx – separator Rising of edge Δy – separator
Edge B	Float	Coordinates of the found edge B: Start point X – separator Start point Y – separator Rising of edge Δx – separator Rising of edge Δy – separator

The output values for the data frame of the process interface describes the edge (2) as a line defined by the starting point (1) and the increase (gradient triangle: Δx , Δy).







Illustration of the output values for a search arrow in part location tracking.

12.1.3 Part location on circle

With this feature check, you can align a round object with regard to its centre. It is also possible to correct the angle of rotation on the basis of an edge along the object.

In this example, the shape of the ring-pull on a drinks can is examined. The angle of rotation is determined and corrected by the soft sensor "Part location in a circle".

This feature check does not support external teach. If a teach procedure is still executed, the parameters set will be maintained.

Configuration for part location on a circle as follows:



- Select the shape of the field of view. A circular ring and a circular ring sector can be chosen.
- Draw the inner and outer reference circles with the mouse.
- The inspection of a circle is always conducted along the individual segments from circle A to circle B and in the direction indicated by the blue arrows.
- Adjust the edge length, transition type and contrast until the circle is reliably detected.

Determine alignment for:  Translation only 

- Select the type of part location. You can either search for a circle and thereby compensate displacement or also detect rotation of the object by an edge in close proximity.
- Draw the arc with the mouse to search for the associated edge.

Conditions for circle

Min. edge length:  Short 
Transition:  Both directions 
Minimum contrast:  Low contrast 
Direction:  Inside -> Outside 
Conditions for edge rotation

Min. edge length:  Short 
Transition:  Both directions 
Minimum contrast:  Low contrast 

Enter the criteria:

- **Min. edge length:** You must also specify whether a short, medium or long edge is to be sought. Using *User defined*, you may manually enter the length of an edge (5-1000 pixels).
- **Transition:** You must specify whether each edge can progress from bright to dark or from dark to bright or in both directions (device dependant).
- **Minimum contrast:** Specify whether you are searching for an edge with sharp or weak contrast.
- **Direction:** Select the direction of the search

Teach

- If you wish to change the reference position of the part location, press the *Teach* button and the new position will be adopted.

 OK

 Cancel

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Circle centre	Float point	X – Separator – Y
Circle diameter	Integer	
Edge for rotation	Integer	Coordinates of the found edge for rotation correction: Start point X – separator Start point Y – separator Rising of edge Δx – separator Rising of edge Δy – separator

12.1.4 Part location on text line

With this feature check, the position of the text within a field of view can be determined. To do this, the field of view must be positioned roughly parallel to the text with deviations of ± 15 degrees being tolerated. The background of the text should be homogeneous to achieve a stable analysis. The position found can then be used to align other feature checks, for example, the "Text" feature check.

This feature check supports external Teach. The position of the text line will be re-taught.

Form:

☐ Rectangle

Correlation  Min 

- The conformance of the current object with the taught-in model is displayed directly. You can set the associated switching point in the graphic display.
- The button on the extreme right inverts the set point.
- The switching point *Min* can also be edited manually.

Determine alignment for: Shift and rotation ▼

Select which alignment should be determined:

- Offset and rotation
- Offset only



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:



Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Conformity	Integer	Match between the current object and the taught-in model (%)
Text position	Float point	X – <i>Separator</i> – Y
Text angle	Float	

12.2 Geometry

12.2.1 Distance

This feature check determines the distance between two points, the right angular distance between two points and the distance of an edge in relation to a reference edge (a taught-in edge) and compares the distance found with the associated switching points.

This feature check supports external Teach. The switching points are adjusted as a percentage to the current measured value.


- Select the shape of the field of view. A search line and an arc can be chosen.
- Adjust the field of view by holding the left mouse button depressed.

In this example, two points on a test object are detected with one search line each. The distance between the intersections is indicated directly in the display:



- The current result is displayed directly in the dialogue as the distance. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Calculation method:  Point-to-point

Select the computation method.

- **Point-to-point:** Distance between two points
- **Rectangular distance:** Right angular distance between two points
- **To reference:** Distance to a reference edge
- **Edge to circle:** Distance from one edge to the centre of a circle
- **Circle to circle:** Distance between centres of two circles

Teach

- Click on Teach to retrain a new reference.

Conditions for Edge A

Min. edge length:  Short

Transition:  Both directions

Minimum contrast:  Low contrast

Conditions for Edge B

Min. edge length:  Short

Transition:  Both directions

Minimum contrast:  Low contrast

- **Min. edge length:** With short, medium or long, select the anticipated length of the sought contour to achieve a consistent result. Using *User defined*, you may manually enter the length of an edge (5-1000 pixels).
- **Transition:** You must specify whether each edge can progress from bright to dark or from dark to bright (device dependant).
- **Minimum contrast:** You can specify whether you are searching for an edge with sharp or weak contrast.

Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.




- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Distance	Float	

12.2.2 Circle

This feature check determines the position, the diameter and the roundness of a circle in comparison to a reference circle that is taught in. The detection area for a circle is defined by selecting a minimum inner circle and a maximum outer circle. Both the position and the diameter of the detected circle are compared with switching points.

This feature check supports external Teach. The switching points for the diameter are adjusted as a percentage to the current measured value. The thresholds for the distance remain unchanged as the newly programmed circle is adopted as a reference and the distance reverts to zero.


- Select the shape of the field of view. A circular ring and a circular ring sector can be chosen.
- Adjust the field of view by holding the left mouse button depressed.

In this example, the diameter, position and roundness of a hole are determined by measuring from the outer circle towards the inner circle. Both results appear directly on the display:

☒ Position:	2 Pixel		Min 0	Max 10	
☒ Diameter:	136 Pixel		Min 123	Max 215	
☐ Roundness:			Min 4	Max 9	

Fail Pass Fail



- **Position:** Determine the switching points of the position.
- **Diameter:** Determine the switching points for the diameter.
- **Roundness:** Determine the switching points of the roundness.

The right button is used to invert the result of the feature check.

Teach

- If you wish to change the reference position of the centre of the circle, simply press the *Teach* button and the new position will be adopted.

Conditions for edge

Min. edge length:	Short	▼
Transition:	Both directions	▼
Minimum contrast:	Low contrast	▼
Direction:	Inside -> Outside	▼

- **Min. edge length:** With short, medium long or user defined, select the anticipated length of the sought contour to achieve a consistent result. Using *User defined*, you may manually enter the length of an edge (5-1000 pixels).
- **Transition:** You must specify whether each edge can progress from bright to dark or from dark to bright (device dependant).
- **Minimum contrast:** You can also specify whether you are searching for an edge with sharp or weak contrast.
- **Direction:** Select the direction of the search.

Track position on:	- Do not use -	▼
External teach:	- Do not use -	▼

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Circle centre	Float point	
Circle diameter	Float	
Distance of the centre to the reference	Float	
Difference of the diameter to the reference	Float	
Roundness	Integer	

12.2.3 Angle


This feature check determines the angle between two edges or to a reference. The angle is compared with the associated switching points.

This feature check supports external Teach. The switching points are adjusted as an absolute to the current measured value.


- Select the shape of the field of view. A search line and an arc (radial search for edges) can be chosen.
- Adjust the field of view by holding the left mouse button depressed.

In this example, the angle between a vertical edge and a horizontal edge on a test object is determined by one horizontal and one vertical search line. The angle between the detected edges is indicated directly in the display:



- The current result is displayed directly in the dialogue as the angle. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Calculation method:  Angle between edges as  Smallest angle between edges A and B

Select the calculation method and orientation of the angle.

- **Calculation method:**
Angle between edges: Angle between two edges
Angle to reference: Angle to a reference edge
- **Orientation of the angle:**
Smallest angle between edge A and B
Angle between edge A and B, clockwise
Angle between edge A and B, anticlockwise

Teach

- You can teach in a new reference with this button.

Configure of the sensor as follows:

Conditions for Edge A	Conditions for Edge B
Min. edge length:  Short	Min. edge length:  Short
Transition:  Both directions	Transition:  Both directions
Minimum contrast:  Low contrast	Minimum contrast:  Low contrast

- **Min. edge length:** With short, medium or long, select the anticipated length of the sought contour to achieve a consistent result. Using *User defined*, you may manually enter the length of an edge (5-1000 pixels).
- **Transition:** You must specify whether each edge can progress from bright to dark or from dark to bright (device dependant).
- **Minimum contrast:** You can also specify whether you are searching for an edge with sharp or weak contrast.

Track position on:

External teach:

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.


This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Corner position	Float point	Coordinates of where the edges intersect
Angle of the corner	Float	Size of the angle between the edges (in degrees)
Position of corner	Float	Rotational position of edge 1 (in degrees, 0° == horizontal, 90° == vertical)
Distance	Float	Distance between the current corner position and the corner position of the reference angle
Angle difference	Float	Difference between the current angle and the reference angle (in degrees)
Deviation of position	Float	Difference between the current rotational position and that of the reference angle (in degrees)

12.2.4 Count edges

This feature check inspects the number of edges along a search beam.

This feature check supports external Teach. The switching points are adjusted as an absolute to the current measured value.



- Select the shape of the field of view. A search line and an arc can be chosen.
- Adjust the field of view by holding the left mouse button depressed.

In this example, the edges of a test object are detected at both the bright/dark and the dark/bright transitions. The number of detected edges is indicated directly in the display in *Number*.



- The current result is displayed directly in the dialog as the *Number*. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Configure of the sensor as follows:

- Position the search line by holding the left mouse button depressed in the image.

Conditions for edge

Min. edge length:  Short 

Transition:  Both directions 

Minimum contrast:  Low contrast 

- **Min. edge length:** With short, medium or long, select the anticipated length of the sought contour to achieve a consistent result. Using *User defined*, you may manually enter the length of an edge (5-1000 pixels).
- **Transition:** You must specify whether each edge can progress from bright to dark or from dark to bright (device dependant).
- **Minimum contrast:** You can also specify whether you are searching for an edge with sharp or weak contrast.

Track position on:
 - Do not use - 

External teach:
 - Do not use - 

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Number of edges	Integer	


12.2.5 Point position

This feature check determines the position and rotational position of a point, as an absolute in the picture or relative to a reference. It is therefore advisable that it is only used with part location. This feature check can, e.g. be used to determine the grasp position for robots (pick and place).

This feature check supports external Teach. The switching points are adjusted as an absolute to the current measured value.

- Set the point on the position to be determined. You may need to rotate it with the lever.



Select the features that should be checked.

- **Rotation:** Determine the switching points of the rotation.
- **Position X:** Determine the switching points of the X position.
- **Position Y:** Determine the switching points of the Y position.

The right button is used to invert the result of the feature check.

Calculation method: Absolute position in image ▾

- **Calculation method:** Absolute position in image (If you set this, you will get the coordinates of this point.) Relative to reference (show the deviations to the taught point.)



The reference point set using Teach is identified with a cross.

Track position on:
 - Do not use - ▾

External teach:
 - Do not use - ▾

- Here, select the part location with which the feature check should be corrected.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.




This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Rotation	Float	
Position X	Float	
Position Y	Float	


12.2.6 Edge characteristics

This feature check scans an edge with search beams and compares the distances detected with the defined conditions.


This feature check does not support external teach.



- Select the shape of the field of view. A rectangle, a circular ring and a circular ring sector can be chosen.



- The current number of distances calculated is displayed as *Number of distances* in the dialog by default.
- You can also select which located distances should be counted. You can select whether to count the number of distances within or outside of the tolerance range.
- The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The button on the right inverts the result of the *Number of distances* partial check.
- If you activate *Only count largest related group*, only the number of distances located within the largest group will be counted – i.e. the distances which fulfil the set criteria and appear directly next to one another.



- **Methods:** Here you can define the methods the search beams should use to search for edges. The search direction is indicated by a yellow arrow in the field of view. The methods available depend upon the shape of the field of view.



NOTE

For horizontal edge searches, you must rotate the field of view.

single: The system searches for an edge in a single direction from each search beam position. The reference point used to calculate the distance is the edge of the field of view (field of view alignment) or the located reference line (object alignment).

double: The system searches for an edge in two directions from each search beam position. The distance between the two located edges on the search beam is calculated.

downwards (single): The search for edges starts at the top edge of the field of view.

upwards (single): The search for edges starts at the bottom edge of the field of view.

inwards (single): The search for edges starts at the outer edge of the circle.

outwards (single): The search for edges starts at the inner edge of the circle.

to the centre line (double): The search for edges begins from both sides.

outwards (double): The search for edges begins from the centre line.

The following table provides an overview of which methods are available for which types of field of view.

	Rectangle		Circle / sector	
	single	double	single	double
downwards	x			
upwards	x			
inwards			x	
outwards			x	
to the centre line		x		x
outwards		x		x

Pixel: Pixels are used as the default preset value if you have not defined your own unit.

[Units]: If you have defined your own unit (*Adjust image* → *Coordinates*), you can select it here.

- **Distance:** Here, you can set the spacing between the search beams.
- **Alignment:** Define how the search beams are to be aligned.

to the field of view: The search beams are aligned according to the orientation of the field of view.

to the object: The system searches for a straight (rectangular field of view) or circular (circular or sector field of view) reference line. The search beams are aligned perpendicular to the reference line.

- **Tolerance field:** Here, you have the option to configure the size of the tolerance range. The tolerance range is the range between the set minimum and maximum values. The system will test whether each distance located falls within or outside of this range. It is shown as a transparent orange area in the field of view.

Conditions for edge search

Min. edge length:  Short ▼

Transition:  Both directions ▼


Minimum contrast:  Low contrast ▼

Specifications for the edge search

Define the specifications for the edge search.

- **Min. edge length:** You must also specify whether a short, medium or long edge is to be sought. Using *User defined*, you may manually enter the length of an edge (5-1000 pixels).

- **Transition:** For each edge, you must specify whether the edge progresses from bright to dark or from dark to bright.
- **Minimum contrast:** Specify whether you are searching for an edge with sharp or weak contrast.



Tab	Minimum distance:	Maximum distance:	Difference (Max. - Min. distance):	Greatest difference between neighbours:
Value	23.50	25.50	2.00	1.50
Min	13.75	15.75	1.80	-
Max	33.75	35.75	2.20	1.65


Statistics	
Mean distance:	23.95
Standard difference:	0.59

On the *Extended* tab, there are further options for influencing the result of the feature check.

- The switching points designated **Min** and **Max** are adjusted on the right hand side. To do this, the corresponding criterion must be activated. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The button on the right inverts the result of the respective partial check for this feature check.
- **Minimum distance:** Define the criteria for the smallest distance value located.
- **Maximum distance:** Define the criteria for the largest distance value located.
- **Difference (max. - min. distance):** Define the criteria for the difference between the smallest and largest distance values located.
- **Greatest difference between adjacent distances:** Determine the criteria for the greatest difference between directly adjacent distances.

Statistics

- **Mean distance:** Define the criteria for the average of all distance values located.
- **Standard difference:** Define the criteria for the standard difference for all distance values located.



On the *Details* tab, there is a table showing the results for the individual search beams and a bar chart. This tab is only used to display the values. You can zoom into the bar chart with the magnifying glass.

If you hover your cursor over one of the values in the table or a bar in the bar chart, the corresponding search line, point or distance will be highlighted in the field of view.

Track position on:

- Do not use -

External teach:

- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here.

OK Cancel

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Number of distances	Float	
Minimum distance	Float	
Maximum distance	Float	
Difference Max-Min	Float	
Greatest difference between adjacent distances	Float	
Mean distance	Float	
Standard difference	Float	
Distance list	Float list	
Edge point A list	Float-Point list	Intersection between search beam and located edge X – separator – Y, "NaN" if point is not found




Output value	Data type	Description
Edge point B list	Float-Point list	Intersection between search beam and located edge <i>X – separator – Y</i> , "NaN" if point is not found

12.3 Feature comparison


12.3.1 Count contour points

This feature check examines the number of contour points within the field of view.

This feature check supports external Teach. The switching points are adjusted as a percentage to the current measured value.




- Choose the shape of the field of view in this menu.



- The current result is displayed directly in the dialog as the *Number*. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Only count following directions:



- Determine the direction of the contour points that should be taken into consideration (device dependant).

Track position on:
 

External teach:
 

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.




This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Number of contour points	Integer	


12.3.2 Contour comparison

This feature check compares the contour of a taught-in object with the contour of the current object. In the comparison, adjacent pixels are counted and correspondence is determined on the basis of switching points. To use this feature check to its best effect, it is highly advisable to combine it with part location.

This feature check supports external Teach. Here all of the contours will be adopted in the model, but the switching points remain unchanged.




- The field of view must firstly be defined.



- The corresponding object is then taught in.

Tolerance: 3 px
☐ Observe edge direction

- **Tolerance:** Now adjust the size of the pixel field in which a pixel-by-pixel search is conducted for adjacent pixels. *Distance* specifies the detection area size in each direction up/down and right/left.
- **Observe edge direction:** Mark this option to increase accuracy during the examination.



- You can use these two buttons to enlarge or reduce the model.



- You can gradually undo or redo the changes using these buttons.




- With the displayed model, you can then use the mouse to delete contour points that clearly do not belong to the reference object or to supplement missing contour areas.

Correlation: 100 %  Min 90 

- The current result is displayed directly in the dialog as the *Match*. The switching point designated **Min** is adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

The differences between the inspected items are marked in red following comparison between correct and defective items.



Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.




This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Conformity	Integer	

12.3.3 Colour identification

This feature check identifies the colour in a field of view and checks whether the result is within a preset tolerance.


This feature check supports external Teach. The current colour is taught as the target colour.

- Select the shape of the field of view.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.



- Tick here if you want to calculate the colour deviation, otherwise it will produce the current colour of the field of view rather than the result (OK, NOK).
- The current result (in ΔE - distance between two colour coordinates in the CIELab colour coordinate system) is displayed under *Colour deviation*. The switching point designated **Max** (max. 50) is adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.




- **Methods: Average value:** The average value of all the pixels in the marked area is used.
- **Methods: Dominant single colour:** The dominant colour in the spectrum in the marked field of view is calculated and used. This means that any small errors such as dirt or reflections can be ignored.

Automatic brightness correction

In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.

Use, do not carry reference area: Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.

Use, carry reference area: This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.



- **Current colour:** The colour currently detected is displayed here. You can view the values for the colour currently detected in various colour spaces (RGB, Lab, LCh, HSV).



- **Target colour:** In this area, you can set the colour that should be searched for in each field of view. Use the arrow to accept the colour currently detected as the target colour.



NOTE



We recommend that you calculate the target colour with a correct model piece. Entered values may deviate from the model piece.

- **Max. deviation:** Here, you can set the maximum permissible colour deviation (in ΔE - distance between two colour coordinates in the CIE Lab colour coordinate system). This change is displayed to you in the CIE Lab colour coordinate system. The cover of the sphere represents the maximum deviation.

CIELab colour coordinates system

The cover of the sphere represents the maximum permissible colour deviation (ΔE) from the target colour and changes as you make entries. This means that all colour values of the current colour that lie within the ball are evaluated as *OK*.

The current colour is represented by a coordinate cross with dotted lines.

	
Current colour outside of the target colour - Result: NOK	Current colour inside of the target colour - Result: OK



NOTE

The scales of the CIELab colour coordinate system are divided into increments of 10 and show up to 50.

CIELab colour coordinate system scale

ΔL = brightness (difference from target colour)

Δa = red / green parts (difference from target colour)

Δb = blue / yellow parts (difference from target colour)

Control buttons

You can move the CIELab coordinate system freely with the mouse and zoom with mouse wheel. There are also buttons to stop the animation and tilt the CIELab colour coordinate system.

Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.




This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Reference area brightness	Integer	
Colour deviation (ΔE)	Integer	
Colour (Lab)	Triple integer	
Colour (RGB)	Triple integer	
Colour (HSV)	Triple integer	
Colour (LCh)	Triple integer	

12.3.4 Brightness

This sensor task measures the mean brightness in a field of view and compares the result with the specified switching points.

This feature check supports external Teach. The switching points are adjusted as an absolute to the current measured value.



- Select the shape of the field of view. A circle, a rectangle and a freely definable polygon, a circular ring and a circular ring sector are available.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.



- The current result for brightness is shown as an average grey scale value or as a percentage. The lightness value calculated during the teach process is 100%. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Track position on:

External teach:

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.

Reference area:

In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.

The mean brightness in the field of view of the reference area should exceed a grey scale value of 128 to ensure reliable operation.

- **Use, do not carry reference area:** Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.
- **Use, carry reference area:** This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Brightness	Integer	
Reference area brightness	Integer	

12.3.5 Contrast

The feature check measures the contrast in a field of view and compares the result with the specified switching points.

This feature check supports external Teach. The switching points are adjusted as an absolute to the current measured value.



- Select the shape of the field of view. A circle, a rectangle and a freely definable polygon, a circular ring and a circular ring sector are available.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.



- The current result of the contrast feature check is displayed directly in the dialogue as the *Contrast*. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Track position on:

- Do not use -

External teach:

- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Contrast	Integer	
Reference area brightness	Integer	


12.3.6 Area size

The feature check calculates the number of bright or dark pixels in a field of view and compares the result with specified switching points.


This feature check supports external Teach. The switching points are adjusted as a percentage to the current measured value.

Proceed as follows for configuration:



- Select the shape of the field of view. A circle, a rectangle and a freely definable polygon, a circular ring and a circular ring sector are available.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.



- The current result of the feature check is displayed directly in the dialogue as the **Area**. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Binary threshold: 82

Color: ☒ Bright on Dark

Method: ☒ Use all areas ☐ Exclude truncated areas

- **Binary switching point:** Set the switching point between 0 and 255, from which bright or dark pixels will be counted.
- **Colour:** This is where you enter the phenomenon that differentiates the pixels to be counted from their surroundings.
- **Methods:** Choose whether you want to count all areas or just the largest related areas.
- **Exclude cropped areas:** Areas which touch the edge of the field of view are excluded from the analysis. (only available for the *largest related areas*).

Track position on:

- Do not use -

External teach:

- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.

Reference area:

In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.

The mean brightness in the field of view of the reference area should exceed a grey scale value of 128 to ensure reliable operation.

- **Use current field of view:** The current defined field of view is used as a reference. It should only be used if the pattern being checked is very similar.
- **Use, do not carry reference area:** Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.
- **Use, carry reference area:** This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Area	Integer	
Centre	Integer	Output always in pixels
Reference area brightness	Integer	
Centre of gravity (float point)	Float point	Output switchable between pixels and coordinates (<i>Adjusting the image – coordinates</i>)

12.3.7 Area size (colour)

This feature check calculates the number of pixels of particular colours in a field of view and compares the result with specified switching points.


This feature check supports external Teach. The switching points are adjusted for the current calculated value.



Proceed as follows for configuration:




- Select the shape of the field of view. A circle, a rectangle and a freely definable polygon, a circular ring and a circular ring sector are available.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.



- Now select *Add* on the colour palette to teach in the first target colour.
- In the next step, mark the first target colour to be added on the image. This target colour can be located in any part of the image area and does not have to be in the field of view. However, only target colours in the defined field of view are assessed as *OK / NOK*. The marked target colours are displayed with a hatched pattern in the field of view.
- You can add up to 8 target colours to the colour palette. With *Add (auto)*, an area is automatically suggested for you to add as a new colour. Move the suggested area to the desired area and adjust its size if necessary.

3D>>: Here you can see where the defined colours are in a CIELab colour coordinate system. Unlike the CIELab colour coordinate system on the *Colour parameters* tab, the complete colour area is displayed and is not limited to 50 values per axis. The current target colour is marked with a grid.



- The current result of the feature check is displayed directly in the dialogue as the *Area*. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

General
Color parameters

Method: Use all areas

☐ Exclude cut areas

i All colors in the color palette are included for each area.

Automatic brightness balance:

Do not use

Adopt reference value

- **Methods:** Choose whether you want to count all areas or just the largest related areas.
- **Exclude cropped areas:** Areas which touch the edge of the field of view are excluded from the analysis. (only available for *only the largest related areas*).

Automatic brightness correction

In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.

Use, do not carry reference area: Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.

Use, carry reference area: This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.

General
Color parameters

Name: Green

Target color

Lab

L = 75


a = -31

b = 22

Current region:

Max. deviation

12







- **Target colour:** In this area, you can set the colour that should be searched for in each field of view. Use the arrow to accept the colour currently detected as the target colour.

NOTE



We recommend that you calculate the target colour with a correct model piece. Entered values may deviate from the model piece.

- **Max. deviation:** Set the maximum permissible colour deviation (in ΔE - distance between two colour coordinates in the CIELab colour coordinate system) (max. 50) here. This change is displayed to you in the CIELab colour coordinate system. The cover of the sphere represents the maximum deviation. Only the current target colour is displayed as a coloured sphere, the other target colours are displayed as abstract spheres.

CIELab colour coordinate system scale

NOTE



The scales of the CIELab colour coordinate system are divided into increments of 10 and show up to 50.

ΔL = brightness (difference from target colour)

Δa = red / green parts (difference from target colour)

Δb = blue / yellow parts (difference from target colour)


Control buttons

You can move the CIELab coordinate system freely with the mouse and zoom with mouse wheel. There are also buttons to stop the animation and tilt the CIELab colour coordinate system.

Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.





- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.


This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Area	Integer	
Centre	Float point	Output switchable between pixels and coordinates (<i>Adjusting the image – coordinates</i>)
Reference area brightness	Integer	
Structure	Integer	Number of contour points on hatched areas

12.3.8 Colour positioning


This feature check checks the dominant colour or the presence of individual colours in one or more fields of view. This can be used to classify colours, for example.





- Select *Add* on the colour palette to teach in the first target colour.
- In the next step, mark the first target colour to be added on the image. This target colour can be found anywhere across the entire image area. The marked target colour in the image is displayed with a hatched pattern. If the target colours touch each other (spheres on the Colour parameters tab), this is indicated with a warning triangle. A tool tip gives you information as to which other target colour it is touching.
- You can add up to 24 target colours to the colour palette. With *Add (auto)*, an area is automatically suggested for you to add as a new colour.
- Move the suggested area to the desired area and adjust its size if necessary.

3D>>: Here you can see where the defined colours are in a CIELab colour coordinate system. Unlike the CIELab colour coordinate system on the *Colour parameters* tab, the complete colour area is displayed and is not limited to 50 values per axis. The current target colour is marked with a grid. Only colour areas that do not overlap can be definitively detected.




- Select *Add* on the Fields of view tab and mark the first field of view in the image. You can define up to 32 fields of view.
- Now select the method according to which the field of view should be analysed. The entire feature check will only be assessed as OK if all of the individual fields of view are OK, i.e. meet the defined criteria.

Dominant colour: The selected colour must be the most frequently occurring colour in the field of view. This method is automatically selected if one colour in the colour palette is dominant in the field of view.

Contains a colour from („or“): The field of view must contain one of the selected colours, the minimum colour proportion (in %) that must be present can also be adjusted.

Contains all colours from („and“): The field of view must contain all of the selected colours.

- You can use the buttons on the right to edit the minimum areas of the colours for the respective field of view, or to delete the entire field of view.




Automatic brightness correction

In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.

Use, do not carry reference area: Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.

Use, carry reference area: This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.



- **Target colour:** In this area, you can set the colour that should be searched for in each field of view. Use the arrow to accept the colour currently detected as the target colour.

NOTE



We recommend that you calculate the target colour with a correct model piece. Entered values may deviate from the model piece.

- **Max. deviation:** Set the maximum permissible colour deviation (in ΔE - distance between two colour coordinates in the CIELab colour coordinate system) (max. 50) here. This change is displayed to you in the CIELab colour coordinate system. The cover of the sphere represents the maximum deviation. Only the current target colour is displayed as a coloured sphere, the other target colours are displayed as abstract spheres.

CIELab colour coordinate system scale

NOTE



The scales of the CIELab colour coordinate system are divided into increments of 10 and show up to 50.


ΔL = brightness (difference from target colour)

Δa = red / green parts (difference from target colour)

Δb = blue / yellow parts (difference from target colour)

Control buttons

You can move the CIELab coordinate system freely with the mouse and zoom with mouse wheel. There are also buttons to stop the animation and tilt the CIELab colour coordinate system.



- If the feature check is to be corrected by the result of the part location, you can choose this option here.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Reference area brightness	Integer	
Field of view, colour, area	Integer list	Three values are listed for each combination of a field of view and a colour (field of view, colour, area). Field of view: Number, starting with 1 (not as letters) Colour: Number, starting with 1 Area: Proportion (in percent) of the field of view occupied by the colour
Dominant colour	Integer list	Number of the dominant colour for each field of view, or 0 if no colour is found
Pass/Fail	Text	Results for the individual fields of view as "P" (Pass) or "F" (Fail)

12.3.9 Count areas

With this feature check, related areas in the field of view are counted.

This feature check supports external Teach. The switching points are adjusted as an absolute to the current measured value.

Form:

☐ Rectangle

- Select the shape of the field of view. A circle, a rectangle and a freely definable polygon, a circular ring and a circular ring sector are available.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.

Number of areas: 3

Fail Pass Fail


Min 0 Max 6

- The current result is displayed directly in the dialog as the *Number of areas*. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Binary threshold: 130 

Color:  Bright on Dark 

☐ Exclude truncated areas

Area filter:  Min 50  Max 14514 

- **Binary switching point:** Set the binary switching point at a value between 0 and 255.
- **Colour:** This is where you enter the phenomenon that differentiates the objects to be counted from their surroundings.
- **Exclude cropped areas:** Areas which touch the edge of the field of view are excluded from the analysis.
- **Areas filter:** Adjust the minimum and maximum number of pixels of the counted areas. You can invert the result using the right button.

Track position on:
 - Do not use - 

External teach:
 - Do not use - 

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.

Reference area: Use, carry area  

In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.

The mean brightness in the field of view of the reference area should exceed a grey scale value of 128 to ensure reliable operation.

- **Use, do not carry reference area:** Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.
- **Use, carry reference area:** This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Number of objects	Integer	
Reference area brightness	Integer	
List of centres	Float-Point list	
List of areas	Float-Point list	
List of structure values	Integer list	Number of contour points within the respective area (BLOB).
List of lightness values	Integer list	Average grey value within the respective area.

12.3.10 Count areas (colour)

This feature check is used to count related areas of a particular colour or colour selection in the field of view.

This feature check supports external Teach. The switching points are adjusted as an absolute to the current calculated value.

Number of areas  

Color palette

- 1 Purple
- 2 Blue
- 3 Green
-

General **Color parameters**


Area filter: ☒ Min 

☐ Max 

☐ Exclude cut areas


 All colors in the color palette are included for each area.

Automatic brightness balance:



Form:

- Select the shape of the field of view. A circle, a rectangle and a freely definable polygon, a circular ring and a circular ring sector are available.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.




- Now select *Add* on the colour palette to teach in the first target colour to be counted.
- In the next step, mark the first target colour to be added on the image. This target colour can be located in any part of the image area and does not have to be in the detection area. However, only target colours in the defined detection area are counted. The marked target colours are displayed with a hatched pattern in the detection area.
- You can add up to 8 target colours to the colour palette. With *Add (auto)*, an area is automatically suggested for you to add as a new colour. Move the suggested area to the desired area and adjust its size if necessary.

3D>>: Here you can see where the defined colours are in a CIELab colour coordinate system. Unlike the CIELab colour coordinate system on the *Colour parameters* tab, the complete colour area is displayed and is not limited to 50 values per axis. The current target colour is marked with a grid. Only colour areas that do not overlap can be definitively detected.



- The current result is displayed directly in the dialog as the *Number of areas*. The switching points designated **Min** and **Max** are adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.




- **Areas filter:** Set the minimum and maximum size of the areas that are to be counted. These settings refer to all areas and not to an individual colour. If you hover the cursor over this area, you will see the size of the detected area in the detection area in the image.
- **Exclude cropped areas:** Areas which touch the edge of the field of view are excluded from the analysis.

Automatic brightness correction

In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.

- **Use, do not carry reference area:** Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.
- **Use, carry reference area:** This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.





- **Target colour:** In this area, you can set the colour that should be searched for in each field of view. Use the arrow to accept the colour currently detected as the target colour.

NOTE



We recommend that you calculate the target colour with a correct model piece. Entered values may deviate from the model piece.

- **Max. deviation:** Set the maximum permissible colour deviation (in ΔE - distance between two colour coordinates in the CIELab colour coordinate system) (max. 50) here. This change is displayed to you in the CIELab colour coordinate system. The cover of the sphere represents the maximum deviation. Only the current target colour is displayed as a coloured sphere, the other target colours are displayed as abstract spheres.

CIELab colour coordinate system scale

NOTE



The scales of the CIELab colour coordinate system are divided into increments of 10 and show up to 50.

ΔL = brightness (difference from target colour)

Δa = red / green parts (difference from target colour)

Δb = blue / yellow parts (difference from target colour)

Control buttons

You can move the CIELab coordinate system freely with the mouse and zoom with mouse wheel. There are also buttons to stop the animation and tilt the CIELab colour coordinate system.

Track position on:

External teach:

- If the feature check is to be corrected by the result of a part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Number of objects	Integer	
Reference area brightness	Integer	
List of centres	Float-Point list	
List of areas	Float-Point list	
List of structure values	Integer list	Number of contour points within the respective area (BLOB).

12.3.11 Pattern comparison

This feature check verifies the presence of a taught-in pattern.


It supports external teach. The current image area is adopted in the model, but the switching points remain unchanged.



Proceed as follows for configuration:



- The field of view must firstly be defined.



- Teach in a new pattern using this button.

Difference  Min Max 

- The current result is displayed directly in the dialog as the *Deviation*. You can also select whether the value should be displayed in *pixels* or in *percent*.
- A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Allowed graylevel difference:

Resolution: 

- **Permissible grey scale variation:** Select the permissible grey scale variation. This corresponds with the absolute grey scale variation in the image.
- **Resolution:** You can choose the calculation accuracy and thereby the required processing time.

Automatic brightness balancing:











In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.

The mean brightness in the field of view of the reference area should exceed a grey scale value of 128 to ensure reliable operation.

- **Use current field of view:** The current defined field of view is used as a reference. It should only be used if the pattern being checked is very similar.
- **Use, do not carry reference area:** Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.
- **Use, carry reference area:** This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.

Track position on:



External teach:



- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Deviation	Integer	
Reference area brightness	Integer	

12.3.12 Pattern comparison (older version)


NOTE




The older version of the feature check is still available due to reasons of compatibility. It is strongly recommended that you use the newer, more powerful version. It is not possible to convert to the newer version.

This feature check verifies the presence of a taught-in pattern.


This feature check supports external Teach. The current image area is adopted in the model, but the switching points remain unchanged.



Proceed as follows for configuration:



- The field of view must firstly be defined.




- Teach in a new pattern using this button.



- The current result is displayed directly in the dialog as the *Match*. The switching point designated **Min** is adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.



- **Resolution:** You can choose the calculation accuracy and thereby the required processing time.
- **Automatic brightness correction:** You can choose an automatic brightness correction to increase the stability of the feature check under ambient conditions. Brightness correction corrects the brightest and darkest grey scale values in the image and thereby adjusts all other grey scale values to the corresponding level.



- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Conformity	Integer	


12.3.13 Pattern comparison (colour)

This feature check verifies the presence of a taught-in colour pattern.


It supports external teach. The current image area is adopted in the model, but the switching points remain unchanged.



Proceed as follows for configuration:



- Select the shape of the field of view. A circle, a rectangle and a freely definable polygon, a circular ring and a circular ring sector are available.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.



- Teach in a new pattern using *Teach*.




- The current result is displayed directly in the dialog as the *Deviation*. You can also select whether the value should be displayed in *pixels* or in *percent*.
- A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed.
- The right button is used to invert the result of the feature check.

Allowed color difference:

- **Permissible colour deviation:** Set the maximum permissible colour deviation (in ΔE - distance between two colour coordinates in the CIELab colour coordinate system).

Automatic brightness balancing:



In order to be independent of fluctuations in the ambient light, the device offers a means of automatically correcting the brightness.


The mean brightness in the field of view of the reference area should exceed a grey scale value of 128 to ensure reliable operation.

- **Use current field of view:** The current defined field of view is used as a reference. It should only be used if the pattern being checked is very similar. However, we recommend that you choose a separate field of view.
- **Use, do not carry reference area:** Here, a field of view is defined as a reference area, for example by attaching a white label to the edge of the conveyor belt (static). The brightness correction is now guided by the brightness of this area.
- **Use, carry reference area:** This function is only available in connection with part location. A field of view is still used as the reference area. However, this is carried with the position correction. The brightness correction is now guided by the brightness of this carried area.

Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.




- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.



This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Deviation	Integer	
Reference area brightness	Integer	

12.3.14 Finding object positions

This feature check finds multiple objects based on one programmed object. The found objects can then be filtered by several criteria, e.g. for pick and place applications.

This feature check does not support external teach.

Form:

☐ Rectangle

- Select the shape of the area in which you want to programme an object. A circle, a rectangle and a freely definable polygon, a circular ring and a circular ring sector are available.
- Adjust the field of view by holding the left mouse button depressed. You can rotate the rectangle by correspondingly dragging the lever in the centre with your mouse.

Teach

Press *Teach* to search for new contours if you move the area.



- A match of the objects found will be directly displayed as a *Match* in the dialogue.
- The switching point designated **Min** is adjusted on the right hand side. A graphic display is located in the middle, in which the positions of the switching points are displayed and where they can be changed. The upper bar shows the object with the highest match and the lower bar the object with the lowest match.

Common	Model editor	Reference Position	Secondary Checks	Output	Expanded
Contrast Low		Mode Detailed			
Form Slightly curved		Rotation Max ±180°			
☐ Limit search area		Maximum number of objects 5 			
☒ Consider secondary checks					

- **Contrast:** Set the minimum contrast of the contours that should be adopted in the model.
- **Form:** Select the shape of the contour that equates to the test object. (Limiting the angular range reduces processing time.)
- **Mode:** Set the amount of detail to be used in the inspection. (The more detailed the mode, the higher the processing time.)
- **Max. rotation:** If you want to find the object only in a limited angular range, you may specify the maximum rotational position here.
- **Maximum number of objects:** This is where you configure the maximum number of objects to be found. (Select the number to be as low as possible to reduce computation time.)


NOTE



- Objects are more stable if they have contours that:
- have no parallel lines spaced up to 4 pixels
 - are long (at least 20 pixels)
 - have a slight curvature

Restricting the detection area: If you do not wish to search for the object in the entire image, set the tick and then limit the detection area.

Using additional tests: Enable this function if you want to conduct additional tests in the immediate surroundings of each located object. These tests are then to be configured on the corresponding tab.



The *Model editor* tab can be used to edit the contours of the programmed object.




- You can use these two buttons to enlarge or reduce the model.



- You can gradually undo or redo the changes using these buttons.




- With the displayed model, you can use the mouse to delete contours which clearly do not belong to the reference object. Select the required tool strength to do this.



The reference position is by default the centre of the work area. The coordinates of this point can be output for each located object via the process interface.


This tab can be used to amend the reference position. It can be moved horizontally and vertically and rotated.



The *Additional tests* tab can be used to determine the criteria for subsequent testing of each located object. This enables detection of overlapping objects, for example, by stipulating criteria in their vicinity or on the surface of the object.

These additional tests can be used to discard initially located objects.


- Select *Add* and then select a feature.
- Now a shape (rectangle, circle) can be selected for the area to be marked.
- The next step is to mark the test area within the image.
- Criteria for this feature check can now be configured in the area on the right.




The *Output* tab can be used to define the content and structure of the *Formatted* list that can be output using the process interface. The *Formatted* list contains information about the located objects. The *Preview* area on the right displays the effect the settings have on the Formatted list in a live view.

Output format

This is where you determine the format of the output. Select *User defined* to see further options for governing the Formatted list.




Open the wizard for the mask. There are further configuration options available.




Sorting by lists

This offers you the opportunity to determine the sequence for outputting the coordinates of located objects.



The *Extended* tab can be used to govern the result of the feature check regarding the number of located objects.



- If the feature check is to be corrected by the result of a part location, you can choose this option here. The location of the detection area will be refreshed when this is activated.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Conformity	Integer	Model match (%) for the object with the lowest match
Number of objects	Integer	Number of located objects
Number of discarded objects	Integer	Number of objects discarded by additional tests
List of object centres	Float-Point list	
List of object rotation angles	Float list	
List of matches	Integer list	
Formatted list	Text	

12.4 Identification

NOTE

For devices with integrated Industrial Ethernet:




In the case of feature checks from the identification area, especially with code that is difficult to read, there can be slight deviations in the calculation of results between *Application Suite* and device. This is due to slight rounding differences caused by platforms that are technologically different. The results displayed after the device is activated are decisive.

12.4.1 Barcode

With this feature check barcodes can be read. In addition, the quality of the barcode can be determined according to ISO/IEC 15416.

This feature check supports external Teach. Here the parameters are adjusted for the identification and the expected value adopted.




Form:

☐ Rectangle

- Choose the detection area.

Read  Expected Text 

- **Read:** The read result is displayed here.
- **Arrow:** Using the arrow, you can accept the current result as the new expected value.
- **Expected:** In addition, you may specify an expected value.
- **Text/binary:** Change the display between *Text* (ASCII) and *Binary* (hexadecimal).

Common
Appearance
Code parameters

Code type 
☒ Detect on teach

Parameters 
☐ Optimize on teach

☐ Abort read attempt after around 

Quality 

☐ Minimum quality 

- **Code type:** Select the type of barcode in the image.
- **Detection on teach:** Using the *Detection on teach* option, you can have the code type automatically determined during external teach.
- **Parameters:** Select the search parameters used to search for the code. *Fast*, *Robust* and *User defined* are available. In the case of the user-defined search, you can manually set the parameters for the display and the code.
- **Optimize on teach:** Using the *Optimize on teach* option, you can have the parameters automatically adjusted for the code search during the external teach. This is only necessary if you have set the search parameters in the User-defined option.
- **Abort read attempt after circa:** Use this function to limit computing time for code determination.

NOTE



If computing time for code determination is limited and code quality is also to be determined, you need to be aware that limiting computing time only applies to code determination. If necessary, the extra time required for determining code quality should be established empirically and planned in addition – so deducted from the maximum permitted computing time, for example.

The limit on computing time may potentially vary between device and PC as they each have a different computing performance.


- **Quality:** If you also wish to check the code quality, you may activate the *Calculate based on ISO/IEC 15416* option. However, this also increases the processing time!
- **Minimum quality:** Activate this box if you want to specify a minimum quality.
- The code quality is specified as follows:
A - F (A = High quality ; F = Poor quality)

- The first parameter corresponds to the overall code quality.
- A total of 8 features are specified:
Legibility, symbol contrast, minimal reflectance, edge contrast, modulation, defects, decodability, additional code-specific parameters.
- You can find more details on the quality characteristics in appendix: *Quality characteristics for barcodes and matrix codes*




NOTE

In order to be able to make the settings "Appearance" and "Code parameters" on the tabs, you must set the Parameters on the "Common" tab to *User defined*.



- **Polarity:** Specify whether the code is brighter or darker than the background.
- **Minimum contrast:** Specify the minimum contrast of the barcode.
- **Optimise for dot matrix:** Activate this function if the barcode consists of a dot matrix.
- **Optimise for long, slim codes:** Activate this function if the height of the code is less than 15% of its width.



- **Bar width (pixel):** Specify the minimum width of one bar of the barcode.
- **Bar height (pixel):** Specify the height of one bar of the barcode.
- **Orientation (Degree):** To reduce processing time, you may restrict the barcode orientation. To do this, specify the maximum deviation with respect to the position of the field of view.
- **Check character:** Specify whether you want to use a check digit.

Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Read code	Text	Read result
Quality	Text	Overall quality
Quality (details)	Text	Individual quality characteristics
Output of position	Float point	Centre of the detected code

The following value can be set via the process interface. Please note that an expected value must be provided during parametrization of the feature check.



Input value	Data type	Description
to expected code	Text	expected code

12.4.2 Barcode (colour)

This feature check enables coloured barcodes with coloured backgrounds to be read. The field of view is first converted into a black and white image. In addition, the quality of the barcode can be determined according to ISO/IEC 15416.

The quality is determined once the image has been converted to black and white. You cannot, therefore, observe any influence the colour has on the quality.

This feature check supports external Teach. Here the parameters are adjusted for the identification and the expected value adopted.


Form:

☐ Rectangle

- Choose the detection area.

Read  Expected Text ▼

- **Read:** The read result is displayed here.
- **Arrow:** Using the arrow, you can accept the current result as the new expected value.
- **Expected:** In addition, you may specify an expected value.
- **Text/binary:** Change the display between *Text* (ASCII) and *Binary* (hexadecimal).



- **Code type:** Select the type of barcode in the image.
- **Detection on teach:** Using the *Detection on teach* option, you can have the code type automatically determined during external teach.
- **Parameters:** Select the search parameters used to search for the code. *Robust* and *User defined* are available. In the case of the user-defined search, you can manually set the parameters for the display and the code.
- **Optimize on teach:** Using the *Optimize on teach* option, you can have the parameters automatically adjusted for the code search during the external teach. This is only necessary if you have set the search parameters in the User-defined option.
- **Abort read attempt after circa:** Use this function to limit computing time for code determination.

NOTE



If computing time for code determination is limited and code quality is also to be determined, you need to be aware that limiting computing time only applies to code determination. If necessary, the extra time required for determining code quality should be established empirically and planned in addition – so deducted from the maximum permitted computing time, for example.

The limit on computing time may potentially vary between device and PC as they each have a different computing performance.

- **Quality:** If you also wish to check the code quality, you may activate the *Calculate based on ISO/IEC 15416* option. However, this also increases the processing time!
- **Minimum quality:** Activate this box if you want to specify a minimum quality.
- The code quality is specified as follows:
A - F (A = High quality ; F = Poor quality)
- The first parameter corresponds to the overall code quality.
- A total of 8 features are specified:
Legibility, symbol contrast, minimal reflectance, edge contrast, modulation, defects, decodability, additional code-specific parameters.
- You can find more details on the quality characteristics in appendix: Quality characteristics for barcodes and matrix codes


NOTE

In order to be able to make the settings "Appearance" and "Code parameters" on the tabs, you must set the Parameters on the "Common" tab to *User defined*.



Common Appearance Code parameters


Color conversion Two color optimization

Polarity Arbitrary

Minimum contrast

☒ Noise suppression (slower)

- **Colour conversion:** Enter the method you wish to use to convert the field of view into a black and white image here. Select *Gray value*, if the black and white version of the field of view contrasts well. Select *Two colour optimization* if the barcode and background appear in similarly light colours.
- **Polarity:** Specify whether the code is brighter or darker than the background. The *Arbitrary* option doubles the processing time.
- **Minimum contrast:** Specify the minimum contrast of the barcode.
- **Noise suppression:** Activate this function if you want to minimize noise.



Common Appearance Code parameters

Bar width (Pixel) Min 1.5 Max 8.0

Bar height (Pixel) Min Arbitrary

Orientation (Degree) Arbitrary

Check character Do not use

- **Bar width (pixel):** Specify the minimum width of one bar of the barcode.
- **Bar height (pixel):** Specify the height of one bar of the barcode.
- **Orientation (Degree):** To reduce processing time, you may restrict the barcode orientation. To do this, specify the maximum deviation with respect to the position of the field of view.
- **Check character:** Specify whether you want to use a check digit.

Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Read code	Text	Read result
Quality	Text	Overall quality
Quality (details)	Text	Individual quality characteristics
Output of position	Float point	Centre of the detected code


The following value can be set via the process interface. Please note that an expected value must be provided during parametrization of the feature check.


Input value	Data type	Description
to expected code	Text	expected code

12.4.3 Matrix code


Matrix codes (ECC 200, QR, PDF417) can be read using this feature check. In addition, the quality of the barcode can be determined according to ISO/IEC 15415 or ISO/IEC TR 29158 (AIM DPM-1-2006).

This feature check supports external Teach. In this process, the parameters for identification are adjusted and the expected value is accepted if an expected value has already been set.





- Choose the detection area.



- **Read:** The read result is displayed here.
- **Arrow:** Using the arrow, you can accept the current result as the new expected value.
- **Expected:** In addition, you may specify an expected value.
- **Text/binary:** Change the display between *Text* (ASCII) and *Binary* (hexadecimal).

Common
Appearance
Code parameters

Code type
QR-Code
☒ Detect on teach

Parameters
Fast
☐ Optimize on teach

☐ Abort read attempt after around
50 ms

Quality
Don't calculate
Not calculated

☐ Minimum quality
D

- **Code type:** Select the type of matrix code in the image.
- **Detection on teach:** Using the *Detection on teach* option, you can have the code type automatically determined during external teach.
- **Parameters:** Select the search parameters used to search for the code. *Fast*, *Robust*, *Maximum* and *User defined* are available. In the *Robust* or *Maximum* modes, codes are found even with more demanding backgrounds. However, this places a burden on the processing time. In the case of the user-defined search, you can manually set the parameters for the display and the code.
- **Optimize on teach:** Using the *Optimize on teach* option, you can have the parameters automatically adjusted for the code search during the external teach. This is only necessary if you have set the search parameters in the User-defined option.
- **Abort read attempt after circa:** Use this function to limit computing time for code determination.

NOTE



If computing time for code determination is limited and code quality is also to be determined, you need to be aware that limiting computing time only applies to code determination. If necessary, the extra time required for determining code quality should be established empirically and planned in addition – so deducted from the maximum permitted computing time, for example.

The limit on computing time may potentially vary between device and PC as they each have a different computing performance.

- **Quality:** If you also wish to check the code quality, you may activate the *Calculate based on ISO/IEC 15415* or *Calculate based on ISO/IEC TR 29158 (AIM DPM-1-2006)* option. However, this also increases the processing time!
- **Minimum quality:** Activate this box if you want to specify a minimum quality.

The code quality is specified as follows:

A - F (A = High quality ; F = Poor quality)

The first parameter corresponds to the overall code quality.

In the *ISO/IEC 15415* mode, various characteristics are determined:

- ECC200 / QR-Code:
Contrast, modulation, pattern damage, decodability, axial non-uniformity (evaluation of width and height), grid non-uniformity (evaluation of slope angle), unused error correction

- PDF417:

Reflection properties of the start/stop pattern, decoded codeword yield, unused error correction, modulation, decodability, defects

In the *ISO/IEC TR 29158 (AIM DPM-1-2006)* mode, a total of 8 characteristics are determined (for *ECC200 / QR* code only):

Cell contrast, cell modulation, fixed pattern damage, decodability, axial non-uniformity (evaluation of the width and height), grid non-uniformity (evaluation of the slope angle), unused error correction, mean grey value of the light modules (0,70..0,86 → A; 0,86..1,0 and 0,55..0,7 → B; 0,4..0,55 → C; 0,25 .. 0,4 → D; below 0,25 → F).

NOTE




The determination of continuous valuation values is not supported.


NOTE




In order to be able to make the settings "Appearance" and "Code parameters" on the tabs, you must set the Parameters on the "Common" tab to *User defined*.



- **Polarity:** Specify whether the code is brighter or darker than the background.
- **Mirroring:** Specify whether the code is mirrored.
- **Minimum contrast:** Specify the minimum contrast of the matrix code.
- **Recognition:** If the outer contour of the code exhibits disturbances, you should activate "Tolerant" recognition. Otherwise, "Normal" recognition is sufficient.



- **Code shape:** Specify the shape of the code to be found. For code type Data Matrix: (rectangular, square, arbitrary). For code type QR code: (Model 1, Model 2, arbitrary).
- **Columns:** Specify the number of columns of the module.
- **Rows:** Specify the number of lines of the module.
- **Module size (Pixel):** Specify the size of a module.
- **Gap between the modules:** Specify whether gaps may occur between the modules.



- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.



- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Read code	Text	Read result
Quality	Text	Overall quality
Quality (details)	Text	Individual quality characteristics
Output of position	Float point	Centre of the detected code


The following value can be set via the process interface. Please note that an expected value must be provided during parametrization of the feature check.


Input value	Data type	Description
to expected code	Text	expected code

12.4.4 Matrix code (colour)


Coloured matrix codes (ECC 200, QR, PDF417) with coloured backgrounds can be read using this feature check. The field of view is first converted into a black and white image. In addition, the quality of the barcode can be determined according to ISO/IEC 15415 or ISO/IEC TR 29158 (AIM DPM-1-2006).

This feature check supports external Teach. In this process, the parameters for identification are adjusted and the expected value is accepted if an expected value has already been set.






- Choose the detection area.



- **Read:** The read result is displayed here.
- **Arrow:** Using the arrow, you can accept the current result as the new expected value.
- **Expected:** In addition, you may specify an expected value.
- **Text/binary:** Change the display between *Text* (ASCII) and *Binary* (hexadecimal).



The screenshot shows the 'Code parameters' configuration window. It includes tabs for 'Common', 'Appearance', and 'Code parameters'. Under 'Code parameters', the 'Code type' is a dropdown menu set to 'QR-Code'. The 'Parameters' dropdown is set to 'Robust'. There are checkboxes for 'Detect on teach' (checked) and 'Optimize on teach' (unchecked). A checkbox for 'Abort read attempt after around' is unchecked, with a value of '50 ms' entered in the adjacent field. The 'Quality' dropdown is set to 'Don't calculate', with 'Not calculated' shown in the adjacent field. A 'Minimum quality' checkbox is unchecked, with a dropdown set to 'D'.

- **Code type:** Select the type of matrix code in the image.
- **Detection on teach:** Using the *Detection on teach* option, you can have the code type automatically determined during external teach.
- **Parameters:** Select the search parameters used to search for the code. *Robust*, *Maximum* and *User defined* are available. In the *Robust* or *Maximum* modes, codes are found even with more demanding backgrounds. However, this places a burden on the processing time. In the case of the user-defined search, you can manually set the parameters for the display and the code.
- **Optimize on teach:** Using the *Optimize on teach* option, you can have the parameters automatically adjusted for the code search during the external teach. This is only necessary if you have set the search parameters in the User-defined option.
- **Abort read attempt after circa:** Use this function to limit computing time for code determination.

NOTE



If computing time for code determination is limited and code quality is also to be determined, you need to be aware that limiting computing time only applies to code determination. If necessary, the extra time required for determining code quality should be established empirically and planned in addition – so deducted from the maximum permitted computing time, for example.

The limit on computing time may potentially vary between device and PC as they each have a different computing performance.

- **Quality:** If you also wish to check the code quality, you may activate the *Calculate based on ISO/IEC 15415* or *Calculate based on ISO/IEC TR 29158 (AIM DPM-1-2006)* option. However, this also increases the processing time!
- **Minimum quality:** Activate this box if you want to specify a minimum quality.

The code quality is specified as follows:

A - F (A = High quality ; F = Poor quality)

The first parameter corresponds to the overall code quality.

In the *ISO/IEC 15415* mode, various characteristics are determined:

- ECC200 / QR-Code:
 - Contrast, modulation, pattern damage, decodability, axial non-uniformity (evaluation of width and height), grid non-uniformity (evaluation of slope angle), unused error correction

- PDF417:

Reflection properties of the start/stop pattern, decoded codeword yield, unused error correction, modulation, decodability, defects

In the *ISO/IEC TR 29158 (AIM DPM-1-2006)* mode, a total of 8 characteristics are determined (for *ECC200 / QR* code only):

Cell contrast, cell modulation, fixed pattern damage, decodability, axial non-uniformity (evaluation of the width and height), grid non-uniformity (evaluation of the slope angle), unused error correction, mean grey value of the light modules. (0,70..0,86 → A; 0,86..1,0 and 0,55..0,7 → B; 0,4..0,55 → C; 0,25..0,4 → D; under 0,25 → F).

NOTE



The determination of continuous valuation values is not supported.

NOTE



In order to be able to make the settings "Appearance" and "Code parameters" on the tabs, you must set the Parameters on the "Common" tab to *User defined*.



- **Colour conversion:** Enter the method you wish to use to convert the field of view into a black and white image here. Select *Gray value*, if the black and white version of the field of view contrasts well. Select *Two colour optimization* if the barcode and background appear in similarly light colours.
- **Polarity:** Specify whether the code is brighter or darker than the background.
- **Mirroring:** Specify whether the code is mirrored.
- **Minimum contrast:** Specify the minimum contrast of the matrix code.

Common
Appearance
Code parameters

Code shape: Square

Columns: Min 12 Max 12

Rows: Min 12 Max 12

Module size (Pixel): Min 7 Max 7

Gap between modules: Min None Max None

- **Code shape:** Specify the shape of the code to be found. For code type Data Matrix: (rectangular, square, arbitrary). For code type QR code: (Model 1, Model 2, arbitrary).
- **Columns:** Specify the number of columns of the module.
- **Rows:** Specify the number of lines of the module.
- **Module size (Pixel):** Specify the size of a module.
- **Gap between the modules:** Specify whether gaps may occur between the modules.

Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the feature check. Select the appropriate option for this purpose.

OK
Cancel

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Read code	Text	Read result
Quality	Text	Overall quality
Quality (details)	Text	Individual quality characteristics
Output of position	Float point	Centre of the detected code


The following value can be set via the process interface. Please note that an expected value must be provided during parametrization of the feature check.


Input value	Data type	Description
to expected code	Text	expected code

12.4.5 Text


You can read date specifications, numbers and words using this feature check. In addition, it is possible to compare the result to an expected value. You can also check the print quality of text.

This feature check supports external Teach. Here, the value actually read is adopted as a new expectation value.





- Select the area containing the text.
- Always mark only one line. If the text covers multiple lines, you must use several feature checks. Make sure that the text is marked as precisely as possible.
- If the text fluctuates in its location in the image, you can use the "Alignment to text line" feature check for part location.



- **Read unknown text:** Select this option if you want to read unknown text.
- **Test print quality of unknown text:** Select this option if you want to check the print quality of unknown text.
- **Test print quality of known text:** With this function, you can compare the print quality to a taught value.

Read unknown text

If you have selected Read unknown text, the read text is displayed. You can also enter the text expected into the Expected field. You can configure settings on the Common, Characters and Filter tabs. Using the arrow, you can accept the current result as the new expected value.

Check the print quality of unknown text

If you have selected *Check the print quality of unknown text*, you can compare the print quality of unknown text to previously taught reference characters. To use this function, you have to teach in the reference characters on the *Print quality* tab. You can also make settings on the Common, Characters and Filter tabs.

Check the print quality of known text


If you have selected Check the print quality of known text, you can compare the read text to previously taught characters and set it as a reference using external teach.



NOTE

Using teach, only the text contents are read and not the text format (e.g., date)!
 All characters to be read must be taught in advance using the Print quality tab!

You can teach in the reference characters on the Print quality tab. You can also make settings on the Common, Characters and Filter tabs.



- **Text type:** Set the type of the text. You may select *Date*, *Numbers*, *Hexadecimal characters*, *Letters*, *Mask* and *Time*. You can describe the text type exactly on the right side, which is then displayed in accordance with the selected type.



NOTE

For the Mask text type, you can enter “?” to recognize any capital letter or number.

Please note that there may be ambiguities (examples: 0/Q/O, 1/l, 5/S, 8/B). If necessary, change the character thickness or the threshold value to achieve better results.

Mask

- 1 – arbitrary number
- H – arbitrary hexadecimal character
- A - arbitrary uppercase letter

a - arbitrary lowercase letter (not with Dot-Print)
 \$ - arbitrary additional character
 x - ignore
 . : - / + () allowed additional character

- **Font:** Select the *Standard* font if you want to recognize Sans-serif writing (e.g., Arial, Verdana, Univers and OCR-B). Select the *Dot-Print* font if you want to recognize dot-matrix fonts.



NOTE

With the Dot-Print font, lower case letters cannot be read.

- **Mode:** The selected mode determines the processing time required to process the feature check. The *Robust* mode requires the longest processing time but makes more stable read results possible if the print format is not optimal.
- **Threshold:** Set the threshold for the separation of background and characters. For optimal recognition, the background should have as little structure as possible!




Common Character Filter Print quality

Polarity **A** Dark on bright

Mirroring **R** None

Font height ☒ automatically
☐ manually 6px x 10px

- **Polarity:** Specify whether the text is brighter or darker than the background.
- **Mirroring:** Specify whether the text is mirrored.
- **Font height:** Choose whether the character size is automatically recognized or whether it should be entered manually. With manual entry, you may enter this value or draw a frame in the image around one individual character.




Common Character Filter Print quality

☒ Find text line



Remove small characters None  Maximum

Adjust font weight **A**  **A**

- **Find text line:** Activate the *Find text line* option if structures are present below or above the text and these structures are to be automatically masked.
- **Remove small characters:** In addition, you can set a minimum size for the characters to remove very small characters.
- **Adjust font weight:** It is also possible to reduce or increase the line thickness of the characters found.



- **Learn reference character:** Click on the **+** to teach in reference characters. The window below opens where you can assign values to the characters read.



Delete the individually marked reference character



Delete all reference characters



Show/hide characters that have not been taught in

Track position on:

External teach:

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the sensor. Select the appropriate option for this purpose.

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Read text	Text	Read result


The following values can be set via the process interface. Please note that an expected value must be provided during parametrization of the feature check.


Input value	Data type	Description
Mask	Text	Masking of the expected text
Expected	Text	expected text

12.4.6 Text (colour)


You can read coloured dates, numbers and words on coloured backgrounds using this feature check. The field of view is first converted into a black and white image. It also gives you the option to compare the result to an expected value. You can also check the print quality of text.

This feature check supports external Teach. Here, the value actually read is adopted as a new expectation value.





- Select the area containing the text.
- Always mark only one line. If the text covers multiple lines, you must use several feature checks. Make sure that the text is marked as precisely as possible.
- If the text fluctuates in its location in the image, you can use the "Alignment to text line" feature check for part location.



- **Read unknown text:** Select this option if you want to read unknown text.
- **Test print quality of unknown text:** Select this option if you want to check the print quality of unknown text.
- **Test print quality of known text:** With this function, you can compare the print quality to a taught value.

Read unknown text

If you have selected Read unknown text, the read text is displayed. You can also enter the text expected into the Expected field. You can configure settings on the Common, Characters and Filter tabs. Using the arrow, you can accept the current result as the new expected value.

Check the print quality of unknown text

If you have selected *Check the print quality of unknown text*, you can compare the print quality of unknown text to previously taught reference characters. To use this function, you have to teach in the reference characters on the *Print quality* tab. You can also make settings on the Common, Characters and Filter tabs.

Check the print quality of known text


If you have selected Check the print quality of known text, you can compare the read text to previously taught characters and set it as a reference using external teach.



NOTE

Using teach, only the text contents are read and not the text format (e.g., date)!
 All characters to be read must be taught in advance using the Print quality tab!

You can teach in the reference characters on the Print quality tab. You can also make settings on the Common, Characters and Filter tabs.



The screenshot shows the 'Common' tab selected. Below it are four sub-tabs: 'Common', 'Character', 'Filter', and 'Print quality'. The 'Common' sub-tab is active. It contains the following settings:

- Text type:** A dropdown menu set to 'Date', with a preview box showing 'DD.MM.YYYY'.
- Font:** A dropdown menu set to 'A Default'.
- Mode:** A dropdown menu set to 'Fast'.
- Threshold:** A horizontal slider bar with a red vertical marker positioned towards the right end.

Text type: Set the type of the text. You may select *Date*, *Numbers*, *Hexadecimal characters*, *Letters*, *Mask* and *Time*. You can describe the text type exactly on the right side, which is then displayed in accordance with the selected type.



NOTE

For the Mask text type, you can enter “?” to recognize any capital letter or number.

Please note that there may be ambiguities (examples: 0/Q/O, 1/I, 5/S, 8/B). If necessary, change the character thickness or the threshold value to achieve better results.

Mask

- 1 – arbitrary number
- H – arbitrary hexadecimal character
- A - arbitrary uppercase letter
- a - arbitrary lowercase letter (not with Dot-Print)

\$ - arbitrary additional character
 x - ignore
 . : - / + () allowed additional character

- **Font:** Select the *Standard* font if you want to recognize Sans-serif writing (e.g., Arial, Verdana, Univers and OCR-B). Select the *Dot-Print* font if you want to recognize dot-matrix fonts.



NOTE

With the Dot-Print font, lower case letters cannot be read.

- **Mode:** The selected mode determines the processing time required to process the feature check. The *Robust* mode requires the longest processing time but makes more stable read results possible if the print format is not optimal.
- **Threshold:** Set the threshold for the separation of background and characters. For optimal recognition, the background should have as little structure as possible!



Common Character Filter Print quality

Polarity **A** Dark on bright


Mirroring **R** None

Font height ☒ automatically
☐ manually 33px x 53px

Color conversion Two color optimization

Relearn text color

- **Polarity:** Specify whether the text is brighter or darker than the background.
- **Mirroring:** Specify whether the text is mirrored.
- **Font height:** Choose whether the character size is automatically recognized or whether it should be entered manually. With manual entry, you may enter this value or draw a frame in the image around one individual character.
- **Colour conversion:** Enter the method you wish to use to convert the field of view into a black and white image here. Select *Gray value*, if the black and white version of the field of view contrasts well. Select *Two colour optimization* if the barcode and background appear in similarly light colours.
- **Re-learn text colour:** Use this function to optimize the way the field of view is converted into a black and white image. This is useful if the colours in the field of view have changed.




Common Character Filter Print quality

☒ Find text line



Remove small characters None Maximum

Adjust font weight A A

- **Find text line:** Activate the *Find text line* option if structures are present below or above the text and these structures are to be automatically masked.
- **Remove small characters:** In addition, you can set a minimum size for the characters to remove very small characters.
- **Adjust font weight:** It is also possible to reduce or increase the line thickness of the characters found.



- **Learn reference character:** Click on the + to teach in reference characters. The window below opens where you can assign values to the characters read.



Delete the individually marked reference character



Delete all reference characters



Show/hide characters that have not been taught in

Track position on:
- Do not use -

External teach:
- Do not use -

- If the feature check is to be corrected by the result of the part location, you can choose this option here. External teach also makes it possible to retrain the sensor. Select the appropriate option for this purpose.

- Confirm your settings and return to the feature list with *OK*. Return to the feature list without making any changes with *Cancel*.

This feature check has the following output values for the datagram at the process interface:

Output value	Data type	Description
Result		Result of the feature check: "P" (Pass); "F" (Fail)
Read text	Text	Read result

The following values can be set via the process interface. Please note that an expected value must be provided during parametrization of the feature check.

Input value	Data type	Description
Mask	Text	Masking of the expected text
Expected	Text	expected text

12.4.7 Appendix: Quality characteristics for barcodes and matrix codes

Numerous quality characteristics are defined for the various code types, these characteristics are described in more detail in the following. Keep in mind that illumination arrangements and quality requirements are defined on the image for these standards so that the values determined cannot be directly mapped to your installation situation!


Barcode quality characteristics (ISO/IEC 15416)

Designation	Description
Legibility	A = Code legible F = Code not read
Symbol contrast	Difference between the maximum and minimum grey scale value of the symbols
Minimum reflection	A = Minimum grey scale value $\leq 0.5 \cdot$ maximum grey scale value F = Other
Edge contrast	Minimum contrast between two symbol elements
Modulation	Amplitude between symbol elements
Defects	Irregularities in the grey scale profile of a symbol
Decodability	Deviations in the width of symbol elements
Additional code-specific parameters	Depending on code type, for example, evaluation of the width of the quiet zones or ratio of symbol widths.

Determining the quality of barcode

The barcode is scanned internally by multiple detection beams (1) and assessed by the above-named quality features. An average of the respectively matching quality features over all detection beams is determined and output (2).

The respectively poorest assessments (3) for a quality feature are also determined per detection beam, their average is formed and then output as overall quality (4).



NOTE



The overall quality of a barcode can in certain circumstances be poorer than all of the individual quality features. This is because in each case it is the poorest individual values (3) that flow into the overall assessment. The overall assessment is not formed from evaluations of the quality features (2).

If various individual values are conspicuously poor in different detection beams, this can result in poor overall quality without the individual quality features being assessed as worse.

Quality characteristics DataMatrix (ECC200) and QR code ISO/IEC 15415 + ISO/IEC TR 29158 (AIM DPM-1-2006)

Designation	Example	Description
Contrast		Difference between the maximum and minimum grey scale value of the modules
Modulation		Amplitude between data code modules (dependant on error correction!)
Pattern damage		Disturbances in the frame pattern (finder pattern)
Legibility		A = Code legible F = Code not read
Axial non-uniformity		Evaluation of the width and height of the modules
Grid non-uniformity		Evaluation of the incline angle (perspective distortion)
Unused error correction		Proportion of the unused error redundancy

Designation	Example	Description														
Gray scale value of the light modules		Average grey scale value of all light modules of the DataMatrix or QR code <table><tr><th>Gray scale value</th><th>Evaluation</th></tr><tr><td>0.7.. 0.86</td><td>A</td></tr><tr><td>0.86.. 1.0</td><td>B</td></tr><tr><td>0.55.. 0.7</td><td>B</td></tr><tr><td>0.4.. 0.55</td><td>C</td></tr><tr><td>0.25.. 0.4</td><td>D</td></tr><tr><td>0.. 0.25</td><td>F</td></tr></table>	Gray scale value	Evaluation	0.7.. 0.86	A	0.86.. 1.0	B	0.55.. 0.7	B	0.4.. 0.55	C	0.25.. 0.4	D	0.. 0.25	F
Gray scale value	Evaluation															
0.7.. 0.86	A															
0.86.. 1.0	B															
0.55.. 0.7	B															
0.4.. 0.55	C															
0.25.. 0.4	D															
0.. 0.25	F															

Quality characteristics PDF 417 (ISO/IEC 15415)

Designation	Description
Reflection properties Start / Stop pattern	Analysis of reflection properties and bar width of the start/stop pattern
Proportion of decoded code words	Relative proportion of decoded code words
Unused error correction	Proportion of the unused error redundancy
Modulation	Amplitude between symbol modules
Decodability	Deviations in the width of symbol elements
Defects	Irregularities in the scanning profile within the module


13 Digital interfaces

13.1 Explanation of terms from the timing diagram

Alarm	Indicates that an irregularity has occurred that should be investigated more closely by an expert.
Trigger	Input signal that triggers image acquisition
Flash Sync exposure time	Output signal for triggering external illumination
Camera ready	Shows that the result is at one of the outputs (pass/fail) and can, for example, be read by an PLC (not for varied output times). With the device, a new image can be recorded before the current analysis is completed. There is internal storage for two images for this reason.
Result invalid	Indicates that the result can be read at the outputs (pass/fail).
Pass	Feature check passed
Fail	Feature check failed
T	Time
Device activated	Shows that the device is activated and ready to run inspection task ("Run Mode").

13.2 Timing when an external trigger is used

The sequence of the individual signals and their designation are indicated in the diagram below:



Signal		Full resolution		Reduced resolution (device dependant)	
		min.	max.	min.	max.
Trigger-exposure time delay T_1		20 μ s plus preset trigger delay			
Exposure time T_2	Internal illumination ¹	35 μ s	10 ms	35 μ s	5 ms
	External illumination	35 μ s ¹ / 10 μ s ²	65.5 ms	35 μ s ¹ / 10 μ s ²	65.5 ms
	Flash controller ²	10 μ s	1 ms / 65.5 ms	10 μ s	1 ms
Image acquisition T_3		16 ms	20 ms	8 ms	11 ms
Output time (min / max) T_4		20 ms		11 ms	
Run-up output T_5		50 μ s	2 ms	50 μ s	2 ms
Result retention time T_6		1 ms	1 s or next result	1 ms	1 s or next result

)¹ Devices with integrated lenses)² Devices with interchangeable lenses

Following image acquisition, the *Image trigger* signal is deactivated. The Image trigger signal is activated again at the end of image acquisition and another image acquisition operation is possible immediately.

The Pass/Fail signal then switches at the set output time even if additional analyses have already been performed. The Result *valid* signal is active during this time.

NOTE




If you have connected an encoder, you may set the output time and duration as a distance.

In addition, you can specify an "output run-up" in milliseconds to activate the Pass/Fail signal before reaching a specific position. This option is available if an exact output time has been specified and this is specified as a distance.

Keep in mind that, in this case, the conveyor speed must be constant!

13.3 Timing for continuous image acquisition

The sequence of the individual signals and their designation are indicated in the diagram below:



Signal		Full resolution		Reduced resolution (device dependant)	
		min.	max.	min.	max.
Exposure time T_2	Internal illumination ¹	35 μ s	10 ms	35 μ s	5 ms
	External illumination	35 μ s ¹ / 10 μ s ²	65.5 ms	35 μ s ¹ / 10 μ s ²	65.5 ms
	Flash controller ²	10 μ s	1 ms / 65.5 ms	10 μ s	1 ms
Image acquisition T_3		16 ms	20 ms	8 ms	11 ms
Output time (min / max) T_4		20 ms		11 ms	
Run-up output T_5		50 μ s	2 ms	50 μ s	2 ms
Result retention time T_6		1 ms	1 s or next result	1 ms	1 s or next result


¹ Devices with integrated lenses

² Devices with interchangeable lenses


If continuous image acquisition is set in the job, the image acquisition operation occurs as soon as the previous image acquisition is complete. The *Image trigger* signal is continuously activated during this time. The Pass/Fail signal is switched at the end of image analysis but no earlier than the set output time. You can recognize this time by a rising edge of the *Result valid* signal.

13.4 External Teach


External Teach adjusts the switching thresholds and models in the feature checks so that the evaluations have OK as the result. External Teach is used if the product changes or there are new product versions.



The digital input "Teach" must be in the "active high" state at the trigger point.



To use external Teach, **Use External Teach:** Must be activated for the corresponding feature checks. External Teach is then triggered simultaneously for all appropriate feature checks.



Job changes are only stored temporarily until the device is deactivated. If you want to retain the settings, you must activate the option "Save changed parameters from External Teach or process SP interface command to the device".


(Device → Device settings → Job selection/Teach)

13.5 Job switching

The jobs saved in the device can be activated by the corresponding switching signals with the digital inputs or individually via the process interface.

They are activated as soon as the command is received, however evaluations that are already running will be completed before the job is switched over. How long it takes to switch the job over depends mainly on its content (exposure time, number and type of feature checks, job position).

New images cannot be triggered during the switch-over.



Signal	Switch-over times
Run-up program selection T_1^*	Jobs 1-16: 5 ms Jobs 17-255: typically < 1 s (plus the set exposure time)

During program selection (T_1), the device is not active and the signal. *Image trigger* signal is deactivated. Please wait with the next image analysis operation until the "Active" state is displayed again by the corresponding signal.

If the switch could not be performed, for example because the job number was invalid, an alarm signal is also output until the next trigger.



NOTE

If a job is selected again by way of Job switching, and this job is already active, the *Image trigger* signal is not deactivated!

13.6 Job selection via digital inputs

There are two ways of switching the active job of the device via the digital inputs:

- **Binary:** The active job can be selected directly by a combination of the levels at the digital inputs.
- **Bit serial:** The stored jobs can be selected directly using a clock and data line.

Switching between jobs is only possible when the current mode is set to *Activated*. Switching between jobs is not possible in any other modes. Observe that you must activate the option *Job selection via digital inputs* in the Job Management to execute job selection by this means.

You can also switch the active job by transferring corresponding Commands via the process interface.

13.6.1 Binary job selection

For the device a maximum of four digital inputs are available for job selection.

It is possible to quickly switch between jobs 1 to 16 in this way.

The allocation of the levels to the selected job is as follows:


	Binary job selection - Bit 0	Binary job selection - Bit 1	Binary job selection - Bit 2	Binary job selection - Bit 3
Job 1	Low	Low	Low	Low
Job 2	High	Low	Low	Low
Job 3	Low	High	Low	Low
Job 4	High	High	Low	Low
Job 5	Low	Low	High	Low
Job 6	High	Low	High	Low
Job 7	Low	High	High	Low
Job 8	High	High	High	Low
...				
Job 16	High	High	High	High

NOTE



Please observe that this table relates to the configuration of the inputs as "active high". If you have configured an input as "active low", you must invert the specified levels for this input in the overview.

13.6.2 Bit serial job selection



	Signal applied to the input	
	min.	max.
Result retention time T_1	10 ms	1,000 ms

For bit serial job switching, two digital inputs are required: digital inputs IN2 ("Bit serial job selection – Clock") and IN3 ("Bit serial job selection – Data"). When inactive, high levels are applied to both lines. The levels of the data line are set briefly to low and then returned to high to start the transfer.

The desired job number can then be transferred as a series of bits. The respective bits must be transferred with the following levels on the data line:

Value	Level on the data line
0	High
1	Low

As soon as a rising edge is detected on the clock line, the corresponding bit is read on the data line. The status of the data line must be held constant for the result retention time T_1 and may only change when a low level is set on the clock line.

When all 8 bits have been transferred in this way, the inactive state is restored.

We recommend that switching to the next bit on the data line should be done simultaneously with activation of the falling edge on the clock line.

NOTE

This description applies when the parameters of the inputs are set to "active high". If you have configured an input as "active low", you must invert the specified levels for these inputs in the description.



You should also make sure that you have made the following settings for bit-serial job selection:


- In Job selection you must set the source "Digital inputs".
- For digital I/Os the parameters for the digital inputs 2 and 3 must be set as "Bit serial job selection – Clock" or "Bit serial job selection – Data".

Transfer the desired job number in this manner.

	Data to be transferred
Job 1	10000000
Job 2	01000000
Job 3	11000000
	...
Job 8	00010000
	...
Job 255	11111111

Example: Activation of job 5

You must switch the two digital inputs as follows to activate job 5:



13.7 Alarm signal

The alarm signal is activated under the following conditions in **parallel with the Pass/Fail signal** of the **current image acquisition/analysis operation**:

- Invalid trigger (trigger during image acquisition or job switching)
- Analysis aborted prematurely (output time exceeded)
- Error in job selection (invalid job number)
- Error at process interface
- FTP Alarm (An error occurred while transferring the images via the FTP client.)

If image analysis is not being performed at this time, the alarm signal is activated in parallel with the Pass/Fail signal of the **next image acquisition/analysis operation** if an error occurs.



NOTE

This output time for the alarm signal is not necessarily the next (seen chronologically) Pass/Fail signal if you are using the *Image trigger* or *Result valid* signals.

The alarm signal is activated immediately under the following circumstances and maintained **until the next trigger or until a successful job switch**:

- Job switching
 - if a job is selected that is not completely configured
 - if a job is selected that is not present
- Device activation
 - if an active job was not selected at Power On

14 Web interface

The device includes an integrated web server. This enables operation and reconfiguration (e.g. of machine control) via the web browser.

The web interface can be adapted to suit the application by configuring the 9 buttons for the main menu. Sub-functions and access rights for up to two user profiles can also be set.

In the web interface, you will be able to access the functions you have configured during job creation (*Configure interface* → *Web interface*) and in the device menu (*Device* → *Device settings* → *Configure web interface / Functions*).

NOTE



When using the web interface, simultaneous operation of the Application Suite is not recommended.

It is possible to use the web interface at the same time as PROFINET or EtherNet/IP.

14.1 Supported browsers

Due to differences in browser technology, there may be some differences in appearance between browsers and browser versions or even incompatibilities with the device. In our experience, these incompatibilities increase with the age of the browser due to a lack of standardization, for instance Internet Explorer® is not compatible with the device. We cannot test all browsers and their various releases, so untested browsers may also function with the device.

Currently the device officially supports the following browsers:

- Edge 134 (recommended)
- Chrome 134 (recommended)
- Firefox 52

Cookies must be permitted.

NOTE



When using the web interface, ensure that security measures are in place to ensure that unauthorised persons do not have access.

This could include restricting access from outside sources or using VPN connections.

Only connect the Vision Sensor to a maximum of two browsers at any one time. Otherwise the web interface may not be displayed in its entirety.

In our experience the web technology only runs reliably to a limited extent in 24-hour operation, which may necessitate refreshing the browser from time to time.

NOTE



To use the web interface, you must activate JavaScript and Cookies!

Using pop-up blocker tools may result in the web interface not being correctly displayed. In this case, deactivate the pop-up blocker!

If necessary, add the IP address of the device to the "Local Intranet" zone. You can find this setting under *Tools → Internet Options → Security → Local Intranet → Sites → Extended*.

14.2 Connecting to the web interface

14.2.1 Connection to one device

Launch a supported browser and enter the IP address of the *device* or the defined domain name into the address bar.

NOTE




You can find the current IP address for your device on the *Info* tab next the *Help* tab in the *Application Suite*.

You can set the domain name under: *Device* → *Device settings* → *Device name*.

Several devices with the same domain name in the network could lead to problems. This could occur if the same backup is transferred to several devices. Give each device a unique domain name!

When using PROFINET, the IP address is usually assigned by the PROFINET master.



You have the option to log into the device as an operator or expert via the address line in your browser (password assignment for user profiles: *Device* → *Device settings* → *Access rights / Web interface*).

NOTE




Please ensure the URL is encoded correctly when entering your password via the browser!

```
http://[IP address]/?user=[Profi|Operator]&password=[password]
```

e.g.

```
http://173.194.35.23/?user=Profi&password=goodPassword
```

The following screen is displayed when the device is activated:



Click on the value to change the unit.

- Parts/ s → Parts/min → Parts/h
- OK (Parts → Percentage)
- NOK (Parts → Percentage)

Click on the picture to access the *Settings*.

14.2.2 Connection to multiple devices

If you have multiple devices in your network, you can display several devices simultaneously in a single browser window. By default you will see four frames with the available devices and their respective location in English.



NOTE

Connection to several devices is only possible if these devices are in the same subnet.



NOTE

Do not use `https` to retrieve the function. Devices that support encrypted data transmission will switch to this mode automatically.

Launch a supported browser and enter the following into the address bar:

<code>http://verisens.local/cockpit</code>	The device with the highest level of software will determine the layout of the viewer.
<code>http://[IP address]/cockpit</code> <code>http://[device name].local/cockpit</code>	The level of software of the accessed device will determine the layout of the viewer.
<code>[IPAdresse]/cockpit?/Live</code> <code>&c[column]r[row]=ip:[IP-Adresse1]</code> <code>&c[column]r[row]=ip:[IP-Adresse2]</code> <code>&c[column]r[row]=ip:[IP-Adresse3]</code> <code>&c[column]r[row]=ip:[IP-Adresse4]</code> <u>Example</u> <code>http://172.20.20.1/cockpit?/Live&c1r1=ip:172.20.20.1&c2r1=ip:172.20.20.2&c1r2=ip:172.20.20.3&c2r2=ip:172.20.20.4</code>	The level of software of the accessed device will determine the layout of the viewer and connect directly to a live view of the device in the selected rows and columns. NOTE Save the access parameters you created as a favourite to gain faster access to your devices.




NOTE

Please input the following to alter the number of frames to be displayed to nine (e.g. 3 windows per column and three per row):

`http://[IP address]/cockpit?view=3x3`

Other arrangements are possible, with up to four windows in a row and column.



Web interface: For establishing a web interface to the device.

Live image: For displaying a live image of the device in the frame. If the device is activated, graphical primitives will be displayed.


14.3 Device specific functions

The device specific functions that can be operated via the web interface are described below.

	NOTE You can set the availability of settings options and the corresponding rights through: <i>Device → Device settings → Configure web interface.</i>

Navigation

		
Back to start view	User profile (Only shown when user profiles are activated)	



Icon	Content
 Info and status	• Device name • Device state • Device type • Firmware version • Serial number of the device
 Statistics	• Name of job currently processing • Total number of checked parts • Number of parts marked good (OK) • Number of parts marked bad (NOK) • Number of alarms • All feature checks for the job with results (Number of OK/NOK)
 Processing time	• Device processing time in ms (Parts/s) • Processing time and results for current feature check
 Switch job	In this menu, you can change the active job. You can select any job on the device. The chosen job will activate immediately once selected.
 Defect images	In this dialogue, you will see the currently saved defect images. You can save defect images in full resolution using your browser's context menu.
 Job management	Under job management you have the following options: ▪ Copy job (Copy the job from one save location on the device to another) ▪ Delete job (Delete job from the <i>device</i>) ▪ Access job (Download a job from the device to your computer) ▪ Transfer job (Transfer a job from your computer to the device) ▪ Job on Power on (Set which job should be active when the <i>device</i> is switched on) ▪ Change job name (Change the name of a job on the <i>device</i>) ▪ Change job location (Save the job to a different location)
 Backup	▪ Create backup on the PC ▪ Restore from the PC ▪ Create on the FTP server ▪ Restore from the FTP server
 Language	You can change the language here. Once the language is selected, you can make sure this language is always used by ensuring <i>Device</i> → <i>Device settings</i> → <i>Configuration</i> → <i>Web interface / Language settings functions / Save selection</i> via web interface is ticked.
 Device	Device-specific functions (provides access to all device-specific functions via an additional menu level.)

14.4 Job specific functions

The job specific functions that can be used via the web interface are described below. Corresponding changes to the job are adopted and effective immediately.

The majority of feature checks support external teach, which can be triggered in the web interface by reconfiguring using the *Teach* button.

External teach must be activated during configuration of the relevant feature check in the *Application Suite*.

NOTE



You can set the availability of settings options and the corresponding rights for the feature check under:

Configure interface → *Web interface tab*

Navigation

					
Back	Apply settings and go back	Cancel	Display the live image if image acquisition is controlled via triggers	Trigger external teach	Determine the target colour



NOTE

The external teach triggered using the *Teach* button can also no longer be cancelled using the *Cancel* button!




ATTENTION!

The live image function puts the device into "free running" mode, i.e. it runs without the external trigger signal. Please be aware of the effects this may have on later processes.

The user level required to access the live image display can be configured under:

Device settings → *Configuration* → *Web interface/Functions*



14.4.1 Image acquisition

Function	Icon	Adjustable parameters
Image acquisition		• Exposure time • Amplification • Edge sharpness • Gamma correction

14.4.2 Part location



NOTE

The web interface does not support chained part location.

Function	Icon	Adjustable parameters
Part location on contours		• Teach area • Detection area • Conformity • Contrast • Maximum rotation • External Teach
Part location on edges		• Field of view edge A • Field of view edge A2 • Field of view of edge B
Part location on circle		• Field of view circle • Field of view edge for rotation
Part location on text line		• Field of view • Conformity

14.4.3 Geometry

Function	Icon	Adjustable parameters
Distance		- Field of view edge/circle A - Field of view edge/circle B - Distance - External Teach
Circle		- Field of view circle - Distance to the centre - Circle diameter - Roundness - External Teach
Angle		- Field of view edge A - Field of view edge B - Angle of the corner - External Teach
Count edges		- Field of view edges - Number of edges - External Teach
Point position		- Field of view - Rotation - Position X - Position Y - External Teach
Edge characteristics		- Field of view - Number of distances

14.4.4 Feature comparison

Function	Icon	Adjustable parameters
Count contour points		- Field of view - Number of contour points - External Teach
Contour comparison		- Field of view - Conformity - Tolerance - External Teach
Colour identification		- Field of view - Colour deviation (in ΔE)
Brightness		- Field of view - Brightness - External Teach

Contrast		• Field of view • Contrast • External Teach
Area size		• Field of view • Area • Colour • Binary threshold • External Teach
Area size (colour)		• Field of view • Area • Target colour
Colour positioning		• Fields of view • Target colour
Count areas		• Field of view • Number of areas • Colour • Binary threshold • Areas filter: Minimum • Areas filter: Maximum • External Teach
Count areas (colour)		• Field of view • Number of areas • Areas filter: Minimum • Areas filter: Maximum • Target colour
Pattern comparison		• Field of view • Deviation
Pattern comparison (colour)		• Field of view • Deviation
Finding object positions		• Detection area • Number of objects • Conformity • Contrast • Maximum rotation • Maximum number of objects • Horizontal reference shift • Vertical reference shift • Reference rotation

14.4.5 Identification

Function	Icon	Adjustable parameters
Barcode		• Field of view • Expected code • Type of code • Parameter set • Bar width: Minimum • Bar width Maximum • Bar height: Minimum • Polarity • Minimum contrast • Rotation tolerance • External Teach
Barcode (colour)		• Field of view • Expected code • Type of code • Parameter set • Bar width: Minimum • Bar height: Minimum • Polarity • Minimum contrast • Rotation tolerance
Matrix code		• Field of view • Expected code • Type of code • Parameter set • Polarity • Minimum contrast • Recognition • External Teach
Matrix code (colour)		• Field of view • Expected code • Type of code • Parameter set • Polarity • Minimum contrast • Recognition
Text		• Field of view • Expected • Mode • Colour • Threshold • Change character density • External Teach

Text (colour)		• Field of view • Expected code • Type of code • Parameter set • Polarity • Minimum contrast • Recognition

14.5 Functions selectable via the address bar

14.5.1 Language selection

The web interface will automatically launch in the same language as your operating system. However, you can change the language via the address bar of the browser.

Web interface in German:

```
http://[IP address]/?lang=de
```

Web interface in English:

```
http://[IP address]/?lang=en
```

Web interface in French:

```
http://[IP address]/?lang=fr
```

Web interface in Spanish:

```
http://[IP address]/?lang=es
```

Web interface in Chinese:

```
http://[IP address]/?lang=zh
```

Web interface in Japanese:

```
http://[IP address]/?lang=ja
```

Web interface in Korean:

```
http://[IP-Adresse]/?lang=ko
```

Web interface in Italian:

```
http://[IP-Adresse]/?lang=it
```

Web interface in Thai:

```
http://[IP address]/?lang=th
```

14.5.2 Scaling down the transferred image

To increase the image refresh rate in the web interface, you can scale down the image before transferring it (binning). The binning parameter can be combined with all of the other access options for the web interface.

Image in its original size

```
http://[IP address]/?binning=none
```

Image scaled down to half of its original height and width (default setting)

```
http://[IP address]/?binning=2x2
```

Image scaled down to quarter of its original height and width

```
http://[IP address]/?binning=4x4
```

14.5.3 Live image

View the live image in the full browser window via the browser's address field. If the device is activated, graphical primitives will be displayed:

`http://[IP address]/?liveImage`



14.5.4 Defect images


Access defect images via the browser's address field. You can save defect images in full resolution using your browser's context menu.

`http://[IP address]/?defectImages`

Other access options:

`http://[IP address]/?errorImages`

	
Update defect images	Delete defect images



14.5.5 Static images

You can access a single image without displaying the feature checks using the address field of the browser:

`http://[IP address]/live_image.bmp`



You can also display a single image showing the feature checks using the address field of the browser:

```
http://[IP address]/live_image.bmp?results=1
```



14.5.6 Setting the display screen

By default, the current image is refreshed as quickly as possible. If you want a constant image refresh rate, say to reduce network traffic, you can change this rate using a parameter on opening the web interface:

```
http://[IP address]/?refreshTime=t
```

The cycle time t is specified in milliseconds. A value of 0 means that the images are to be transferred as quickly as possible.

If display errors result when using a fixed image refresh rate, please increase the cycle time value.

NOTE



It is possible that the device is transferring image data via the web interface while simultaneously being linked to an *Application Suite*. In this case, the image data are preferably transferred to the *Application Suite* with the image frequency on the web interface being correspondingly reduced.

You can check in the *Status* area whether the device is linked to an *Application Suite*.

15 Communication via the process interface (device dependent)

This chapter provides an overview of the process interface of the device.

15.1 Process interface via TCP/UDP (device dependant)

15.1.1 Configuration of the Ethernet interface

The device is integrated via the process interface using an Ethernet connection and pre-configured port 23 ("Telnet"). For this purpose, connect the device with your machine and set the parameters, in particular the configuration of the IP address, using the *Application Suite*.

You can change the *Application Suite* parameters under: *Device* → *Device settings* → *Process interface*.

The following parameters are also required to control the logical transfer of the process data:

Parameters	Description	Values
<u>Result</u>	Time of result transfer	On request Continuous
<u>Receipt timeout</u>	Maximum duration between two characters	10 – 2,000 ms
Connection timeout	Maximum time between two received commands	Deactivated 1 – 3.600s

The transfer of the datagrams can occur at two different times:

- The Vision Sensor transfers the datagrams *on request*, i.e. as a response to the command "GD". This mode is designated "*Polling mode*".
- The Vision Sensor transfers data *continuously* after each image has been transferred. This mode is designated "Continuous mode".

NOTE



The connection timeout will in principal (depending on the duration of the process) not be reset, or not be reset at the correct time, for the following commands:

- Command GB (backup of the device)
- Command GF (retrieve individual pieces of data from the device)
- Command GI (retrieve an image)

15.1.2 Protocol structure – Ethernet



After you have established a connection with the device via the set port, you can request data from the device or transfer commands. To do this, you may use the device protocol. This consists of a 2-byte command code followed by the parameters and the actual data.

The datagrams may also be terminated with the following control characters:

- <CR> (Hex: 0D, Escape sequence: \r)
- <LF> (Hex: 0A, Escape sequence: \n)
- <CR><LF> (Hex: 0D 0A, Escape-Sequence: \r\n)
- without

15.2 Process interface via RS485 (device dependant)

You can communicate directly with the device via an RS485 connection.

15.2.1 Configuration of the RS485 interface

The integration of the device via the process interface is made with an RS485 connection. For this purpose, connect the device with your machine using the pins provided and set the RS485 parameters using the *Application Suite*.

The following parameters are available with which the physical transfer is controlled:

Parameters	Description	Values
Baud rate	Transfer speed	9600, 38400, 57600, 115200, 230400 bps
Parity	Control of the parity bit	none, even, odd
Data bits	Number of bits per character	8
Stop bits	Number of stop bits as end code	1

The following parameters are also required to control the logical transfer of the process data:

Parameters	Description	Values
<u>Device number</u>	Address in the bus protocol	1 – 254
<u>Protocol</u>	Protocol type	Point-to-point Bus without checksum Bus with checksum
<u>Result</u>	Time of result transfer	On request Continuous
<u>Receive timeout</u>	Maximum duration between two characters	10 – 2,000 ms
<u>Response delay</u>	Duration between reception of a command and transmission of the response	Min: 0 – 2,000 ms Max: 500 – 10,000 ms

The transfer of the datagrams can occur at two different times:

- The Vision Sensor transfers the datagrams on *request*, i.e. as a response to the command "GD". This mode is designated "*Polling mode*".
- The Vision Sensor transfers data *continuously* after each image has been transferred. This mode is designated "*Continuous mode*".

15.2.2 Protocol structure – RS485

Two means of data transfer are available for the operation of the process interface:

- **Point-to-point protocol** This protocol is a shortened form of the bus protocol. It provides no means of addressing or verification with a checksum. This protocol is suitable when fast reaction times and low data volumes are concerned and transfers are verified by other means.
- **Bus protocol**
This protocol permits up to 254 devices to be accessed on one RS485 bus. Communication security is ensured by the use of synchronization signals and an optional checksum. The formatting of the data is a so more strictly defined in this protocol, simplifying further processing.


Point-to-point protocol:




The point-to-point protocol consists of a 2-byte command designator followed by the parameters and the actual data. No control codes are used. Synchronization can be achieved using receive timeout.

Bus protocol:

With checksum




Without checksum




If you wish to transfer more than 65,535 bytes, e.g. jobs, you can extend the length to 8 bytes (sufficient for 2^{32} bytes). This changes the start and end codes:

With checksum




Without checksum



This protocol has a defined format:

Element	Size	Meaning
{ / [(/ <	1 byte	These codes are used for synchronization of the transfer. If you specify the length in 4 bytes, use the code "{" (datagram with checksum) or "[" (datagram without checksum). If you specify the length in 8 bytes, use the code ">" (datagram with checksum) or ">" (datagram without checksum).
Length	4 or 8 bytes ASCII-Hex	The length is equivalent to the number of transferred bytes from the device number (inclusive) to the end of the data, i.e. without any checksum. If the datagram exceeds a length of 65,535 bytes and you require 8 bytes for the length, you must use the start code "(" or "<".
Device number	2 byte ASCII hex	Each connected device has its own device number in a range from 1 („01“)-254 („FE“). Number 0 is reserved to address the bus master (PLC, PC ...). Device number 255 ("FF") can be used to send commands to all connected devices simultaneously.
Command	2 byte	<u>Command designation</u>
Parameters	4-12 bytes	Each command has a parameter block at least 4 bytes in length, some of which remain unused.
Data	variable	Optional data section, which may contain result or job data.
Checksum	2 byte ASCII hex	The checksum is produced by linking all characters beginning with the device number to the end of the data byte for byte with XOR. The checksum must only be specified if the start code "{" or "(" is used, otherwise this entry is omitted.
} /]) / >	1 byte	These codes are used as the end codes of the command blocks. If you specify the length in 4 bytes, use the code "}" (datagram with checksum) or "]" (datagram without checksum). If you specify the length in 8 bytes, use the code ">" (datagram with checksum) or ">" (datagram without checksum).

The following section is used to calculate the checksum:



If you use the RS485 bus protocol (device number: 6), the formats change as follows:

Example (Retrieve the last feature check)

NOTE

You can set the structure of datagrams for input and output via the process interface during job creation under *Configure interface*.

{	0	0	0	8	0	6	G	D	0	0	0	0	0	5	}
Star	Length	Device	Com-	unused	Check-	End									
t	8 byte	no.	mand		sum										

Retrieve a result

{	0	0	1	6	0	6	R	D	0	0	0	E	S	T	P	,	P	,	0	1	2	5	E	T	7	5	}
Star	Length	Device	Respon	Length	Start	Result		Result	Brightnes	End	Check-	End															
t	22 byte	no.	se	14 byte	Data			Intensity 1	s	Data	sum																
									Intensity 1																		

Response datagram

15.3 General Information

15.3.1 General description of data formats

It is important to distinguish between primitive data types (integers, floats, text) and composite data types (integer points, float-points, lists) as well as the format of the corresponding data type (ASCII-dec, binary, ASCII-2 decimal places).

15.3.1.1 Integer

This data type is a whole number value and can also be negative.

Example: 234

Format	Text representation	Transferred value (process interface)
ASCII hex	„EA"	\45 \41
ASCII dec	„234"	\32 \33 \34
Binary	cannot be represented	\00 \00 \00 \EA

15.3.1.2 Float

This data type is a floating value and can also be negative.

Example: 10.02

Format	Text representation	Transferred value (process interface)
ASCII (2 decimal places)	„10.02"	\31 \30 \2E \30 \32
ASCII (Exponent)	„+1.002E+01"	\2B \31 \30 \30 \32 \45 \2B \30 \30 \31
Decimal	„10"	\31 \30
Binary (Little Endian)	cannot be represented	\EC \51 \20 \41
Binary (Big Endian)	cannot be represented	\41 \20 \51 \EC

15.3.1.3 Text

This data type can contain both printable and non-printable characters.

Example: „MHD"

Format	Text representation	Transferred value (process interface)
ASCII	„MHD"	\4D \48 \44
Binary	„MHD"	\4D \48 \44

15.3.1.4 Composite data type: Integer point

This composite data type is formed of two integer values, the x-coordinate and the y-coordinate.

Available format: Analogue integer

Portrayal: x coordinate <separator> y coordinate

Example: Value: (234, 123), Separator: „;"

Format	Text representation	Transferred value (process interface)
ASCII hex	"EA;7B"	\45 \41 \3B \37 \42
ASCII dec	„234;123"	\32 \33 \34 \3B \31 \32 \33
Binary	cannot be represented	\00 \ 00 \00 \EA \3B \00 \ 00 \00 \7B

15.3.1.5 Composite data type: Float point

This composite data type is formed of two float values, the x-coordinate and y-coordinate.

Available format: Analogue float

Portrayal: x coordinate <separator> y coordinate

Example: Value: (234.02, 123.03), Separator: „;"

Format	Text representation	Transferred value (process interface)
ASCII (2 decimal places)	„234.02;123.03"	\32 \33 \34 \2E \30 \32 \3B \31 \32 \33 \2E \30 \33
ASCII (Exponent)	" +2.3402E+02;1.2303E+02"	\2B \31 \30 \30 \32 \45 \2B \30 \30 \31
Decimal	„234;123"	\31 \30
Binary (Little Endian)	cannot be represented	\1F \05 \6A \43 \3B \5C \0F \F6 \42
Binary (Big Endian)	cannot be represented	\43 \6A \05 \1F \3B \42 \F6 \0F \5C

15.3.1.6 Composite data type: List

This composite data type is a list of values of arbitrary type.

Available format: Analogue used data type

Represented as: Number <separator> <1. value corresponding data type> <separator> <2. Value corresponding data type> <separator> ... <separator> <last value corresponding data type>

Example: (data type integer):

Values: (123,234,245), Separator: „,“

Format	Text representation	Transferred value (process interface)
ASCII hex	„03;7B;EA;F5“	\30 \33 \3B \37 \42 \3B \45 \41 \3B \46 \35
ASCII dec	„3;123;234;245“	\33 \3B \31 \32 \33 \3B \32 \33 \34 \3B \32 \34 \35
Binary	cannot be represented	\00 \00 \00 \03 \3B \00 \00 \00 \7B \3B \00 \00 \00 \EA \3B \00 \00 \00 \F5

15.3.2 Numeric values in commands

Various commands require numeric values as parameters or return numeric values. For example, when switching the current job, the corresponding job number must be specified and the new job number is returned in the status datagram.



NOTE

Numerals are always entered as ASCII Hex information in the command data. Observe that the Hex values must be specified in upper case letters!

For example, the Hex numbers below result from the following values:

Value	2 byte ASCII hex	4 byte ASCII hex
1	01	0001
10	0A	000A
100	64	0064
255	FF	00FF
1000	-	03E8

15.3.3 Conversion Table Decimal ↔ Hexadecimal ↔ Character

Dec	Hex	Char	Dec	Hex	Char	Dec	Hex	Char	Dec	Hex	Char
00	00	NUL	32	20	SP	64	40	@	96	60	`
01	01	SOH	33	21	!	65	41	A	97	61	a
02	02	STX	34	22	"	66	42	B	98	62	b
03	03	ETX	35	23	#	67	43	C	99	63	c
04	04	EOT	36	24	\$	68	44	D	100	64	d
05	05	ENQ	37	25	%	69	45	E	101	65	e
06	06	ACK	38	26	&	70	46	F	102	66	f
07	07	BEL	39	27	'	71	47	G	103	67	g
08	08	BS	40	28	(	72	48	H	104	68	h
09	09	HT	41	29	)	73	49	I	105	69	i
10	0A	LF	42	2A	*	74	4A	J	106	6A	j
11	0B	VT	43	2B	+	75	4B	K	107	6B	k
12	0C	FF	44	2C	,	76	4C	L	108	6C	l
13	0D	CR	45	2D	-	77	4D	M	109	6D	m
14	0E	SO	46	2E	.	78	4E	N	110	6E	n
15	0F	SI	47	2F	/	79	4F	O	111	6F	o
16	10	DLE	48	30	0	80	50	P	112	70	p
17	11	DC1	49	31	1	81	51	Q	113	71	q
18	12	DC2	50	32	2	82	52	R	114	72	r
19	13	DC3	51	33	3	83	53	S	115	73	s
20	14	DC4	52	34	4	84	54	T	116	74	t
21	15	NAK	53	35	5	85	55	U	117	75	u
22	16	SYN	54	36	6	86	56	V	118	76	v
23	17	ETB	55	37	7	87	57	W	119	77	w
24	18	CAN	56	38	8	88	58	X	120	78	x
25	19	EM	57	39	9	89	59	Y	121	79	y
26	1A	SUB	58	3A	:	90	5A	Z	122	7A	z
27	1B	ESC	59	3B	;	91	5B	[	123	7B	{
28	1C	FS	60	3C	<	92	5C	\	124	7C	
29	1D	GS	61	3D	=	93	5D	]	125	7D	}
30	1E	RS	62	3E	>	94	5E	^	126	7E	~
31	1F	US	63	3F	?	95	5F	_	127	7F	DEL

Example: Command GB – access device backup


Command

Char	G	B	0	0	0	0
Dec	71	66	48	48	48	48
Hex	0x47	0x42	0x30	0x30	0x30	0x30

Response

Char	R	B	0	0	0	0	0	0	0	4	F	6	1	6	...
Dec	82	66	48	48	48	48	48	48	48	52	70	54	49	54	Data
Hex	0x52	0x42	0x30	0x30	0x30	0x30	0x30	0x30	0x30	0x34	0x46	0x36	0x31	0x36	

15.3.4 Receipt timeout




Signal	Duration	
	min.	max.
Receive timeout T_1	10 ms	2000 ms

If errors occur in the communication, receiving is terminated after a defined time. The data received to this point is then discarded. The possible error causes may be:

- The cable was unplugged or mechanically damaged during the transfer.
- Transmission of the data was prematurely terminated due to a technical fault.
- An error occurred in the transfer of the length information, so that the information is incorrectly transferred. The device then presumes an incorrect overall length of the data.

15.3.5 Response delay



Signal		Duration	
		min.	max.
Response time T_1 No further commands must be transferred during this time!		0 ms	max. { T_2 , T_3 } + T_4
Reaction time T_2	Ethernet	1 ms	5 ms
	RS485 (device dependant)	1 ms	5 ms + 2.5 ms per 128 bytes of data
Response delay T_3		T_2	10,000 ms
Transfer time T_4		Dependant on the transfer parameters and the length of the data	

The transfer of the data begins not before time T_2 or the value set by the user.

If the time of the maximum response delay is exceeded without data being transferred, the possible response is discarded and you can transfer further commands.

Please observe that the received command will be processed in any case, even if no response datagram has been transferred due to the elapse of the maximum response time! For example, it is possible that this time could be exceeded when switching the active job. In this case, you will receive no confirmation, although the active job has been changed. If necessary, query the device status if you have received no confirmation.

15.4 Available commands for TCP / UDP / RS485

15.4.1 CS command – reset statistics

This function enables you to reset the statistics for individual jobs.

Example

Structure of the command PLC → device						
Command		Parameters				
C	S	0	0	0	0	
Clear Statistics		4 byte ASCII hex Job number 0000 = active job 0001 – 0010 = Job number 1-16 0011 – 00FF = invalid				

Structure of the Response PLC ← device						
Response						
R	C	0	0	0	0	
Response Statistics Cleared		4 byte ASCII hex Job number 0000 = active job 0001 – 0010 job number 1-16 0011 – 00FF = invalid				

15.4.2 Command DJ – delete job

This function enables you to delete some or all of the jobs on the device. The device must be in *Configuration* mode for jobs to be deleted.

	NOTE When a power-on job is deleted it will be deleted without replacement! There is currently no option to insert a new power-on-job via command. Although power-on jobs can be amended via an update (Command – UJ).

Example

Structure of the command PLC → device						
Command		Parameters				
D	J	0	0	0	0	
Delete Job		4 byte ASCII hex FFFF = all jobs on the device will be deleted 0001 (1) - 00FF (255) = individual jobs on the device will be deleted				

Structure of the command PLC → device				
Command		Parameters		
R	J	0	0	
Response Job		2 byte ASCII hex 0000 = job(s) deleted 0001 = device not in Configuration mode 0002 = invalid job number (job does not exist)		

15.4.3 Command GA – temperature alarm queries (only devices with integral Industrial Ethernet)

This function enables you to query the device's current temperature status.

An internal protection device intervenes when the device is operated outside of specification; this is intended to protect the components against destruction by heat.

The *Application Suite*, the web-interface and the process interfaces will output an overheating warning to notify users that the maximum permissible operating temperature has been reached (circa 85–90% of loading, see the *Request GT heat state command*).

Should the housing temperature continue to rise, the device will undergo emergency shutdown to protect it from damage.

Example

Structure of the command PLC → device		
Command	Parameters	
G	A	
Get Alarm	none	

Structure of the Response PLC ← device										
Response										
R	A	0	0	0	0	0	0	0	0	
Response Alarm	8 byte ASCII hex Temperature status									

Parameters of the "RA" command – current temperature status

The current temperature status will be transmitted using 8 characters, where the first 7 characters in a bit mask are always 0 and the current temperature status is contained in bits 0 and 1 of the eighth character.

Bits							
3	2	1	0	3	2	1	0
1. ASCII characters				2. ASCII characters			
0				0			
3. ASCII characters				4. ASCII characters			
0				0			
5. ASCII characters				6. ASCII characters			
0				0			
7. ASCII characters				8. ASCII characters			
0				0	Thermal shutdown		Heat warning

15.4.4 Command GB – access device backup

This function enables you to access a backup of the device with firmware or the job as well as the device settings.

Example

Structure of the command PLC → device						
Command		Parameters				
G	B	0	0	0	0	
Get Backup		0000 = Backup with firmware 0001 = Only jobs and device settings				

Structure of the Response PLC ← device													
Response													
R	B	0	0	0	0	0	0	0	4	F	6	1	6
Response Backup		4 byte ASCII hex Parameters of the GB-command				8 Byte ASCII-Hex data length (32bit) For errors, the length is 0						Data	
		Error messages: F001 = Device is not deactivated F002 = Not enough memory on the device F004 = Backup has already been called F008 = Password protection activated											

(device dependant)

NOTE



If the device backup contains calibrated lens distortion or shading correction, then the backup will only be completed when the *Application Suite* has been used to switch the device to set-up mode after recovery (*Device configuration*).

Switching via the SM command is insufficient for this.

15.4.5 GD command – retrieve last result

This function enables you to retrieve the result of the last feature check.



NOTE

You can set the content of the datagram for output via the process interface during job creation under *Configure interface* → *Output process interface*.

Example

Structure of the command PLC → device		
Command		Parameters
G	D	
Get Data		none

Structure of the Response PLC ← device						
Response						
R	D	0	0	0	0	...
Response Data		4 byte ASCII hex Length of the result data			Data	


Parameters of the "RD" datagram response

The datagram contains the results of the last image analysis.



NOTE

You can set the content of the datagram for output via the process interface during job creation under *Configure interface* → *Output process interface*.



The time stamp in the datagram consists of 8 ASCII characters which specify the number of milliseconds since the system start of the device as a hexadecimal number. This value reverts from 4,294,967,295 ms to the value 0 ms after about 49.7 days.

Numbers in datagrams can be represented in different ways:


Representation	Description
ASCII decimal	Decimal notation of the number. Negative numbers are represented with "-". „123“, „78“, „89“, „-123“
ASCII hexadecimal	Hexadecimal notation of the number. Negative numbers are represented as a complement. "7B", "4E", "59", FF85
Binary	Binary output of the number. Measured value 123: Characters output 0x00, 0x00, 0x00, 0x7B


NOTE

In ASCII decimal, the sign is included in the length. For example, if a length with the value of 4 is set, this results in a range of values from –999 to 9999.

Example for the transfer of result data

The configuration of the datagram is set as shown in the illustrations:



Active	Feature	Value	Start	Format	Min. length
1	Ergebnis	Total result			
2	Brightness 1	Result			0
3	Brightness 1	Brightness		ASCII Deci	0

Preview: Result only

STP ,P,125ET

The response from the device would be:

Structure of the Response PLC ← device															
Response															
R	D	0	0	0	E	S	T	P		,	P		,	0	1
Response Data		4 byte ASCII hex Length of the result data				Start Data		Result			Result Brightness			Brightness	
														End Data	

Each feature check result is represented within 1 Byte. The inspection result is described by "P" (result OK) or "F" (result NOK).

An interpretation of this datagram produces:

The overall result of the last image analysis was OK. In the field of view for the "brightness" feature check, the measured value is defined as 125. The individual result for this feature check was also OK.

Each feature check can produce a range of parameters, which you can find in the description of the current feature check.

15.4.6 Command GF – retrieve individual files from the device

This function enables you to access individual data on the device.

Example

Structure of the command PLC → device						
Command		Parameters				
G	F	0	0	0	0	
Get File		0000 = List of all jobs				
		01nn = Retrieve job (nn 2 byte ASCII-Hex Job number)				
		02nn = Call a job using the job name (nn:2-byte ASCII hex length of the file name + file name)				
		0300 = Access Logging				

Structure of the Response PLC ← device																
Response																
R	F	0	0	0	0	0	0	0	0	0	0	F	1	2	3	...
Response File		4 bytes ASCII-hex, mirrored parameters of the GF request				2 bytes ASCII hex: Error code 00 = no error occurred 01 = is not in Configuration- or IDLE- mode 02 = File not found 04 = last file still being retrieved FF = internal error		2 bytes ASCII hex Reserved		8 bytes ASCII hex Length of the following data				Data		

List of all jobs (GF0000)

Parameters									
0x0D	0x0A	0	1	:	3247	:	Job1.app	0x0D	0x0A
2 byte (separation)		2 bytes ASCII Hex: job numberr		1 character (separation)	ASCII decimal: Size of job file	1 character (separation)	ASCII: name of job file	2 byte (separation)	
NOTE: This data is transferred per job.									

otherwise (GF0300)

Parameters	
...	
Data of the log file (binär)	

15.4.7 GI command – access an image (only via Ethernet)

This function enables you to access live images and defect images with and without the field of view.

Example

Structure of the command PLC → device						
Command		Parameters				
G	I	0	0	0	0	
Get Image	2 byte ASCII hex 00 = live image 01 = Live image with field of view 80 = Fault image 81 = Fault image with field of view		2 byte ASCII hex image number 00 = Last image, 01 = penultimate image, 02 = ...			

Structure of the Response PLC ← device															
Response															
R	I	0	0	0	0	0	0	0	4	F	6	1	6	...	
Response Image	2 byte ASCII hex			2 byte ASCII hex		8 byte ASCII hex								Image data in the format BMP	
	Image number			Image number		Length of the image data									
		00 = live image													
		01 = Live image with field of view													
		80 = Fault image													
		81 = Fault image with field of view													

NOTE



A new *GI* command must be used to wait until the *RI* response to the previous request has been sent. Otherwise a precipitously renewed *GI* command will be acknowledged with the *RI000000000000* response.

15.4.8 GM command – access information about the device

This function enables you to access information about the connected device.

Example

Structure of the command PLC ➡ device						
Command		Parameters				
G	M	0	0	4	0	
Get Model Information		4 byte ASCII hex				
		Access single elements				
		0001 = Device type				
		0002 = MAC address				
		0004 = Serial number				
		0008 = Firmware version				
		0010 = Hardware version				
		0020 = Device name				
		0040 = Manufacturer				
0000 = All (in the order given above)						

Structure of the Response PLC ← device										
Response										
R	M	0	0	4	0	0	0	1	4	Baumer Optronic GmbH
Response Model Information		4 byte ASCII hex mirrored parameters of the GM request				4 byte ASCII hex For each element: Length of the result data				Data

15.4.9 GP command – access the current configuration of the SP command

This function allows you to read out the current values that can be changed using the SP command (set parameters for feature checks).

This is useful, for example, if you wish to read out the expected value for the "Barcode" / "Matrix code" via the controller.

Example

Structure of the command PLC → device		
Command		Parameters
G	P	
Get Parameter		none

Structure of the Response PLC ← device													
Response													
R	G	0	0	0	8	1	5	.	0	2	.	1	4
Response Get Parameter		4 byte ASCII hex Length of the result data				Data The content of the data corresponds with the expected values currently set for the feature check e.g. a date, or a combination of expected values for different feature checks and display settings.							

NOTE



You can set the content of the datagram for output via the process interface during job creation under *Configure interfaces* → *Output process interface*.

15.4.10 GS command – request status

This function enables you to access current status information for the device.

Example

Structure of the command PLC → device		
Command	Parameters	
G	S	
Get State	none	

Structure of the Response PLC ← device										
Response										
R	S	0	0	8	5	0	0	1	A	
Response State	4 byte ASCII hex Status				4 byte ASCII hex Number of the active job					

NOTE



A TCP/IP connection can be monitored, for example by the PLC cyclically sending the GS command. If the connection is broken, this is shown on the Vision Sensor page and the connection is reset.

Parameters of the "RS" command – Current status information

The current status information consists of 8 characters, of which the first 4 characters describe various states in a bit mask and the other 4 characters contain the current job number.

Bits

3	2	1	0	3	2	1	0
1. Status (ASCII)				2. Status (ASCII)			
Internal error	Backup OK	Backup Error	Backup Active	Acquisition Trigger possible	Job Update OK	Job Update Error	Job Update Active
3. Status (ASCII)				4. Status (ASCII)			
Mode Run Mode	Mode Test Mode	Mode Setup	Mode Recovery	Acquisition continuously	Acquisition External trigger	Protocol Continuous Mode	Protocol Polling Mode
1. Job number (ASCII)				2. Job number (ASCII)			
Number of active job							
3. Job number (ASCII)				4. Job number (ASCII)			
Number of active job							

When a job is being transferred via the process interface, the current status of this action can be queried by the PLC. The corresponding bit "Job update active" is set during the data transfer period. This bit remains set until the job has been completely transferred and stored or an error has occurred. The success of the action can then be assessed by the corresponding bits "Jobupdate – OK" and "Job update – error". These flags are retained until the next transfer of a job.

If the sensor is in *Activated* mode, the current job number is entered in the datagram. 0000 is entered here in all other operating modes.

Here are two examples of possible states of the device:

Character string	Meaning	
0 0 8 5 0 0 1 A	0 0 8 5 0 0 0 0 0 0 0 0 1 0 0 0 0 1 0 1	Current inspection mode: Activated Acquisition: External trigger Protocol: Polling mode Active job: 26 (Hex: 1A)
0 0 2 9 0 0 0 0	0 0 2 9 0 0 0 0 0 0 0 0 0 0 1 0 1 0 0 1	Current inspection mode: Configuration Acquisition: Continuous Protocol: Polling mode Active job: -

15.4.11 GT command – request thermal condition (only devices with integral Industrial Ethernet)

This function enables you to query the device's current thermal state. The internal temperature sensor is queried for this and the capacity is output in %.

An internal protection device intervenes when the device is operated outside of specification; this is intended to protect the components against destruction by heat. The device will undergo emergency shutdown when 100% capacity is reached.

The *Application Suite*, the web-interface and the process interfaces will output an overheating warning to notify users that the maximum permissible operating temperature (circa 85–90% of loading) has been reached (see *GA temperature alarm command*).

Example

Structure of the command PLC → device		
Command	Parameters	
G	T	
Get Thermal Condition	none	

Structure of the Response PLC ← device		
Response		
R	T	0 0 0 0 0 0 0 0 0 0
Response Thermal Condition	8 byte ASCII hex Thermal state	

Parameters of the "RS" command – current thermal state

The percentage value for capacity of the temperature range before emergency thermal shutdown (100% capacity) is transmitted using 8 characters, the first 6 characters in a bit mask are always 0 and the current thermal state is contained in ASCII characters 7 and 8.

Bits							
3	2	1	0	3	2	1	0
1. ASCII characters				2. ASCII characters			
0				0			
3. ASCII characters				4. ASCII characters			
0				0			
5. ASCII characters				6. ASCII characters			
0				0			
7. ASCII characters				8. ASCII characters			
Thermal state							

15.4.12 SJ command – change to a different job

This function enables you to change to a different job.

To use this function, you must first activate the option Command SJ via process interface in the device settings.

Example

Structure of the command PLC → device						
Command		Parameters				
S	J	0	0	1	A	
Switch Job		4 byte ASCII hex desired job number				

Structure of the Response PLC ← device									
Response									
R	S	0	0	8	5	0	0	1	A
Response State		4 byte ASCII hex Status				4 byte ASCII hex Number of the active job			



NOTE

Further explanation of the parameters of the RS response can be found under "Request status (GS / RS)".

15.4.13 SM command – change operating mode

This command enables you to change the operating mode for the device as well as the parameters for data exchange.

Example

Structure of the command PLC → device				
Command		Parameters		
S	M	M	R	
Switch Mode		2 byte ASCII hex		
		Mode DC = Data transfer – Continuous Mode The result data is autonomously transferred via the process interface after each analysis in Activated mode. You must also set the "Activate outputs" parameter during job testing. DP = Data transfer – Polling Mode In <i>Activated mode</i> and in <i>Configuration mode</i>, the result data is only transferred after the GD command has been received. MR = Mode switch – Modus <i>Run</i> The device is activated. Data is only transferred autonomously if the Continuous mode is activated as described above. MS = Mode switch – Modus <i>Parametrieren</i> The device is switched to Configuration No result data is transferred.		
		For Ethernet only		
		CC = Command delimiter – Carriage return Data packets from the process interface are terminated using <CR> (Hex: 0D, Escape sequence: \r) complete CL = Command delimiter – Line feed Data packets from the process interface are terminated using <LF> (Hex: 0A, Escape sequence: \n) complete CB = Command delimiter – Both carriage return + line feed Data packets from the process interface are terminated using <CR><LF> CN = Command delimiter – No sequence Data packets from the process interface are not terminated using a sequence		

Structure of the command PLC → device				
Command		Parameters		
S	M	M	R	
Switch Mode	2 byte ASCII hex			
	Mode			
	For RS485 only			
	Point-to-point protocol	Bus protocol		
	PP	PP	Protocol mode – Point-To-Point Changes the employed protocol to point-to-point protocol	
	PB	PB	Protocol mode – Bus without checksum Changes the used protocol to bus protocol without checksum	
	PC	PC	Protocol mode – Bus with Checksum Changes the used protocol to bus protocol with checksum	

Structure of the Response PLC ← device										
Response										
R	S	0	0	8	5	0	0	1	A	
Response State	4 byte ASCII hex Status					4 byte ASCII hex Number of the active job				


NOTE

Further explanation of the parameters of the RS response can be found under "Request status (GS / RS)".

15.4.14 SP command – set parameters for the feature checks

With this function, you can adjust the expected values of the feature checks as well as adjust the parameters of the image settings such as exposure time, amplification, edge sharpness, trigger mode and trigger delay.

The expected values are set temporarily and remain valid until the device is restarted or switches to configuration mode.

To save it long term, activate: *Device* → *Device settings* → *Job selection / Teach* → *Save changed parameters from external Teach or process interface command XX to device...*




NOTE

You can set the content of the datagram for output via the process interface during job creation under *Configure interface* → *Output process interface*.



NOTE

When setting the exposure time for the job, the "Camera ready" signal must be active before the next image can be acquired.



Example

Structure of the command PLC → device																			
Command		Parameters																	
S	P	0	0	0	A	1	7	.	0	3	.	2	0	2	5				
Set Parameter	4 byte ASCII hex Length of the result data					<u>Example 1</u> a date, or a combination of expected values for different feature checks													
	000D					3	0	0	0	0	3	0	2	5	4	5	0	0	
	4 byte ASCII hex Length of the result data					Exposure time (device dependent [µs])				Reinforcement (0 - 100 [%])		Sensitivity edge detection (5 - 100 [%])		Trigger mode (1 = continuous / 4 = or set distance)		Trigger delay (e.g. 500 ms)			
						<u>Example 2</u> Parameters for image settings													

Structure of the Response PLC ← device												
Response												
R	P	0	0	0	0	0	0	0	0	0		
Response Parameter	4 byte ASCII hex Status					4 byte ASCII hex Error position						
	0000 = OK 0001 = defective data in data packet 0002 = device not in RUN mode 0003 = value range exceeded 0004 = no datagram defined in job other = internal fault											


Timing diagram for SP and TE commands

The SP and TE commands can be sent at any time and are buffered. The system simultaneously sets a flag to prevent further images from being acquired.

This means that all processes currently running are completed before a new one is triggered.


Example 1 (sequential processing)

All processes are completed up to result output 1. SP/TE then becomes effective.



Example 2 (overlapped, clocked processing)

The command comes after the second trigger → all processes up to trigger 1 and trigger 2 are completed, SP/TE become effective after result 2.



15.4.15 TE command – use next image for external teach

This function enables you to use the next image for an external teach. However, image acquisition will not be triggered.

The function is set temporarily and remains valid until the device is restarted or switches to configuration mode.

To save it long term, activate: *Device* → *Device settings* → *Job selection / Teach* → *Save changed parameters from external Teach or process interface command XX to device...*

Structure of the command PLC ➡ device		
Command		Parameters
T	E	
TEach Image		none

Structure of the Response PLC ⬅ device		
Response		
R	T	
Response Teach		


Timing diagram for SP and TE commands

The SP and TE commands can be sent at any time and are buffered. The system simultaneously sets a flag to prevent further images from being acquired.

This means that all processes currently running are completed before a new one is triggered.


Example 1 (sequential processing)

All processes are completed up to result output 1. SP/TE then becomes effective.



Example 2 (overlapped, clocked processing)

The command comes after the second trigger → all processes up to trigger 1 and trigger 2 are completed, SP/TE become effective after result 2.



15.4.16 TR command – request image acquisition and response datagram

This function enables you to immediately trigger image acquisition and request a response datagram if required (the trigger delay remains in effect). The response datagram will only be sent if the result is automatically sent following image evaluation and if the data is defined.

Example

Structure of the command PLC → device		
Command		Parameters
T	R	
TRigger Image		none

Structure of the Response PLC ← device						
Response						
R	D	0	0	0	E	...
Response Data		4 byte ASCII hex			Data	
		Length of the result data				



NOTE

Further information on the composition of the datagram can be found using the command "Retrieve last result (GD / RD)".

15.4.17 TI command - trigger immediately

This function enables you to immediately trigger image acquisition and request a response datagram if required (any configured trigger delay is ignored). The response datagram will only be sent if the result is automatically sent following image evaluation and if the data is defined.

Example

Structure of the command PLC → device		
Command		Parameters
T	I	
Trigger Immediately		none

Structure of the Response PLC ← device						
Response						
R	D	0	0	0	E	...
Response Data		4 byte ASCII hex			Data	
		Length of the result data				



NOTE

Further information on the composition of the datagram can be found using the command "Retrieve last result (GD / RD)".

15.4.18 TD command – request image acquisition and transfer data

This function enables you to immediately acquire an image and response datagram. The response datagram will only be sent if the result is automatically sent following image evaluation and if the data is defined.

Unlike with command TR, this function can be used to transfer a string with the trigger, for example the part number of the current item being checked. The device allows you to use this string in the file name for the image when saving it to an FTP server. This is an easy way to establish a connection between images and objects.

Example

Structure of the command PLC → device							
Command		Parameters					
T	D	0	0	0	0	...	
Trigger Data		4 byte ASCII hex Length of the transferred string				Characters (0-255)	

Structure of the Response PLC ← device							
Response							
R	D	0	0	0	0	...	
Response Data		4 byte ASCII hex Length of the result data				Data	

A maximum of 156 characters is permitted in the data string (0-255).

15.4.19 UD command – transfer backup data (only for Ethernet)

This function enables you to transfer backup data to the device.

NOTE



The device must be restarted following use of the UD command and successful transfer of a backup, for example via the *VB0000* command.

Example

Structure of the command PLC → device																			
Command		Parameters																	
U	D	S	1	9	2	.	1	6	8	.	0	0	0	.	2	5	0	→	
Update Device		IP address	15 characters ASCII																
		S = static D = DHCP	IP address																
Parameters																			
2	5	5	.	2	5	5	.	2	5	5	.	0	0	0	→				
15 characters ASCII																			
Subnet mask																			
Parameters																			
0	0	0	.	0	0	0	.	0	0	0	.	0	0	0	→				
15 characters ASCII																			
Gateway																			
Parameters																			
1	1	V	S	X	F	2	0	0	M	1	0	W	E	-	T	E	S	T	→
2-Byte ASCII Hex		Device name																	
Length of device name																			

Parameters									
0	0	B	6	B	B	4	6	...	
8 byte ASCII hex Length of the following data								Data of the backup device	

NOTE

If using DHCP, you can set what happens following a DHCP timeout as follows:



- Use DHCP and in case of DHCP failure, use the last IP address
UDD000.000.000.000000.000.000000.000.000...
- or
UDD255.255.255.255000.000.000000.000.000...
- Use DHCP, set an alternative IP address
e.g. UDD192.168.000.250255.255.255.000000.000.000.000...
(In this case, the alternative IP address is 192.168.0.250)

The response datagram is only sent once the backup has been transferred and stored in full or an error occurs.

Structure of the Response PLC ← device				
Response				
R	U	0	0	
Response Update	2 byte ASCII hex			
	00 = received OK 01 = device not in Configuration mode 02 = backup too large 03 = job could not be loaded 04 = job update still active 05 = invalid network settings 06 = invalid device name 07 = backup file device type not identical to the device 08 = user management is active 09 = device file is password protected 10 = file could not be opened for writing 11 = file write error 12 = incompatible backup 13 = only the firmware cannot be imported other = internal fault			

15.4.20 UJ command – transfer a new job

This function enables you to transfer a new job to the device.



NOTE

The job name including the file extension ".app" can be a maximum of 31 characters.



NOTE

Jobs cannot be renamed on the PC when using the UJ command for job transfers.

Example

Structure of the command PLC → device												
Command		Parameters										
U	J	0	0	0	3	0	0	0	4	F	9	E 2 ...
Update Job		4 byte ASCII hex job number				8 byte ASCII hex Job size						Job as binary data

Structure of the Response PLC ← device				
Response				
R	U	0	0	
Response Update	00 = received OK 01 = device not in Configuration mode 02 = invalid job number 03 = job could not be loaded 04 = job update still active 05 = invalid network settings 06 = invalid device name 07 = backup file device type not identical to the device 08 = user management is active 09 = device file is password protected 10 = file could not be opened for writing 11 = file write error 12 = incompatible backup 13 = only the firmware cannot be imported FA = Receipt timeout			
	NOTE Timeout adjustable in the <i>Application Suite</i> under: <i>Device → Device settings → Process interface</i>			
other = internal fault				

15.4.21 VB command – restart device

This function enables you to restart the device or put it into recovery mode. This command does not send a response.

Example

Structure of the command PLC → device					
Command		Parameters			
V	B	0	0	0	0
Vision Sensor ReBoot		4 byte ASCII hex 0000 = Restart FFFF = Recovery mode			

15.5 Communication via Industrial Ethernet (device dependant)

It is possible to communicate with the Vision Sensor via various Industrial Ethernet protocols, such as PROFINET or Ethernet/IP™, using a PLC.

15.5.1 Mode of operation

The data transfer protocol is determined by the Industrial Ethernet specification.

The following data can be transmitted:

- General control and status data (triggers, pass / fail, active job, etc.)
- Result data (configuration in the case of job creation via the *Output process interface*)
- Job parameters (configuration in the case of job creation via the *Input process interface*)
- Additional trigger data (data in addition to the trigger that can be transmitted for object identification)

The data will be combined into logical groups. Data transmission of each group can be secured with a handshake.

Mapping of the data in the PLC must be planned using the manufacturer-specific tool.

Selection of the protocol can be undertaken via the *Application Suite* as can the relevant settings. The setting options can be found under: *Device* → *Device settings* → *Process interface*.

15.5.2 Abbreviations for Industrial Ethernet


The following abbreviations are used in the next sections.

Abbreviation	Meaning
C	Controller (PLC)
D	Device (vision sensor)
HSS	Handshake simple
HSWA	Handshake with Acknowledge
HS	Handshake
ACT	Activation / Active
ACK	Acknowledge
pad	Padding
Img Proc	Image Processing
Res	Result
PIF	Process Interface
Buf OV	Buffer overflow
Pipe OV	Pipeline overflow
Inv	Invalid
TRG	Trigger
RDY	Ready
Res	Result
O	Originator
T	Target
SM	Switch Mode
SP	Set Parameter
SJ	Switch Job


15.5.3 Timing diagrams

This chapter describes the time sequences and communication processes of various functions and processes in the context of communication via Industrial Ethernet. The timing diagrams are used to illustrate the chronological sequence of signals and actions to enable an understanding of how the respective processes work.

Read operation



1	TRG is set to 1 to trigger image acquisition
2	Image acquisition begins and TRG RDY is set to 0 and Img Proc ACT to 1.
3	At the end of image acquisition, TRG RDY is set to 1 again and the actual image analysis begins.
4	At the end of Image analysis, Img Proc ACT is set to 0 again and the new Results* are output.
5	Regardless of all events, TRG can be set to 0 again at any time.
	)* Results: Total Res Pass, Total Res Fail, Result Toggle Bit, Act Res Data Len, Res Data

Read operation (simple handshake)


1	TRG is set to 1 to trigger image acquisition. At the same time (or afterwards) the C -> D HS Flag must be changed.
2	Then <i>image acquisition</i> begins and TRG RDY is set to 0 and <i>Img Proc ACT</i> is set to 1. At the same time, the D -> C HS Flag is changed.
3	At the end of <i>image acquisition</i> , TRG RDY is set to 1 again and the actual <i>image analysis</i> begins. At the same time, the D -> C HS Flag is changed.
4	At the end of <i>image analysis</i> , <i>Img Proc ACT</i> is set to 0 again and the new <i>Results*</i> are output. At the same time, the D -> C HS Flag is changed (for PROFINET separately for the <i>Control & State</i> module and the <i>Result</i> module).
	)* Results: Total Res Pass, Total Res Fail, Result Toggle Bit, Act Res Data Len, Res Data

)** Handshake signals (see chapter *Handshake*)

Handshake for output data (controller to device)

C -> D HSS ACT: Simple handshake activation

C -> D HSS ACT ACK: Confirmation for activation simple handshake

C -> D HS Flag: Handshake flag, inversion when new data is valid

C -> D HS ACK: Handshake Ack Flag, is set to the value of C -> D HS Flag when new data has been transferred

Handshake for input data (device to controller)


D -> C HSS ACT: Simple handshake activation

D -> C HSS ACT ACK: Confirmation for activation simple handshake

D -> C HS Flag: Handshake flag, inversion when new data is valid

D -> C HS ACK: Handshake Ack Flag, is set to the value of D -> C HS Flag when new data has been transferred


Read process (handshake with confirmation)



1	TRG is set to 1 to trigger image acquisition. At the same time (or afterwards), the C -> D HS flag must be changed.
2	Reception is confirmed by changing C -> D HS ACK accordingly. In addition, image acquisition begins and TRG RDY is set to 0 and Img Proc ACT to 1. At the same time, the D -> C HS flag is changed.
3	The reception must be confirmed by changing D -> C HS ACK accordingly.
4	At the end of image acquisition, TRG RDY is set to 1 again and the actual image analysis begins. At the same time, the D -> C HS Flag is changed.
5	Reception must be confirmed by changing D -> C HS ACK accordingly.
6	At the end of Image analysis, Img Proc ACT is set to 0 again and the new Results* are output. At the same time, the D -> C HS Flag is changed (for PROFINET separately for the Control & State module and the Result module).
7	The receipt must be confirmed by changing D -> C HS ACK accordingly. With PROFINET, the confirmation must be made separately for the Control & State module and the Result module.
8	Regardless of all events, TRG can be set to 0 again at any time (after receiving the confirmation for TRG -> 1). At the same time (or afterwards), the C -> D HS Flag must be changed.
9	Reception is confirmed by changing C -> D HS ACK accordingly.

	)* Results: Total Res Pass, Total Res Fail, Result Toggle Bit, Act Res Data Len, Res Data
	)** Handshake signals (see chapter <i>Handshake</i>) Handshake for output data (controller to device) C -> D HSWA ACT: Activation handshake with confirmation C -> D HSWA ACT ACK: Confirmation for handshake activation with confirmation C -> D HS Flag: Handshake flag, inversion if new data valid C -> D HS ACK: Handshake Ack flag, is set to the value of C -> D HS flag if new data has been accepted Handshake for input data (device to controller) D -> C HSWA ACT: Activation handshake with confirmation D -> C HSWA ACT ACK: Confirmation for handshake activation with confirmation D -> C HS Flag: Handshake flag, inversion if new data valid D -> C HS ACK: Handshake Ack Flag, is set to the value of D -> C HS Flag if new data has been accepted


Read process with handshake with confirmation (delayed)



1	TRG is set to 1 to trigger image acquisition. In this example, the <i>C -> D HS Flag</i> is changed with a delay.
2	The <i>C -> D HS Flag</i> is changed with a delay.
3	Only now is the changed trigger signal evaluated. Reception is confirmed by changing <i>C -> D HS ACK</i> accordingly. Image acquisition also begins and <i>TRG RDY</i> is set to 0 and <i>Img Proc ACT</i> to 1. At the same time, the <i>D -> C HS Flag</i> is changed.
4	The receipt must be confirmed by changing <i>D -> C HS ACK</i> accordingly. In this example, this is done with a delay.
5	At the end of image acquisition, the actual image analysis begins and <i>TRG RDY</i> could be set to 1 again. However, as the previously sent data has not yet been confirmed with <i>D -> C HS ACK</i> , this is delayed until the confirmation is received.
6	The receipt of the previously received data (3) is now confirmed by changing <i>D -> C HS ACK</i> accordingly.
7	After receiving the confirmation, the already internally pending change of the <i>TRG RDY</i> to 1 can be sent. At the same time, the <i>D -> C HS Flag</i> is changed.
8	Reception is confirmed by changing <i>C -> D HS ACK</i> accordingly.


9	At the end of image analysis, <i>Img Proc ACT</i> is set to 0 again and the new <i>Results*</i> are output. At the same time, the <i>D -> C HS Flag</i> is changed (for PROFINET separately for the <i>Control & State</i> module and the <i>Result</i> module).
10	The receipt must be confirmed by changing <i>D -> C HS ACK</i> accordingly. With PROFINET, the confirmation must be made separately for the <i>Control & State</i> module and the <i>Result</i> module.
11	Regardless of all events, <i>TRG</i> can be set to 0 again at any time (after receiving the confirmation for <i>TRG -> 1</i>). At the same time (or afterwards), the <i>C -> D HS Flag</i> must be changed.
12	Reception is confirmed by changing <i>C -> D HS ACK</i> accordingly.
	) * Results: Total Res Pass, Total Res Fail, Result Toggle Bit, Act Res Data Len, Res Data
	) ** Handshake signals (see chapter <i>Handshake</i>) Handshake for output data (controller to device) <i>C -> D HSWA ACT</i> : Activation handshake with confirmation <i>C -> D HSWA ACT ACK</i> : Confirmation for handshake activation with confirmation <i>C -> D HS Flag</i> : Handshake flag, inversion if new data valid <i>C -> D HS ACK</i> : Handshake Ack flag, is set to the value of <i>C -> D HS Flag</i> if new data has been accepted. Handshake for input data (device to controller) <i>D -> C HSWA ACT</i> : Activation of handshake with confirmation <i>D -> C HSWA ACT ACK</i> : Confirmation for handshake activation with confirmation <i>D -> C HS Flag</i> : Handshake flag, inversion if new data valid <i>D -> C HS ACK</i> : Handshake Ack flag, is set to the value of <i>D -> C HS Flag</i> if new data has been accepted.

Read process with Teach




1	To trigger an image acquisition with <i>Teach</i> , <i>TRG</i> and <i>Teach</i> are set to 1. It is also possible to set <i>Teach</i> before <i>TRG</i> (1b).
2	Receipt of the teach signal is acknowledged immediately by a corresponding output on <i>Teach Act</i> . If the teach signal is reset to 0 before a trigger is received, this is also acknowledged immediately (1c). No <i>Teach</i> is carried out on the next recorded image.
3	After receiving the trigger signal, <i>Image acquisition</i> begins. This first resets <i>Teach Act</i> to 0 and then sets <i>TRG RDY</i> to 0 and <i>Img Proc ACT</i> to 1.
4	At the end of <i>Image acquisition</i> , <i>TRG RDY</i> is set to 1 again and the actual <i>Image analysis</i> begins.
5	At the end of the <i>Image analysis</i> , <i>Img Proc ACT</i> is reset to 0 and the new <i>Results*</i> are output.
6	Regardless of all events, <i>TRG</i> and <i>Teach</i> can be reset to 0 at any time.
	)* Results: Total Res Pass, Total Res Fail, Result Toggle Bit, Act Res Data Len, Res Data

Set Parameters




1	To set new parameters, the corresponding data (<i>Parameters</i> and <i>Act Parameters Len</i>) are sent to the device.
2	The receipt of the data is immediately acknowledged with <i>State SP</i> -> 1.
3	If no <i>Image acquisition</i> or <i>Image analysis</i> is active, <i>TRG Ready</i> is immediately set to 0 and the transfer of the new parameters begins.
4	If <i>Image acquisition</i> or <i>Image analysis</i> is active, the transfer of the new parameters is delayed until <i>Image acquisition</i> and <i>Image analysis</i> have been completed. <i>TRG RDY</i> remains at 0 during this time (or is immediately set to 0).
5	When the transfer of the new parameters is complete, <i>State SP</i> is set to 2 (or 3 in the event of an error) and <i>TRG RDY</i> is set to 1.
6	The value of <i>State SP</i> can be reset to 0 at any time by changing the value of <i>Reset State SP</i> from 0 to 1.
	)*Results: Total Res Pass, Total Res Fail, Result Toggle Bit, Act Res Data Len, Res Data

Switch job



1	To select a new job, the corresponding <i>Job selection</i> is sent to the device.
2	The receipt of the new <i>Job selection</i> is immediately acknowledged with <i>State SJ</i> -> 1.
3	If no <i>Image acquisition</i> or <i>Image analysis</i> is active, <i>TRG RDY</i> is immediately set to 0 and loading of the new job begins.
4	If <i>Image acquisition</i> or <i>Image analysis</i> is active, the loading of the new job is delayed until <i>Image acquisition</i> and <i>Image analysis</i> are complete. <i>TRG RDY</i> remains at 0 during this time (or is immediately set to 0).
5	Once the new job has been loaded, <i>State SJ</i> is set to 2 (or 3 in the event of an error) and <i>TRG RDY</i> is set to 1.
6	The value of <i>State SJ</i> can be reset to 0 at any time by changing the value of <i>Reset State SJ</i> from 0 to 1.
	)* Results: Total Res Pass, Total Res Fail, Result Toggle Bit, Act Res Data Len, Res Data

Switching the operating mode



1	To switch to setup mode, the value of <i>Operating mode</i> is set to 1.
2	The receipt of the new <i>Operating mode</i> is immediately acknowledged with <i>State SM</i> -> 1.
3	If no <i>Image acquisition</i> or <i>Image analysis</i> is active, it is immediately set <i>TRG RDY</i> to 0 and switching to setup mode begins.
4	When the switchover to setup mode is complete, <i>State SM</i> is set to 2 (or to 3 in the event of an error). However, <i>TRG RDY</i> remains permanently off in setup mode.
5	In setup mode, <i>Image acquisition</i> can still be triggered with <i>TRG</i> 0 -> 1. When <i>Image acquisition</i> is started, <i>Img Proc Act</i> and <i>Operating mode</i> (IN) are set to 1.
6	At the end of <i>Image acquisition</i> , no <i>Image analysis</i> is started in setup mode, but <i>Img Proc Act</i> is immediately set to 1. There is also no result output. The <i>Results*</i> retain their old value.
7	To switch back to run mode, the value of <i>Operating mode</i> is set to 0.
8	The receipt of the new <i>Operating mode</i> is immediately acknowledged with <i>State SM</i> -> 1.
9	If <i>Image acquisition</i> or <i>Image analysis</i> is active, the <i>Operating mode</i> switchover is delayed until <i>Image acquisition</i> and <i>Image analysis</i> are complete. <i>TRG RDY</i> remains at 0 during this time (or is immediately set to 0).
10	When the switchover to run mode is complete, <i>State SM</i> is set to 2 (or to 3 in the event of an error) and <i>TRG RDY</i> are set to 1 and <i>Operating Mode</i> (IN) to 0.
11	The value of <i>State SM</i> can be reset to 0 at any time by changing the value of <i>Reset State SM</i> from 0 to 1.
	)* Results: Total Res Pass, Total Res Fail, Sub Res..., Alarm..., Result Toggle Bit, Act Res Data Len, Res Data

15.5.4 Data

There is a difference between the transfer of cyclical and non-cyclical data.

15.5.4.1 Cyclical data

Cyclical data is data that is sent between the devices and the PLC at regular intervals. The cycle is defined via the PLC configuration.

Cyclical data is grouped into different modules. The consistency of the data can only be ensured within a module. If multiple modules in the PLC are interconnected (e.g. new trigger data for each trigger), this must be taken into account.

For example, you must ensure that the trigger in the *control and status* module is triggered after the new trigger data in the *trigger data* module. This can be achieved by setting the HS flag at the correct time.

If the cyclical data changes, the corresponding reactions are triggered. If the handshake is used, this only happens when the handshake flag changes. When the connection is first established, actions are triggered for some data even if this data does not change.

Element	Behaviour on initial receipt
Trigger	Is not analysed, is only stored to detect changes
Teach	Is analysed, 0 received → deactivate teach, 1 received → activate teach
Operating Mode	Is analysed, 0 received → Run mode is triggered, 1 received → Configuration mode is triggered
Current job number	Is analysed, 0 received → no change, all other values → switch to the given job
Reset Statistics	Is not analysed, is only stored to detect changes
Reset State SJ	Is not analysed, is only stored to detect changes
Reset State SP	Is not analysed, is only stored to detect changes
Reset State SM	Is not analysed, is only stored to detect changes
SetParam	"Immediately" used
TriggerData	"Immediately" used, data is scheduled for next image acquisition

Below there is a description of the individual data elements that could be exchanged in different compilations depending on the protocol used.

15.5.4.2 Group: Control and status

This group gives you access to Control (e.g. trigger, teach), Job number (switching between jobs), State (e.g. status of the job changeover) and Job result (results of the feature checks) and alarms.

Data element	Direction	Type	Length (byte)	Description
Device controller	PLC → device	UINT8	1	Control word
				Bit 0 Trigger (switching from 0 -> 1 triggers image acquisition), corresponds with the "TR" process interface command
				Bit 1 Teach (if 1 is triggered during image acquisition, Teach is carried out), corresponds with the "TE" process interface command
				Bit 2 Operating mode (switching from 0 -> 1 switches to Configuration mode, switching from 1 -> 0 switches to run mode), corresponds with the "SM" process interface command
				Bits 3..7 Reserved (always 0)
Job selection	PLC → device	UINT8	1	Current job number (changing triggers job switching, job number eff. 0x01..0xFF, 0x00 -> does not trigger job switching ("Inactive"), corresponds with the "SJ" process interface command
Reset statistics	PLC → device	UINT8	1	Reset statistics (changing triggers a statistics reset for the corresponding job number, eff. 0x01..0xFF, 0x00 -> does not trigger a statistics reset ("Inactive"), corresponds with the "CS" process interface command
Reset status (actions)	PLC → device	UINT8	1	Resets the status for various actions
				Bit 0 Reset job switching status (changing from 0 -> 1 triggers a reset if the status is not "in progress")
				Bit 1 Reserved (always 0)
				Bit 2 Reset SetParam status (changing from 0 -> 1 triggers a reset if the status is not "in progress")
				Bit 3 Reserved (always 0)
				Bit 4 Reset mode switching status (changing from 0 -> 1 triggers a reset if the status is not "in progress")
				Bit 5..7 Reserved (always 0)

Data element	Direction	Type	Length (byte)	Description
Device status	Device ➡ PLC	UINT8	1	Status word, corresponds with the "GS" process interface command
				Bit 0 TRG ready 0: Trigger not permitted, 1: Trigger permitted
				Bit 1 Teach 0: Teach will not be carried out with the next image recorded 1: Teach will be carried out with the next image recorded
				Bits 2..3 Mode 0: Run mode 1: Configuration mode 2: Test mode
				Bit 4 ImgProcAct 0: Image acquisition/analysis not active 1: Image acquisition/analysis active
				Bits 5..7: Reserved (always 0)
Current job number	Device ➡ PLC	UINT8	1	Current job number 1..255 0: if not in run mode or if job switching is active, corresponds with the "GS" process interface command
Thermal state	Device ➡ PLC	UINT8	1	The device's current thermal state (capacity in percent), corresponds to the "GT" process interface command
Action status	Device ➡ PLC	UINT8	1	Status for various actions, corresponds with the "GS" process interface command
				Bits 0..1 Job switching status 0: idle (no request pending), 1: in progress 2: completed successfully 3: completed with errors
				Bits 2..3 SetParam status 0: idle (no request pending) 1: in progress 2: completed successfully 3: completed with errors
				Bits 4..5 SwitchMode status 0: idle (no request pending), 1: in progress 2: completed successfully 3: completed with errors
				Bit 6..7 Reserved (always 0)

Data element	Direction	Type	Length (byte)	Description
Job results	Device ➔ PLC	UINT32	4	1 bit "Pass" and 1 bit "Fail" for each total and partial result, if both bits=0 -> no result available
				Bit 0 1 if the total result = "Pass", otherwise 0
				Bit 1 1 if the total result = "Fail", otherwise 0
				Bit 2 1 if a process alarm was produced during image analysis (details -> ProcessAlarm), otherwise 0
				Bit 3 Result toggle bit - always changes when a new result is available
				Bits 4..15 Reserved (always 0)
				Bit 16 1 if partial result 1 = "Pass", otherwise 0
				Bit 17 1 if partial result 1 = "Fail", otherwise 0
				Bit 18 1 if partial result 2 = "Pass", otherwise 0
				Bit 19 1 if partial result 2 = "Fail", otherwise 0
				Bit 20 1 if partial result 3 = "Pass", otherwise 0
				Bit 21 1 if partial result 3 = "Fail", otherwise 0
				Bit 22 1 if partial result 4 = "Pass", otherwise 0
				Bit 23 1 if partial result 4 = "Fail", otherwise 0
				Bit 24 1 if partial result 5 = "Pass", otherwise 0
				Bit 25 1 if partial result 5 = "Fail", otherwise 0

Data element	Direction	Type	Length (byte)	Description
Device alarms	Device ➔ PLC	UINT32	4	Process alarms in terms of device functionality: Each "total" and "alarm type" is 1 bit: "Alarm pending"
				Bit 0 1 if any process alarm is pending, otherwise 0
				Bit 1 1 if the "invalid trigger" alarm is pending, otherwise 0
				Bit 2 1 if the "output time exceeded" alarm is pending, otherwise 0
				Bit 3 1 if the "job selection error" alarm is pending, otherwise 0
				Bit 4 1 if the "process interface error" alarm is pending, otherwise 0
				Bit 5 1 if the "FTP client was unable to send all data" alarm is pending, otherwise 0
				Bit 6 1 if the "buffer overflow" alarm is pending, otherwise 0
				Bit 7 1 if the "pipeline overflow" alarm is pending, otherwise 0
				Bit 8 1 if the "handshake error" alarm is pending, otherwise 0
				Bits 9..31 Reserved (always 0)

15.5.4.3 Group: Result data

This group is used to transfer the result data from job processing. The results datagram is configured during job creation in the *Application Suite* in the step *Configure interfaces* → *Output process interface*.

Versions are available with payload capacities of 4/8/16/32/64/128/250 bytes. You should choose the smallest possible version for the volume of data you expect to handle. An unnecessarily large selection reduces overall system performance.

The data corresponds to response to the "GD" command from the classic process interface.

Data element	Direction	Type	Length (byte)	Description
Actual length of the result data	Device ➡ PLC	UINT16	2	Length of data actually used in ResultData
Result data (<n> byte)	Device ➡ PLC	OCTET-STRING	4/8/16/32/64/128/250	Result data for job processing (data length corresponds with the selected module)

15.5.4.4 Group: Parameters

This group is used to transfer parameter data for the current job. It is configured during job creation in the Application Suite in the step *Configure interfaces* → *Input process interface*.

Depending on the protocol versions are available with payload capacities of 4/8/16/32/64/128/250 bytes. You should choose the smallest possible version for the volume of data you expect to handle. An unnecessarily large selection reduces overall system performance.

The data corresponds with the "SP" command in the classic process interface.

Data element	Direction	Type	Length (byte)	Description
Actual length of the parameters	PLC → device	UINT16	2	Length of data actually used in ParamData
Parameter (<n> byte)	PLC → device	OCTET-STRING	4/8/16/32/64/128/250	Parameter data for the current job

15.5.4.5 Group: Trigger data

This group is used to transfer the data that will be assigned to the next trigger. Versions are available with payload capacities of 4/8/16/32/64/128 bytes. You should choose the smallest possible version for the volume of data you expect to handle. An unnecessarily large selection reduces overall system performance.

It is used in the same way as the TD command in the process interface for FTP and in the results datagram, the only difference being that new trigger data does not automatically trigger image acquisition. Here, image acquisition must be triggered with an additional trigger.

If the data is not deleted (payload length → 0), the data is used for each new image acquisition thereafter.

Data element	Direction	Type	Length (byte)	Description
Actual length of the trigger data	PLC → device	UINT8	1	Length of data actually used in TriggerData
Trigger data (<n> byte)	PLC → device	OCTET-STRING	4/8/16/32/64/128	Data that is assigned to the next trigger

15.5.4.6 Handshake

The different processing speeds of the devices in the network mean that it is often necessary to synchronise the flow of data between the devices at application level, and therefore ensure that the data is communicated.

There are two different handshake procedures available for this: the *simple handshake* and the *handshake with acknowledgement*.

15.5.4.6.1 Simple handshake

Each time new data is sent, the sender inverts the handshake flag (flag bit). The receiver can then detect that new data is being sent, even if the content of the data is the same.

Example: The same result is produced for each job analysis (e.g. identical grey value or the same distance is detected). The handshake flag shows that a new image has been analysed and its (unchanged) results is being sent.

General process for the simple handshake for input data for the PLC (status, result data):

1. The PLC activates the simple handshake (outgoing handshake activation for input data bit 0).
2. The Vision Sensor confirms the activation of the handshake (ingoing handshake activation for input data bit 0).
3. When it sends new data, the Vision Sensor inverts the handshake flag (ingoing handshake flag for input data bit 4). If new data is ready to be sent, it is sent immediately with the handshake flag inverted once again.
4. The inverted handshake flag (ingoing handshake flag for input data bit 4) tells the PLC that new data has arrived and it begins to process it. The PLC does not need to confirm the receipt of the data, and this would be ignored by the Vision Sensor.

General process for the simple handshake for output data for the PLC (control, parameters, trigger data):

1. The PLC activates the handshake (outgoing handshake activation for output data bit 0).
2. The Vision Sensor confirms the activation of the handshake (ingoing handshake activation for output data bit 0).
3. When it sends new data, the PLC inverts the handshake flag (outgoing handshake flag for output data bit 4). If new data is ready to be sent, it is sent immediately with the handshake flag inverted once again.
4. The inverted handshake flag (outgoing handshake flag for output data bit 4) tells the PLC that new data has arrived and it begins to process it. The Vision Sensor does not need to confirm the receipt of the data, and this can be ignored by the PLC.

15.5.4.6.2 Handshake with acknowledgement

Each time new data is sent, the sender inverts the handshake flag (flag bit). The receiver sends the received handshake flag back to the sender. The sender can only send new data (with the handshake flag inverted once again) once it has received this acknowledgement. However, this mode reduces the amount of data that can be transferred simultaneously.

General process for the handshake with acknowledgement for input data for the PLC (status, result data):

1. The PLC activates the handshake (outgoing handshake activation for input data bit 1).
2. The Vision Sensor confirms the activation of the handshake (ingoing handshake activation for input data bit 1).
3. When it sends new data, the Vision Sensor inverts the handshake flag (ingoing handshake flag for input data bit 4) and waits for receipt of the acknowledgement (outgoing handshake act. flag for input data bit 4). If new data is ready to send, it remains in a pipeline.
4. The inverted handshake flag (ingoing handshake flag for input data bit 4) tells the PLC that new data has arrived and it begins to process it. It confirms receipt of the data by sending the received handshake flag back as an acknowledgement (outgoing handshake act. flag for input data bit 4).
5. The Vision Sensor detects the acknowledgement (outgoing handshake flag for input data bit 4) and therefore that the data has been received, and can now send new data and invert the handshake act. flag again.

General process for the handshake with acknowledgement for output data for the PLC (control, parameters, trigger data):

1. The PLC activates the handshake (outgoing handshake activation for output data bit 1).
2. The Vision Sensor confirms the activation of the handshake (ingoing handshake activation for output data bit 1).
3. When it sends new data, the PLC inverts the handshake flag (outgoing handshake flag for output data bit 4) and waits for receipt of the acknowledgement (ingoing handshake act. flag for output data bit 4). If new data is ready to be sent, there is the option to retain or discard the data as required.
4. The inverted handshake flag (outgoing handshake flag for output data bit 4) tells the Vision Sensor that new data has arrived and it begins to process it. It confirms receipt of the data by sending the received handshake flag back as an acknowledgement (ingoing handshake act. flag for output data bit 4).
5. The PLC detects the acknowledgement (ingoing handshake act. flag for output data bit 4) and therefore that the data has been received, and can now send new data and invert the handshake flag again.

15.5.4.6.3 Data elements for handshake

Data element	Direction	Type	Length (byte)	Description
Handshake for Input data from the controller (Output: Activation and HS ACK)	PLC → device	UINT8	1	Handshake for input data
				Bit 0 1 if "simple" handshake should be activated, otherwise 0
				Bit 1 1 if handshake with acknowledgement should be activated, otherwise 0
				Bits 2..3 Reserved (always 0)
				Bit 4 Handshake act. flag - must always be set to the value of the most recent handshake flag received therefore acknowledges receipt for the device (if handshake with acknowledgement is activated)
				Bits 5..7 Reserved (always 0)
Handshake for Input data from the controller (Input: ACK for activation and HS control)	Device → PLC	UINT8	1	Handshake for input data
				Bit 0 1 if "simple" handshake was activated (ACK for activation), otherwise 0
				Bit 1 1 if handshake with acknowledgement was activated (ACK for activation), otherwise 0
				Bits 2..3 Reserved (always 0)
				Bit 4 Handshake flag - is inverted by the device simultaneously or after each new, valid piece of data is sent and signals with the edge that this data can be transferred (if handshake is activated)
				Bits 5..7 Reserved (always 0)

Data element	Direction	Type	Length (byte)	Description
Handshake for output data from the controller (Output: Activation and HS control)	PLC → device	UINT8	1	Handshake for output data
				Bit 0 1 if "simple" handshake should be activated, otherwise 0
				Bit 1 1 if handshake with acknowledgement should be activated, otherwise 0
				Bits 2..3 Reserved (always 0)
				Bit 4 Handshake flag is inverted by the device simultaneously or after each new, valid piece of data is sent and signals with the edge that this data can be transferred (if handshake is activated)
				Bits 5..7 Reserved (always 0)
Handshake for output data from the controller (Input: ACK for activation and HS ACK)	Device → PLC	UINT8	1	Handshake for output data
				Bit 0 1 if "simple" handshake was activated (ACK for activation), otherwise 0
				Bit 1 1 if handshake with acknowledgement was activated (ACK for activation), otherwise 0
				Bits 2..3 Reserved (always 0)
				Bit 4 Handshake flag ACK - must always be set to the value of the most recent handshake flag received therefore acknowledges receipt for the controller (if handshake with acknowledgement is activated)
				Bits 5..7 Reserved (always 0)

15.5.5 PROFINET

15.5.5.1 LEDs on the Vision Sensor



LED	Meaning
LINK / ACT	Indicates that the Vision Sensor is connected to a network. - On: Network connection established - Blinking: Data traffic active
NET RUN	Indicates that data is being transferred via Profinet. - Off: Profinet will not be used - Long blinking: Waiting for first cyclical connection - On: Cyclical connection active - Short blinking: Cyclical connection ended (waiting for next connection) 3 seconds of regular blinking: Device identification in the system

15.5.5.2 Cabling

Follow the general rules for cabling Industrial Ethernet.

Use a shielded cable for data transfer. The maximum cable length is 100m. Make sure during cable assembly that the cable shield is properly connected with the connector housing.

15.5.5.3 Connection to the PLC

The following section describes how to connect a Vision Sensor to a PLC. Connection of a *Siemens CPU 1516-3 PN/DP* with *TIA Portal v14 SP1* software is used as an example.


15.5.5.3.1 Determining a permanent IP address and name for the Vision Sensor

The Vision Sensor no longer visible in the PROFINET device list once it is connected to the PLC, since data transmission via PROFINET is disabled in the Vision Sensor's factory settings.

This section explains how PROFINET is enabled, a persistent IP address is assigned and a device name is determined for the Vision Sensor.


1. After connecting the Vision Sensor to the PLC, the *Accessible devices* dialogue contained in the Siemens PLC software package can be used to monitor whether the connected Vision Sensor is visible.

It is not, since the factory settings mean that PROFINET is disabled in the Vision Sensor.




2. Open the *Application Suite*.
3. Connect to the desired Vision Sensor.
4. Switch to *Configuration* operating mode.
5. Open the *Device settings* → *process interface*.


6. Select the PROFINET protocol.



7. Reset the network settings to the initial state.



8. Restart the Vision Sensor.



NOTE




It is not essential to reset the network settings to the initial state. A normal PROFINET device does not have any IP address (0.0.0.0) in the factory settings and the IP address is (permanently or temporarily) assigned by the PLC.

The *Application Suite* → *Device settings* or the Siemens PLC software package can always be used to configure the PROFINET network and device name settings.


9. The *Accessible device* dialogue can now be used to find the Vision Sensor without an IP address.

Although it is still necessary to assign a permanent IP address and a device name.




10. You have to open *Non-grouped devices* and use the TIA project to click on the Vision Sensor and *Online & Diagnostics* to assign a permanent IP address and a device name for the Vision Sensor.

Determine the *IP address* and *subnet mask* for the Vision Sensor.




11. Click *Assign PROFINET device name* and assign a chosen name for the Vision Sensor.

The data will be saved in the Vision Sensor's flash memory and the Vision Sensor will immediately be reconfigured.



12. The *Accessible devices* dialogue will now show the Vision Sensor with its new IP address and device name.




15.5.5.3.2 Installation of the GSD file

Integrating the Vision Sensor into the PLC project requires installation of a product-specific driver (GSD file).


Data organisation in PROFINET is module-based. The product-specific driver describes which modules are being offered.

Follow the next instructions to install the driver.

1. Open the Siemens GSD file manager.



2. Select the device description file to be installed.



Storage location of the device description file after installation of the *Application Suite*


<Installation path>\Industrial_Ethernet\PROFINET

Device description file


GSDML-V2.32-Baumer-VeriSens-[date]-[time].xml

Download the device description file under: <https://baumer.com/asset/1823249>

3. The device description file has now been installed.




4. All of the Vision Sensors will be available in the catalogue after a brief waiting period (the hardware catalogue is being updated).





15.5.5.3.3 Integration of the device into the PLC project

Follow the next instructions to integrate the Vision Sensor into the PLC project.


1. Use drag & drop to move the Vision Sensor onto the PROFINET subsystem.



2. Assign the Vision Sensor to the correct PROFINET network group.




3. Access the properties and enter the correct name for the Vision Sensor and its stipulated IP address.



4. Configure the PROFINET cycle time (4 ms is advisable) in which data is to be transmitted.

The shortest period supported by Vision Sensor is 4 ms.



Shorter periods reduce the computing power available for feature checking in the Vision Sensor and thus analysis performance. Longer periods increase the delay during analysis of received data and when transmitting result data and thus reduce response performance.

The period you choose will therefore be a compromise between these factors.

5. Configure the data structure to be transmitted.



You can connect up to four modules. These modules must be plugged into certain, predefined slots:

Slots	Module
1	Control and status
2	Result data (selection of the user data size)
3	Parameters (selection of the user data size)
4	Trigger data (selection of the user data size)

You can leave out individual modules. For example, only the *control* and *status* module and the result data module may be connected.


6. Configure the correct data input / output address range in the PLC process map.

→ The Vision Sensor has now been installed.





7. The project has to be compiled to test data transmission.

Click on the corresponding icon to do this.



8. Load the complete project into the PLC.


Switch the PLC to run mode.



15.5.5.3.4 Configuring the Application Suite


1. Open the *Application Suite* and create a new job with any chosen feature check.

Configure the process interface message that is to be transmitted to the PLC.




2. Save the job on the Vision Sensor.

Activate the Vision Sensor.



3. The process interface message will be sent to the PLC and the sent data can be monitored via *Watch table*.



15.5.5.4 Vision Sensor alarm

A PROFINET diagnosis alarm is triggered by the Vision Sensor for certain errors. An error code (a 32 bit value) is then transmitted. It is possible for multiple alarms to be triggered simultaneously.

The alarms are reset once the source of the error has been rectified.

Error code	Error description
Bit 0	Data buffer overrun: The amount of data produced by the Vision Sensor (e.g. result data) is larger than can be received by the module intended.
Bit 1	Pipeline overflow: The internal buffer for data output is full, the data was sent too slowly via PROFINET (or not at all).
Bit 2	Handshake error: The handshake mechanism was not used correctly, e.g. acknowledgement without a corresponding request being sent.
Bit 3	0 no thermal warning 1 thermal warning
Bit 4	0 no thermal shutdown 1 thermal shutdown Shutdown of the device has occurred.

15.5.5.5 Depiction of the data elements on the PROFINET module

The following tables provide a brief overview of the arrangement of data elements in the individual modules.

15.5.5.5.1 Module: Control and status

Input data (device → PLC)

Byte	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
0	Handshake for output data	pad (0)			C -> D HS ACK	pad (0)		C -> D HSWA ACT ACK	C -> D HSS ACT ACK	
1	Handshake for input data	pad (0)			D -> C HS Flag	pad (0)		D -> C HSWA ACT ACK	D -> C HSS ACT ACK	
2	Device status	pad (0)			Img Proc ACT	Operating Mode		Teach ACT	TRG RDY	
3	Current job number	Active job number								
4	Thermal state	Thermal state								
5	Action status	pad (0)		Status SM		Status SP		Status SJ		
6	Job results	pad (0)							Sub Res 5 Fail	Sub Res 5 Pass
7		Sub Res 4 Fail	Sub Res 4 Pass	Sub Res 3 Fail	Sub Res 3 Pass	Sub Res 2 Fail	Sub Res 2 Pass	Sub Res 1 Fail	Sub Res 1 Pass	
8		pad (0)								
9		pad (0)				Result Toggle Bit	Alarm	Total Res Fail	Total Res Pass	
10	Device alarms	pad (0)								
11		pad (0)								
12										Alarm PIF HS Err
13		Alarm PIF Pipe OV	Alarm PIF Buf OV	Alarm FTP	Alarm PIF	Alarm Inv Job	Alarm Output Timeout	Alarm Inv TRG	Alarm (Any)	

Output data (PLC → device)

Byte	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Handshake for output data	pad (0)			C -> D HS Flag	pad (0)		C -> D HSPA ACT	C -> D HSS ACT
1	Handshake for input data	pad (0)			D -> C HS ACK	pad (0)		D -> C HSPA ACT	D -> C HSS ACT
2	Device controller	pad (0)					Operating mode	Teach	TRG
3	Job selection	Select job number							
4	Reset statistics	Reset statistics							
5	Reset status (actions)	pad (0)			Reset State SM	pad (0)	Reset State SP	pad (0)	Reset State SJ

15.5.5.5.2 Module: Result data

Input data (device ➡ PLC)

Byte	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Handshake for input data	pad (0)			D -> C HS Flag	pad (0)		D -> C HSSWA ACT ACK	D -> C HSS ACT ACK
1 ... 2	Actual Length Result data	Act Res Data Len							
3 ...	Result data	Result data (4/8/16/32/64/128/250 byte)							

Output data (PLC ➡ device)

Byte	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Handshake for input data	pad (0)			D -> C HS ACK	pad (0)		D -> C HSWA ACT	D -> C HSS ACT

15.5.5.5.3 Module: Parameters

Input data (device ➡ PLC)

Byte	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Handshake for output data	pad (0)			C -> D HS ACK	pad (0)		C -> D HSWA ACT ACK	C -> D HSS ACT ACK

Output data (PLC ➡ device)

Byte	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Handshake for output data	pad (0)			C -> D HS Flag	pad (0)		C -> D HSSWA ACT	C -> D HSS ACT
1 ... 2	Actual length of the Parameters	Act Parameters Len							
3 ...	Parameters	Parameters (4/8/16/32/64/128/250 byte)							

15.5.5.5.4 Module: Trigger data

Input data (device → PLC)


Byte	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Handshake for output data	pad (0)			C -> D HS ACK	pad (0)		C -> D HSWA ACT ACK	C -> D HSS ACT ACK

Output data (PLC → device)

Byte	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Handshake for output data	pad (0)			C -> D HS Flag	pad (0)		C -> D HWSA ACT	C -> D HSS ACT
1	Actual length of the trigger data	Act Trigger Data Len							
2 ...	Trigger data	Trigger data (4/8/16/32/64/128 byte)							

15.5.5.5.5 Example

The following examples provide a depiction of the mapping of data elements in memory for two module configurations.



Number	Description																																												
1	PLC																																												
2	PLC programme																																												
3	PLC process map Example 1 Simple configuration – use of the "Control and status" and "Result data (32 bytes)" modules with selected start address 1000 / 500 (start addresses subject to overall configuration). Vision Sensor input data device ➔ PLC <table><tr><th colspan="2">Control and status</th><th colspan="2">Result data</th></tr><tr><td>Start address: 1000</td><td>Start address + 13</td><td>Start address + 14</td><td>Start address + 48</td></tr></table> Vision Sensor output data PLC ➔ device <table><tr><th colspan="2">Control and status</th><th>Result data</th></tr><tr><td>Start address: 500</td><td>Start address + 5</td><td>Start address + 6</td></tr></table> Example 2 Extensive configuration – use of the "Control and status", "Result data (250 byte)", "Parameters (128 byte)" and "Trigger data (64 byte)" modules with selected start address 200 / 100 (start addresses subject to overall configuration). Vision Sensor input data PLC ➔ device <table><tr><th colspan="2">Control and status</th><th colspan="2">Result data</th><th>Parameters</th><th>Trigger data</th></tr><tr><td>Start address: 200</td><td>Start address + 13</td><td>Start address + 14</td><td>Start address + 252</td><td>Start address + 253</td><td>Start address + 254</td></tr></table> Vision Sensor output data device ➔ PLC <table><tr><th colspan="2">Control and status</th><th>Result data</th><th colspan="2">Parameters</th><th>Trigger data</th></tr><tr><td>Start address: 100</td><td>Start address + 5</td><td>Start address + 6</td><td>Start address + 7</td><td>Start address + 137</td><td>Start address + 138</td></tr><tr><td></td><td></td><td></td><td></td><td></td><td>Start address + 203</td></tr></table>	Control and status		Result data		Start address: 1000	Start address + 13	Start address + 14	Start address + 48	Control and status		Result data	Start address: 500	Start address + 5	Start address + 6	Control and status		Result data		Parameters	Trigger data	Start address: 200	Start address + 13	Start address + 14	Start address + 252	Start address + 253	Start address + 254	Control and status		Result data	Parameters		Trigger data	Start address: 100	Start address + 5	Start address + 6	Start address + 7	Start address + 137	Start address + 138						Start address + 203
Control and status		Result data																																											
Start address: 1000	Start address + 13	Start address + 14	Start address + 48																																										
Control and status		Result data																																											
Start address: 500	Start address + 5	Start address + 6																																											
Control and status		Result data		Parameters	Trigger data																																								
Start address: 200	Start address + 13	Start address + 14	Start address + 252	Start address + 253	Start address + 254																																								
Control and status		Result data	Parameters		Trigger data																																								
Start address: 100	Start address + 5	Start address + 6	Start address + 7	Start address + 137	Start address + 138																																								
					Start address + 203																																								
4	Device																																												

15.5.6 EtherNet/IP™

15.5.6.1 LEDs on the Vision Sensor



LED	Meaning
LINK / ACT	Indicates that the Vision Sensor is connected to a network. - On: Network connection established - Blinking: Data traffic active
NET RUN	Indicates that data is being transferred via Ethernet/IP. - Off: Ethernet/IP will not be used - Long blinking: Waiting for first cyclical connection - On: Cyclical connection active - Short blinking: Cyclical connection ended (waiting for next connection)

15.5.6.2 Cabling

Follow the general rules for cabling Industrial Ethernet.

Use a shielded cable for data transfer. The maximum cable length is 100m. Make sure during cable assembly that the cable shield is properly connected with the connector housing.

15.5.6.3 Ethernet/IP™ object classes and instances

When using the EtherNet/IP™ protocol, access to object classes and instances is supported by non-cyclical access methods („explicit messaging”).

The Vision Sensor supports the following general objects:

Class	Number of instances
0x01: Identification object	1
0x02: Message router object	1
0x04: Assembly object	2
0x06: Connection manager object	1
0xF4: Port object	2
0xF5: TCP/IP interface object	1
0xF6: EtherNet link object	2

The payloads from the connected devices are assigned to the assembly object instances as follows:

Instance	Type	Content	Size (bytes)
109	Output (O -> T)	Data from the PLC to device	203
110	Input (T -> O)	Data from device to PLC	150

Acyclic access is possible for all these objects. Although cyclical connections ("implicit messaging") are generally recommended.

15.5.6.4 Connection to the PLC

The following section describes how to connect a Vision Sensor to a PLC. Connection to an *Allen Bradley Compact Logix L16ER* with *Studio 5000* software serves as an example.


15.5.6.4.1 Determining a permanent IP address and name for the Vision Sensor

The Vision Sensor is not visible in the EtherNet/IP device list once it is connected to the PLC, since data transmission via EtherNet/IP is disabled in the Vision Sensor's factory settings.

This section describes how a persistent IP address is assigned and a device name determined for the Vision Sensor.


1. After connecting the Vision Sensor to the PLC, the *RSLinx* contained in the Rockwell software package can be used to monitor whether the connected Vision Sensor is visible.

It is not, since the factory settings mean that EtherNet/IP is disabled in the Vision Sensor.




2. Open the *Application Suite*.
3. Connect to the desired Vision Sensor.
4. Switch to *Configuration* operating mode.
5. Open the *Device settings* → *process interface*.

6. Select the *Ethernet/IP* protocol.




7. Open the *IP address / network*.

Determine the *IP address* and *subnet mask* for the Vision Sensor.




8. Restart the Vision Sensor.



9. The *RSLinx* will now find the Vision Sensor with the recently determined IP address as an unknown device.

This Vision Sensor is unknown to the PLC, since a driver has not been installed.



15.5.6.4.2 Installation with EDS file

Data organisation is based on assembly objects in Ethernet/IP™.


The available data and predefined connections are described in the EDS file (device description file).

When integrating the vision sensor into the PLC project, it is possible to configure the necessary settings by installing an EDS file.


Follow the next instructions to install the EDS file.

1. Open *Studio 5000*, which is available in the Rockwell software package.


Start the *EDS Hardware Installation Tool*.



2. Follow the instructions provided by the *Rockwell Automation EDS Wizard*.



3. Select the device description file to be installed.



Storage location of the device description file after installation of the *Application Suite*:


<Installation path>\Industrial_Ethernet\EtherNetIP

Device description file:


Baumer_EIP_VeriSens.eds

Download the device description file under: <https://baumer.com/asset/1823248>

3. Follow the other steps and complete installation of the EDS file.



4. Open *RSLinx* again and the Vision Sensor is now displayed as a correctly detected device.




15.5.6.4.3 Integration of the Vision Sensor into the PLC project


Follow the next instructions to integrate the Vision Sensor into the PLC project.

1. Open the project in *Rockwell Studio 5000 Logix Designer*.

Right click on Ethernet and select *New module* to create a new module for the I/O configuration.




2. Search and create the corresponding module in the catalogue.



3. Enter a name for the Vision Sensor.

Enter the determined IP address for the Vision Sensor.

→ The Vision Sensor has now been installed.



4. Move to the *Connection* tab.


Now configure the EtherNet/IP cycle time (4 ms is advisable) in which data is to be transmitted.

The shortest period supported by Vision Sensor is 4 ms.

Shorter periods reduce the Vision Sensor's computing power available for feature checking and thus its evaluation performance.


Longer periods increase the time taken for evaluation of received data and sending result data and thus reduce response performance.

The period you choose will therefore be a compromise between these factors.



5. The project has to be loaded into the PLC to test data transmission.


Switch the PLC to run mode.



15.5.6.4.4 Configuring the Application Suite


1. Open the *Application Suite* and create a new job with any chosen feature check.

Configure the process interface message that is to be transmitted to the PLC.



2. Save the job on the Vision Sensor.


Activate the Vision Sensor.



3. The process interface message will be sent to the PLC and the sent data can be monitored via *Controller tags*.

NOTE

In order to ensure data consistency in the PLC, we recommend the use of the CPS (Synchronous Copy File) command when planning using the Rockwell planning software.



15.5.6.5 Additional data elements

Since Ethernet/IP™ does not provide a mechanism for spontaneous transmission of asynchronous results from the device to the PLC, similar to the alarm mechanism in PROFINET, such events are made available in an additional data element:

Data element	Direction	Type	Length (byte)	Description
Alarms	Device ➡ PLC	UINT32	4	Process alarms in terms of device functionality
				Bit 0 1 in the event of data buffer overflow: The amount of data produced by the Vision Sensor (e.g. result data) is larger than can be received by the module intended., otherwise 0
				Bit 1 1 in the event of pipeline overflow: The internal buffer for data output is full, the data was sent too slowly via PROFINET (or not at all), otherwise 0
				Bit 2 1 in the event of handshake error: The handshake mechanism was not used correctly, e.g. acknowledgement without a corresponding request being sent, otherwise 0
				Bit 3 0 no thermal warning 1 thermal warning
				Bit 4 0 no thermal warning 1 thermal shutdown Shutdown of the device has occurred.
				Bits 5..31 Reserved (always 0)

15.5.6.6 Depiction of the data elements on the assembly instances

For EtherNet/IP™ there is no option available for selecting the payload size of the data elements "Result data", "Parameters" and "Trigger data". The payload size of the data elements "Result data" and "Parameters" is always 128 bytes and for "Trigger data" 64 bytes.

The data attribute (0x03) of the assembly object instance (109-110) should normally be accessed via cyclical I/O connections ("implicit messaging").

The following tables describe the mapping of data elements in memory.

Input data (device → PLC) target (T) to (originator (O), assembly instances 110):

Byte	Group	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
0	Alarms	Alarms	pad (0)								
1			pad (0)								
2			pad (0)								
3			pad (0)			Thermal shutdown	Heat warning	Handshake error	Pipeline overflow	Buffer overflow	
4	Control and status	Device status	pad (0)			Img Proc ACT	Operating Mode		Teach ACT	TRG RDY	
5		Current job number	Active job number								
6		Thermal state	Thermal state								
7		Action status	pad (0)		Status SM		Status SP		Status SJ		
8		Job results	pad (0)				Result Toggle Bit	Alarm	Total Res Fail	Total Res Pass	
9			pad (0)								
10			Sub Res 4 Fail	Sub Res 4 Pass	Sub Res 3 Fail	Sub Res 3 Pass	Sub Res 4 Fail	Sub Res 4 Pass	Sub Res 3 Fail	Sub Res 3 Pass	
11			pad (0)						Sub Res 5 Fail	Sub Res 5 Pass	
12		Device alarms	Alarm PIF Pipe OV	Alarm PIF Buf OV	Alarm FTP	Alarm PIF	Alarm Inv Job	Alarm Output Timeout	Alarm Inv TRG	Alarm (Any)	
13											Alarm PIF HS Err
14			pad (0)								
15			pad (0)								
16		Handshake for output data	pad (0)			O -> T HS ACK	pad (0)		O -> T HSWA ACT ACK	O -> T HSS ACT ACK	
17		Handshake for input data	pad (0)			T -> O HS Flag	pad (0)		T -> O HSWA ACT ACK	T -> O HSS ACT ACK	
18	Result data	Actual Length Result data									
19 ... 146		Result data	Result data (128 byte)								
147		Handshake for input data	pad (0)			T -> O HS Flag	pad (0)		T -> O HSWA ACT ACK	T -> O HSS ACT ACK	
148	Parameters	Handshake for output data	pad (0)			O -> T HS ACK	pad (0)		O -> T HSWA ACT ACK	O -> T HSS ACT ACK	
149	Trigger data	Handshake for output data	pad (0)			O -> T HS ACK	pad (0)		O -> T HSWA ACT ACK	O -> T HSS ACT ACK	

Output data (PLC → device) (originator (O) to target (T), assembly instance 109):

Byte	Group	Data element	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Control and status	Device controller	pad (0)					Operating mode	Teach	TRG
1		Job selection	Select job number							
2		Reset statistics	Reset statistics							
3		Reset status (actions)	pad (0)		Reset State SM	pad (0)	Reset State SP	pad (0)	Reset State SJ	
4		Handshake for output data	pad (0)		O -> T HS Flag	pad (0)		O -> T HSWA ACT	O -> T HSS ACT	
5		Handshake for input data	pad (0)		T -> O HS ACK	pad (0)		T -> O HSWA ACT	T -> O HSS ACT	
6	Result data	Handshake for input data	pad (0)		T -> O HS ACK	pad (0)		T -> O HSWA ACT	T -> O HSS ACT	
7	Parameters	Actual length of the Parameters	Act Parameters Len							
8 ... 135		Parameters	Parameters (128 byte)							
136		Handshake for output data	pad (0)		O -> T HS Flag	pad (0)		O -> T HSWA ACT	O -> T HSS ACT	
137	Trigger data	Actual length of the trigger data	Act Trigger Data Len							
138 ... 201		Trigger data	Trigger data (64 byte)							
202		Handshake for output data	pad (0)		O -> T HS Flag	pad (0)		O -> T HSWA ACT	O -> T HSS ACT	

16 Use with UR (Universal Robots)

Vision sensors with Universal Robot support are designed and certified to retrofit UR3e, UR5e, UR10e and UR16e Universal Robots (UR) with image processing.

	ATTENTION!  Please observe the instructions and notes in the Universal Robots technical documentation!

Image processing supports the following use cases:

- The image-based feature check of objects supported by the UR
- The image-based finding of objects and transmission of the coordinates to the UR

The image processing task is configured via the *Application Suite* of the vision sensor.

The configuration software of the UR is functionally extended by the installation of the URCaps for the vision sensor. There are also some additional commands in the UR control available to select the inspection task or to use special waypoints whose coordinates are determined with the image processing.

Important UR robot control terms

Term	Meaning
PolyScope	Software for robot control and creation of UR programs.
Node	Step in the UR program, contains processing step or subroutine.
URCap	Additional software (plug-in) that allows UR to communicate with external accessories such as the vision sensor. URCap is installed on the UR via a USB stick.
Reference level	In relation to the Z axis, there are different heights, e.g. contact surface in the machine, top of the examination object, bottom <i>SmartGrid</i> , top <i>SmartGrid</i> . It may be easier to relate all heights to one level, e.g. the contact surface in the machine. This is the reference level.
Depth of field	Depending on the lens and design, the vision sensor captures a sharp image at a defined distance with a tolerance field up and down. This focus area is the depth of field. When arranging the <i>SmartGrid</i> , care should be taken to ensure that it is still in the depth of field even when <i>tilted</i> , in order to be detected, even if the <i>SmartGrid</i> is able to deal with certain blurs.
Distortion correction	Due to the physical lens distortion and oblique installation, the captured image differs from the original state, it is "distorted". The vision sensor is able to electronically equalise the image to match the undistorted ideal state.

16.1 Installation

In the following chapters, you will learn how to integrate the vision sensor into a robot environment and configure communication with the robot controller.

What else is needed in addition to the vision sensor?

The starter kit, which contains the following components, which are also available individually, is perfect:




- USB stick with URCap
- *SmartGrid* of the calibration surface 200 mm x 150 mm
- *SmartGrid* mounting bracket with two M6x8 screws
- UR mounting bracket for the vision sensor with four M6x18 and four M4x8 screws
- UR mounting plate for the vision sensor with four screws M6x18 and four M4x8
- Vision sensor connecting cable, 2 m, connection M12 12-pin with power supply unit 24 V / 1 A.
- Alternative terminating cable, 5 m, M12 connection 12 poles, robot-compatible with free cable end
- Ethernet cable, 5 m, robot-compatible
- Screwdriver I6K 3 mm

Additional accessories


- Screwdrivers for Torx screws (TX 30)

UR attachment


- (1) Offset Z
- (2) Reference level


UR mounting bracket for vision sensor

UR mounting plate for vision sensor



Centre of gravity of UR mounting bracket (235 g) for vision sensor




Centre of gravity of UR mounting plate (160 g) for vision sensor



SmartGrid with mounting bracket




SmartGrid on the flange of the robot



16.2 Quick installation

The following table gives you an overview of the installation procedure in short form. The following chapters explain these steps in more detail.

Step	Vision sensor with <i>Application Suite</i>	Universal Robot (UR)
1. Preparation: UR and vision sensor		
A		Install cap
B		Cap vision sensor installation ⇒ Call Tab 1
C	Mount the vision sensor on the robot or stationary on the machine	
D	Connect the vision sensor and integrate it in the UR network: Installing and commissioning the vision sensor	
E	Start <i>Install Application Suite</i> and establish connection to the vision sensor: Installation and initial set-up	
F	Activate robot mode (UR) <i>Device</i> → <i>Device settings</i> → <i>Robotics</i>	
G	Focus on the area to be examined	
Optional steps for using the distortion correction or coordinate transfer of objects		
H	Place the <i>SmartGrid</i> in the depth of field of the vision sensor	
I	Performing distortion correction <i>Device</i> → <i>Device settings</i> → <i>Distortion correction</i> (optional, necessary for coordinate transfer of found objects) ⇒ Do not adjust the focus of the vision sensor from now on	
J	Performing shading correction <i>Device</i> → <i>Device settings</i> → <i>Shading correction</i> (optional)	
K	Performing Z calibration (device dependent) <i>Device</i> → <i>Device settings</i> → Z calibration (optional, necessary for coordinate transfer of found objects)	
2. Performing set-up in URCap		
L		Cap vision sensor installation ⇒ Call Tab 2
M		Connect to the vision sensor.
Setup is now complete. Now a job can be created on the vision sensor and the results are passed as variables to the robot controller (UR).		
If object positions of the objects found by the vision sensor are to be transferred to the UR, then please perform the following steps as well.		
N		As preparation for Step 3, if vision sensor is installed dynamically: Move UR to test position Recommendation: Save position

3. Performing coordinate adjustment in URCap		
O		Check for Z calibration, otherwise repeat Step "K".
P		Selection: Choose the type of vision sensor assembly (dynamic or stationary).
Q		Selection: By default, the coordinate system should be set to "Base", otherwise it must be ensured that the Z-axis of the coordinate system has the same Z-axis as the <i>SmartGrid</i> .
R		For dynamically installed vision sensors: UR should be in the appropriate pose, the stored installation pose is optimal.
S		<u>Dynamic vision sensor:</u> Place the <i>SmartGrid</i> at object height, i.e. in the range of a good depth of field <u>Stationary vision sensor:</u> The <i>SmartGrid</i> is clamped in the robot and driven with it to the height of the object to be examined (optimum depth of field).
T		Since all height distances are referenced to a reference level, the distance from the top of the <i>SmartGrid</i> to the reference level must be entered here.
U		Press Initiate "coordinate adjustment"
V		Reduce the speed to approx. 15-20 %. Move to waypoints on the entire <i>SmartGrid</i> by following an imaginary rectangular contour (see illustration). Perform a rotation of approx. 15° at the respective corners. 
W		If the calibration quality is at least "good", you can complete the calibration.
X		Complete the calibration with "Complete".

16.3 Installation instructions

16.3.1 Preparation: UR and vision sensor

16.3.1.1 Preparation of the UR - installation of the URCap


For the UR (robot control) to communicate with the vision sensor, the URCap must be installed on the UR. The URCap contains the command sets and operating elements required for communication and operation, as well as corresponding plug-ins.



NOTE

For proper operation, PolyScope version ≥ 5.4 is required.

Insert the USB stick on which the URCap is supplied into the UR Teach Pendant.




Under *Settings*, select → *System* → *URCaps* → + the URCap file from the USB stick.

After successfully accepting the URCaps, click *Restart*.



NOTE

To uninstall a UCap, click - and select the URCap to uninstall.




After successful installation of the URCap, you must call the first step of the installation node.



NOTE

In the first step of the installation node, you will also find the most important steps up to successful installation as an overview.



The screenshot shows the URStudio software interface. The top toolbar includes icons for Run, Program, Installation, Move, I/O, and Log. The main window displays the 'VeriSens(R) Installation' node, which is expanded to show three steps: 1. Preparation and Guideline, 2. Set-up, and 3. Coordinate Alignment. The 'Preparation' step is currently selected and shows a list of instructions for mounting and connecting the VeriSens(R) sensor. The 'Set-up' and 'Coordinate Alignment' steps are also visible. The bottom status bar shows the robot is in 'Normal' mode, speed is at 100%, and simulation is disabled.

VeriSens(R) Installation

1. Preparation and Guideline

Preparation

- Mount VeriSens(R) and connect to network
- Start VeriSens(R) Application Suite and connect to VeriSens(R)
- Switch VeriSens(R) to robotics mode "Universal Robot"
- For dynamic mounting, bring UR into image acquisition pose
- Adjust VeriSens(R) focus to object
- Place SmartGrid in the field of depth of VeriSens(R)
- Proceed "Distortion correction" with the Application Suite (device settings)
- Proceed "Z Calibration" with the Application Suite (device settings)

Switch to "2. Set-up"

- Connect to relevant VeriSens(R)
- Dynamic mounting: store VeriSens(R) position (recommended)

Switch to "3. Coordinate Alignment"

- Ensure a valid Z Calibration of VeriSens(R) (LED is green)
- Place the SmartGrid in the field of depth (or keep it there from the steps above). In case of stationary VeriSens(R) mounting the SmartGrid needs to be fixed on the UR and placed in the field of depth
- Follow further instructions

2. Set-up

3. Coordinate Alignment

Normal Speed 100% Simulation

16.3.2 Mount the vision sensor on the robot or stationary on the machine

There are two options for the mechanical setup of the vision sensor:

Carrying the vision sensor with the robot ("dynamic") or stationary attachment of the vision sensor above the robot ("stationary").

Dynamic:

For attachment to the robot, a special mounting plate is provided. If the mounting space appears unfavourable, the Vision Sensor can alternatively be attached with a mounting bracket. When using the mounting bracket, depending on the gripper, an additional position, rotated by 90°, must be approached to take a picture. When mounting the vision sensor, also pay attention to the adaptation of the weight (gripper + vision sensor) to the TCP (Tool Center Point).

Route the cables in a suitable way over the robotic arm, for example using commercially available mounting kits or flexible cable ties.

ATTENTION!



Please note that the position range for wrist 3 should be limited to avoid cable twists (*Installation → Safety → Joint Limits*).

If an object is to be gripped in the application in any rotational position, this range must cover at least 0° to 360°. Since the other joint positions also have an influence, a larger range (e.g. -90° to 450°) is recommended, provided that the cable routing permits this.

Stationary:

Optimally mount the device in the centre of the area to be monitored and above the robot.

ATTENTION!



The robot could collide with and damage the stationary installed vision sensor or connected peripherals (e.g. cables).

During installation, observe the robot's freedom of movement and restrict it if necessary (*Safety → Levels*)!

NOTE




Since an image is helpful in mechanical setup, the later steps of the connection to the *Application Suite* can be provisionally anticipated here.

Installation type	Advantage	Disadvantage
Dynamic	• Allows the inspection of a larger area • It is also possible to approach coordinates in the space (X, Y, Z, redX, redY, redZ) for the feature check	• The accompanying vision sensor increases the space required by the robot in the area of the gripper • The weight of the vision sensor reduces the useful load capacity of the UR • Cable routing
Stationary	• Usually easier to install - both mechanically and electrically • No burden on the UR due to added weight and volume. • Higher freedom of UR movement, since no vision sensor is in the way.	• The UR arm covers part of the monitored area and, depending on the application, must first be moved out of the way

16.3.3 Installing and commissioning the vision sensor

To install the vision sensor, follow the instructions in Chapter: [Installation and initial set-up](#).

The vision sensor, the PC with the *Application Suite* and the UR robot controller must all be in the same subnetwork, e.g. connected by a hub or switch.



Number	Description
1	UR robot controller (For Setup see PolyScope Technical Documentation)
2	Vision sensor To set up the network connection, see Chapter: IP address / network
3	PC with <i>Application Suite</i> To set up the network connection, see Chapter: Initial set-up of the Ethernet interface on your computer
4	Switch / hub

16.3.4 Activating robotics mode in the vision sensor

Vision sensors with Universal Robot support have an additional operating mode that must be enabled for proper communication with the UR.

To activate Robotics mode, follow the instructions in Chapter: [Robotics \(device-dependent\)](#).

→ Now the vision sensor can communicate with UR and should display an image via Application Suite.

16.3.5 Shading correction (optional)

Uneven lighting can result in some areas of the image being darker than others.

Shading correction provides the option to compensate for brightness irregularities in the image.

Follow the instructions in Chapter: [Shading correction \(device dependend\)](#).

16.3.6 Distortion correction (optional)

The recorded images can be contorted by lens distortion or inclined positioning of the Vision Sensor.

The *Distortion correction* function can be used to compensate for these distortions .

Follow the instructions in Chapter: [Distortion correction \(device dependend\)](#).

**NOTE**

If the distortion correction is carried out with the calibration template, the world coordinates are automatically taught in and are thus available to the vision sensor for communication with UR.

16.3.7 Z calibration (optional)

Image processing is two-dimensional. However, in robotics, the Z-axis (depth) must also be taken into account, because robotics typically works in space. The Z-calibration allows the world coordinates of the vision sensor to be adjusted to a height Z and further processed by a robot.

Z calibration is necessary if object positions are to be found with the vision sensor and are to be passed on to the UR.

Follow the instructions in Chapter: [Z calibration \(device dependent\)](#).

**NOTE**

Do not adjust the focus of the vision sensor after the first calibration.

16.3.8 Set-up

**NOTE**

Changing the language in PolyScope may result in the installation of the vision sensor having to be repeated. It is therefore recommended to activate the desired language before performing the first installation steps.

Create a connection between the UR and the vision sensor.

There does not have to be a job on the vision sensor. However, it is important to activate Robotics mode via the *Application Suite* (*Device* → *Device settings* → *Robotics*).


Select the relevant device from the device list and press the *Connect* button. After some time, the *Connected* signal should light up green and you should also see the live image of the vision sensor.

**NOTE**

After loading an installation (*Open...* → *Installation*) it is necessary to reconnect to the Vision Sensor in order to adapt the dialog to the current device.

If the signal lights up yellow, the vision sensor is deactivated. It is possible that a test job is being configured on the vision sensor and configuration and saving is in progress. To ensure that the configuration is not lost, it should be completed via the *Application Suite*.

Regardless of this, the vision sensor can also be activated directly from the URCap. In the status of the yellow signal, the inscription of the button *Connect* changes to *Activate*. Pressing and confirming the confirmation prompt activates the vision sensor.



The prerequisite for finding and transferring object positions is the calibration of the vision sensor with the optional steps listed above (*Distortion correction, Z calibration*).

For dynamically installed vision sensors, it is recommended to save the position (pose) of the calibration position at this point at the latest.

Pose of vision sensor during installation

This is supported by the buttons *Save* and *Restore*. Possible applications for this are the re-calibration of the coordinates or the image acquisition from this optimal position.

Options

Automatic connection after startup

Here, an attempt is made to connect to the last selected vision sensor when the robot is powered up. The vision sensor may also have been renamed via *Application Suite*. The lighting settings below will be reactivated.

If no coordinates of found objects are to be passed on to the UR, then the vision sensor setup is completed here.

Internal illumination

It may be possible to improve the image quality during live viewing via the internal illumination during installation; it can be switched on here (not for vision sensors with C-mount interface).

External illumination

It may be possible to improve the image quality during live viewing via the external illumination during installation. This function can be activated here (if available).

You can now create a "job" (inspection task) on the vision sensor and also transfer the data to the UR - for example, to control the removal of defective parts by the robot.

The configuration of inspection tasks on the vision sensor is described in the Chapter [Creating a job](#).

Example program for the robot controller can be found in the Chapter [Example programs for the robot controller](#).



NOTE

Make sure that dimensions are distance-dependent; the vision sensor should always be in the same position and at the same distance from the test object.





NOTE

Please note the instructions for data transfer to the UR in the Chapter [Output Robotics \(device dependent\)](#).

16.3.9 Coordinate alignment

This step is necessary when transferring coordinates determined by the vision sensor to the UR robot controller - to find objects through image processing and to feed the nodes of the Vision Sensor based waypoints.





After calling the tab "3rd coordinate alignment", you must observe the two upper lines, which indicate the state of the vision sensor with regard to Z calibration and coordinate alignment. If both signals are green, a coordinate alignment has already taken place and the installation is complete.

If the first signal (Z calibration) is not active (grey signal), the Z calibration must first be performed in the *Application Suite* (see above).

If the second signal (coordinate alignment) is not active (grey signal) or you want to make changes to the installation of the vision sensor, proceed with the following entries.

Select the type of installation of the vision sensor:

- Dynamic, vision sensor is robot-guided or
- Stationary, vision sensor is stationary mounted

Robot coordinate system

Select "Base". If you want to use another coordinate system, then this must have the same orientation in the Z direction as the *SmartGrid* when teaching the distortion correction of the vision sensor.

Optional: Z offset to the reference level

If the X-Y plane of the robot coordinate system corresponds to the reference level, then the Z offset = 0. However, if the robot coordinate system is higher than the reference level, you can specify this distance here (Z offset > 0). If the robot coordinate system is lower than the reference level, then the Z offset is < 0.

Installation pose / adaptation Z-axis:

This selection is made depending on the selection according to the installation variant.

Selection with "dynamic, robot-guided":

Installation pose

The next two signals should be green to make sure the robot is in the correct pose. If it is not in the correct pose, you should correct the pose under Step "2. Set-Up".

Distance SmartGrid to the reference level

Now place the *SmartGrid* in the field of vision of the vision sensor. The *SmartGrid* must not be moved during the subsequent calibration process! If you have a difference from the top of the *SmartGrid* to the reference level (e.g. thickness of the *SmartGrid*), you can set this value here.

Selection with "stationary, not robotically guided"

Now mount the *SmartGrid* directly on the robot flange or grip it on the *SmartGrid* using a gripper and, if necessary, using the mounting bracket.

Z-axis adjustment


Here you should only make sure that the robot flange is aligned parallel to the *SmartGrid*. If not, the rotation of X and Y can be set to zero with a button. The corresponding signal should then light up. The key is that the *SmartGrid* aligns with the position that was present during calibration of the distortion correction on the Vision Sensor.

If desired, the height (Z direction) of the *SmartGrid* can still be adjusted.

Distance SmartGrid to the reference level

Measure the distance from the top of the *SmartGrid* to the reference level and enter this value here.

In the last step under "3rd Coordinate Alignment", start the coordinate alignment; this brings up a new screen.



Here, after a sufficient number of movements, you will see a bar graph showing the calibration quality. The goal should be to achieve at least a good calibration quality, but ideally an excellent one.

Move the Tool Center Point (TCP) so that at least two linear movements (at least 10 mm) and one rotation movement (at least 5 °) are performed. On the bar display of the calibration quality, close the function via the button *Close*.

→ The calibration of the vision sensor-equipped robot is now complete. You can now remove the calibration plate.

16.4 Messages

Message	Remedy / meaning
A connection can only be established if the Vision Sensor [serial number] has been configured for robotics mode "Universal Robot" (Device settings → Robotics).	Enable Robotics mode for the vision sensor in the <i>Application Suite</i> (Device Settings → Robotics).
On the Vision Sensor [serial number] a Z calibration has to be accomplished first.	Perform a Z calibration in the <i>Application Suite</i> (Device Settings → Z calibration).
The image brightness is very low. Please activate an illumination if necessary.	Increase the brightness. If necessary, activate the internal / external illumination of the vision sensor in PolyScope.
The image brightness is very high. Please deactivate an illumination if necessary.	Reduce the brightness. If necessary, deactivate the internal / external illumination of the vision sensor in PolyScope.
The connection to the Vision Sensor [serial number] could not be established.	Make sure the vision sensor is turned on and in the same network as the robot.
Should the Vision Sensor be activated?	The vision sensor is in <i>Configuration</i> mode. Complete the configuration of the vision sensor to perform further work.
Do you really want to overwrite the previously saved robot position?	Security query to prevent the accidental overwriting of a previously stored robot position.
Please update your URCap first to establish a connection to this device.	The version of the URCap is outdated. Please update the URCap to connect to the vision sensor.
Changing the type of mounting requires recalibration.	When changing between dynamic and stationary installation of the vision sensor, the calibration is lost. If necessary, create a new one.
A change of the robot coordinate system requires recalibration.	When changing the coordinate system, the calibration is lost. If necessary, create a new one.
There is no connection to the Vision Sensor [serial number].	The connection to the vision sensor has been lost. Reconnect to the vision sensor.
The Vision Sensor could not be activated.	Make sure that the vision sensor has been configured correctly.
The job [job number] could not be activated on the Vision Sensor [serial number].	No job is stored under the specified job number, or the job cannot be loaded because the job requires other device settings.

16.5 Programming the UR with vision sensor

In the simplest case, the UR moves the vision sensor to different fixed waypoints so that image-based feature checks can be performed there.

The task of finding objects by image processing is somewhat more complex. Image processing with the vision sensor and UR complements the existing work with waypoints with a function for image acquisition and a "second kind" of waypoint not set by hand but which receives coordinates from the image processing. In addition, it is possible to evaluate result data from the vision sensor in the robot controller in the form of variables.

NOTE



Please note that the image-based waypoints, unlike "classic" waypoints, do not have an additional parent program point for the movement. The type of movement is individually set directly in the image-based waypoint.

16.5.1 Node for job execution


The node of the vision sensor job execution is used to perform image processing. In other words, an image is triggered, captured and, after some time, results are transmitted to the UR.

There are two types of result data:

- Coordinates through the image processing of found objects in the form of an object list
- Information in the form of named variables for the feature check of different criteria

The elements of the object list can be processed (i.e. approached) with the vision sensor Waypoint node. Therefore, the job execution node must be used when using the vision sensor.

The vision sensor job execution node can be inserted wherever an image-based inspection is required.



The screenshot displays the UR robot programming software interface. On the left, a tree view shows the 'Robot Program' structure, including a 'VeriSens(R) Job Execution (#1)' node. The main workspace shows the configuration for this node. The 'Command' tab is active, displaying the 'VeriSens(R) Job Execution' configuration. Key elements include:

- Status:** VeriSens(R) connected (green dot).
- Active Job on VeriSens(R):** #1: PickAndPlace.app (dropdown menu).
- Object list with positions contains:** 2 items.
- VeriSens(R) results received:** 0 variables.
- Buttons:** 'Recover Pose of VeriSens(R) Installation' and a circular arrow button.
- Visual Feedback:** A 3D camera view showing the robot arm and the vision sensor's field of view.
- Simulation Controls:** A 'Normal' status indicator, a 'Speed' slider set to 100%, and 'Simulation' toggle buttons.

Signal to display the connected vision sensor

The vision sensor must be connected and the signal must light green. If not, check the installation and if the vision sensor is activated or restart the system.

For the inspection task to be performed at this point, the correct job of the vision sensor must be selected.

Make sure that the "Job active" signal is green, otherwise the image processing task on the vision sensor cannot be activated. In this case, check the vision sensor via *Application Suite* to see if the job is present and correctly configured.

If the signal lights up yellow, the vision sensor is activated. Activation can be triggered by pressing the Refresh button and confirming the confirmation prompt.

Restore pose of vision sensor installation (RX, RY, Z)

This button allows you to approach the pose saved during installation in order to use it temporarily for image acquisition. If necessary, add a UR waypoint in front of this waypoint with the current position to always start it before the job runs.

Note on UR programming - result data

`VS_NumObjects`

is the number behind "Object list contains". This variable can be used to control a robot loop so that a vision waypoint is approached as long as `VS_NumObjects > 0`.

**NOTE**

Please note that only one object list is managed in the robot program. An existing object list is overwritten with each job execution if a "waypoint feature" is selected in the executed job (see chapter [Output Robotics \(device dependent\)](#)).

Irrespective of the image-based determination of object positions, the vision sensor has various feature checks on board to perform, among other things, inspections on objects (see Chapter [Feature checks](#)).

The results can be output via the process interface of the vision sensor (see chapter [Output Robotics \(device dependent\)](#)) directly as a variable to the UR and evaluated there. The configuration menu enables the combination of feature and value according to the configured job.

These values can be retrieved in the UR and follow a generic nomenclature:

`VSV_designation`

and can thus be integrated into program sequences.

Example: `VSV_distance =`

Additional variables help to query the state.

16.5.2 Node for finding waypoints

So far, waypoints have been taught and started accordingly in the program. With the Vision Sensor, it is possible to use a second type of waypoint - defined by a position provided by the vision sensor.


The user can specify an offset. This offset can be edited by entering values or calculated by adopting a robot position.



NOTE

The vision sensor cannot detect the rotation (RX, RY), nor the "depth" (Z). The fixed value defined via the vision sensor is supplied for Z ("reference height"). RZ corresponds to the object rotation between the X and Y axes, i.e. around the Z axis.

This node can also be used multiple times to, for example, first to move over a found object, then move to the gripping position via a linear movement and again move a piece up after gripping by a linear movement.



VeriSens(R) Waypoint & Move

Robot positioning based on objects found by VeriSens(R)

VS_Waypoint_1

Variable	Vision Sensor	Offset
X	-135.22 mm	0.00 mm
Y	-196.10 mm	0.00 mm
Z	18.00 mm	0.00 mm
RX	0.00 °	180.00 °
RY	0.00 °	0.00 °
RZ	-155.71 °	0.00 °

☒ Stop at this point ☒ Joint Speed 60 °/s
☐ Blend with radius Joint Acceleration 80 °/s²
 0.0 mm ☐ Time 0 s

Object list contains: 2 items
☐ delete current item after finishing this waypoint

Movement type of the robot

MoveJ

The robot moves its joints freely, it can rotate to the desired position. Angle of rotation and spin are adjustable.

MoveL

The robot moves in a straight line (linear) from one point to the next. Speed and acceleration are adjustable.



With this function, you can edit the name of the waypoint.

Coordinates of the waypoint

Variable: Reference to the coordinate system

Vision Sensor: Value delivered by the vision sensor.

Offset: Offset that can be set in relation to the vision coordinates

Edit offset

Enables direct editing of offset data in a subsequent dialogue.

Move here

Analogous behaviour as for non-vision based waypoints - approaching the vision waypoint including offset.

Stop at this point

After approaching the waypoint, the robot stops in the course of the program.

Grinding with radius

Here, the radius can be ground analogously to non-vision-based waypoints.


Object list contains

The number of objects found by the job execution node is displayed here. It is the supply of object positions or objects to be approached.

Delete current entry after ending the waypoint

This checkbox marks a found and approached object as done and deletes from the list. For example, this checkbox should be enabled on a Pick&Place application with multiple objects in the last node to which a found object should be moved.

Edit offset



VeriSens(R) Waypoint & Move

Robot positioning based on objects found by VeriSens(R)

Variable	Vision Sensor	Offset
X	-135.22 mm	0.00 mm
Y	-196.10 mm	0.00 mm
Z	18.00 mm	50.00 mm
RX	0.00 °	180.00 °
RY	0.00 °	0.00 °
RZ	-155.71 °	0.00 °

Learn robot pose as offset

Position robot with "Freedrive" or "Move" before

OK

Cancel

The offset can be edited directly in the field.

Edit offset by pose

This is the most convenient way to adjust the offset by simply moving the robot using the Freedrive or Move function (top button on the UR Teach Pendant).


The new position is displayed in the table and can be readjusted here optionally.

With **OK** the new offset is accepted and the dialogue is closed. **Cancel** closes the dialogue without accepting the values.

Error message: Coordinate alignment problem

The image-based waypoint works only if the vision sensor and UR coordinates are properly aligned during installation (URCap installation, coordinate alignment).

If the coordinate alignment is not available or no longer up-to-date (signalling inactive under URCap, coordinate alignment), then the icon of the waypoint is displayed in yellow and the following error message appears:



16.5.3 "Pick & Place" node

The node additionally simplifies the UR programming of a typical Pick&Place application. Here, the two new nodes for job execution and for the vision waypoint are combined in a loop that monitors the number and approach of found objects.

16.6 Example programs for the robot controller

Below you will find two examples illustrating the steps in the UR robot controller. The program can be seen in the left area and the setting options for the selected program point (node) can be seen in the right area.

16.6.1 Pick & Place

This sample program represents a typical Pick&Place application. The vision sensor searches for objects and the coordinates of the objects found are transferred to the robot controller. Then the objects are approached one after the other.

Settings in the *Application Suite*


- In the *Application Suite*, configure the feature check *Find object positions*.
- In the *Configure interfaces* step, you can set the coordinates of the found objects to be transferred to the robot controller. (*Configure interfaces* → *Output robotics*)

Check whether *Feature for waypoint* has the feature check *Find object positions*. Entry should be automatic.

- Save the job on the Vision Sensor.

→ The coordinates of the objects found are now transferred to the robot controller via the process interface when the job is executed.

Settings on the robot controller (PolyScope)



Program point	Settings
Robot Program	
Vision Sensor Pick & Place	Name of the program
MoveJ	Definition of the type of movement with which the robot should move. Where the robot should then move is determined later. MoveJ = the robot moves its joints freely, it can rotate to the desired position MoveL = the robot moves in a straight line (linear) from one point to the next MoveP = the robot can make circular movements
'Vision Sensor Job Execution Position'	Comment
Waypoint_1	Position where the robot should move to in order to perform the vision sensor job. For example, in the case of stationary installation of the vision sensor, the robot must be moved out of the field of view of the vision sensor so that object positions can be found in the work area.
Vision Sensor Job Execution	The job stored on the vision sensor (<i>Find object positions</i>) is selected here.
If VS_NumObjects == 0	If the number of found objects is 0, a message could subsequently be defined that no objects were found. The robot then has no coordinates to approach. NOTE If this program point is omitted and the number of objects found is 0, the following error occurs when the program is executed: <i>Fehlercode -32022</i> <i>...urcap.baumer.camera job exception NoRoboticCoordinates...</i> To solve this problem, please add the following program items and adjust them accordingly: <pre> If VS_NumObjects == 0 'Action if not objects found' ... Else 'While objects are in result list' ... </pre>
'Action if no objects found'	Comment
Else	The Else branch specifies what to do when objects are found.

Program point	Settings
'While objects are in result list'	Comment
Loop VS_NumObjects > 0	The loop is executed while there are still objects in the list (VS_NumObjects> 0) received from the vision sensor.
'Pre-Pick-Position'	Comment
Vision Sensor: VS_Waypoint_1	The position above the first found object is approached. If necessary, adjust the Z offset.
'Pick-Position'	Comment
Vision Sensor: VS_Waypoint_2	The robot moves to the position where the object is to be gripped. NOTE In the following step, a node should be inserted to control the gripper. This is missing due to the large number of grippers to be used in the example program.
'Post-Pick-Position'	Comment
Vision Sensor: VS_Waypoint_3	The position is approached after grasping the object. Here, the coordinates of the currently accessed object are removed from the list.
'Place-Positon'	Comment
MoveJ	Here, you can set the movement type with which the robot should move to the storage position for the object.
Waypoint_2	Here, the storage position of the object is defined. NOTE In the following step, a node should be inserted to control the gripper. This is missing due to the large number of grippers to be used in the example program.
	Afterwards you jump to the point Loop VS_NumObjects> 0 until all coordinates from the object list have been processed.

16.6.2 Quality control



NOTE

If the robot controller does not require coordinates supplied by the vision sensor as waypoints, as in this example program, Z-calibration / Z-correction and distortion correction on the vision sensor is not urgently necessary.

This sample program represents a typical application of quality control. The vision sensor carries out the feature check *Distance* with a part location and depending on the result of the feature check, the test object can be treated accordingly by the robot controller. However, no coordinates provided by the vision sensor are used to control the robot.

Settings in the *Application Suite*

- In the *Application Suite*, configure the feature *Check part location on contours*.
- Configure the feature check *Distance*.
- In the step *Configure interfaces*, you set which data is to be transmitted to the robot controller. (*Configure interfaces* → *Output robotics*)

Since in contrast to example program 1 (*Pick & Place*), no coordinates of the found object are to be transmitted to the robot control, no feature check has to be selected for *Feature for waypoint*.

Continue to configure the transfer of the determined distance here. For example, select the variable name `VSV_Distance`.

- Save the job on the Vision Sensor.

→ The position of the test object is now determined by *Part location on contours* and the feature check *Distance* is performed. However, only the determined distance is transferred via the process interface to the robot controller.

Settings on the robot controller (PolyScope)



Program point	Settings
Robot Program	
Vision Sensor Inspection	Name of the program
MoveJ	Definition of the type of movement with which the robot should move. Where the robot should then move is determined later. MoveJ = the robot moves its joints freely, it can rotate to the desired position MoveL = the robot moves in a straight line (linear) from one point to the next MoveP = the robot can make circular movements
'Vision Sensor Job Execution Position'	Comment
Waypoint_1	Position where the robot should move to in order to perform the vision sensor job. For example, in the case of stationary installation of the vision sensor, the robot must be moved out of the field of view of the vision sensor so the test object can be found in the work area.
Vision Sensor Job Execution	The job (<i>Distance</i>) stored on the vision sensor is selected here.
'Check distance'	Comment
If VSV_Distance<30	The VSV_Distance variable represents the distance determined with the vision sensor and transmitted to the robot controller via the process interface . Subsequently, it can be determined what should happen if this distance is smaller or larger than 30.
'Inspection failed'	Comment
Else	The Else branch specifies what to do if the distance is less than 30.
,Inspection okay'	Comment

16.6.3 Applications with heights as well as relative object positions

Image processing with the Vision Sensor is based on 2D images. Robotics operate in the 3D realm. The effect of the third dimension on the 2D scaling is already taught in during the calibration process via *SmartGrid* when the Vision Sensor / UR is integrated. During the subsequent setup, this makes it considerably easier to handle the different “Z” values such as object height, grabbing height, or work surface height, as all values can operate with a “reference level.”


The height of an object is measured and stored in the image processing job. This enables the Vision Sensor to convey to the robot not only the x , y , and $rotZ$ that were determined by the 2D image processing but also the value z of the object surface that is “seen”.



NOTE

To put it simply, $rotX$ and $rotY$ are zero, accordingly are all 3D coordinates covered.

This leads to the justified question of whether the Vision Sensor and UR can also be used to handle objects with different heights in an application. Imagine a winner’s podium:



You want to use image processing to measure from above whether the platforms have the correct dimensions.

Problem: Capturing an image from an overhead camera position makes the captured platforms appear differently sized due to their varying distances from the capturing device.

How can such applications be resolved?

16.6.3.1 Option 1 – simply create several jobs

16.6.3.1.1 Applications

An object with varying heights is to be inspected or measured with limited effort. All heights are in the depth of field area of the Vision Sensor in its calibrated capturing position.

Using the example of our winner's podium, it must therefore be possible for all 3 steps to be in the depth of field area. With the Vision sensors with changeable lens, the depth of field can be influenced by the choice of the respective lens.

The Vision Sensor is mounted dynamically according to the technical documentation – i.e. carried along. Alternatively, it can also be mounted statically, i.e., above the robot.

16.6.3.1.2 Advantages and disadvantages of the option

Advantages:

- Very easy to comprehend and implement
- Can be implemented with both mounting options

Disadvantages:

- Object heights must be located in a common depth of field area
- Specific object heights must be known when creating the program

16.6.3.1.3 Installation and calibration

The application is calibrated via *SmartGrid*. The focus must not be shifted anymore. The image capturing position is stored via *URCap* in step 2.

	NOTE Please make sure that when the distance between the <i>SmartGrid</i> and the reference level is entered in both the <i>Application Suite</i> and <i>URCap</i>, the additional distance between the <i>SmartGrid</i> bottom side and reference level is added to the <i>SmartGrid</i> material thickness if the <i>SmartGrid</i> is not directly placed on the reference level.


After the automatic alignment of the coordinates is completed in installation step 3 of the *URCap*, the application can be created.

16.6.3.1.4 Image processing job and robot program

For each height to be inspected – in our case the three heights of the platforms – a job must be created or adapted (“Platform_1”, “Platform_2”, etc.). For this purpose, the respective object height (height of the step to the reference level) must be saved in every job under Coordinates/Z-correction.

As the Vision Sensor is familiar with the overall system from the calibration, it is capable of correspondingly scaling objects that appear to have different sizes due to their heights for each job correctly in x and y and thus verifying the correct dimensions.

How can the robot be additionally moved to the different heights, e.g., to assemble the winner’s podium from the individual steps using the robot?



Very simply, the movement of the robot is based on the coordinates of the respective upstream “Job Execution” in the robot’s program using the individual job for each level. This provides the coordinates to the subsequent “Waypoint & Move”, including z of the object height. At this node, an additional, corresponding Z offset can be freely selected each time, allowing the grabber, e.g., to move to a position underneath the surface of the step.

If the individual steps are provided randomly, the selection of the associated job could take place based on the results of a distance sensor (measurement of the step height), for example.

16.6.3.2 Option 2 – Movement affected by the robot program

16.6.3.2.1 Applications

- A screwdriver guided by a robot arm is to move to four screws in the corners of an object, depending on a position determined by the Vision Sensor.
- A distance sensor moving along with the UR provides the distance to the object, allowing the inspection to take place based on the height and thus flexibly.
- For application reasons, the robot program itself is to introduce an additional offset to the image-based coordinates provided by the Vision Sensor for the waypoint.
- With option 2, the robot in our example of a winner's podium moves to each step of the podium individually to allow measurement with a constant distance to *the Vision Sensor*.

Only dynamic mounting of the Vision Sensor i.e., moving along with the robot, is possible.

16.6.3.2.2 Advantages and disadvantages of the option

Advantages:

- Different object heights do not have to be in the same depth of field area
- A distance sensor can be used for the automatic determination of the object height
- Positions depending on the heights z or x , y , $rotZ$ can be approached


Disadvantages:

- More complex than option 1
- Limited to dynamic mounting with its advantages and disadvantages (see the documentation)

16.6.3.2.3 Installation and calibration

In our example of a winner's podium, the height of precisely one platform is measured in relation to the reference level and permanently defined in the robot program. This offers the advantage that only one image processing job is required and the work is also done independently of the depth of field area of the Vision Sensor. The addition to or deduction from coordinate z required for steps of different heights is specified by the robot program itself.

The system is calibrated in *URCap* based on the top step of our winner's podium, to which the *SmartGrid* is applied. In this captured image, the robot position is stored under step 2 as standard. The coordinates are now calibrated in step 3; the focus of the Vision Sensor should now no longer be shifted.



NOTE

Please make sure that when the distance between the *SmartGrid* and the reference level is entered, the additional distance between the *SmartGrid* bottom side and the reference

level is added to the *SmartGrid* material thickness in both *Application Suite* as well as in *URCap*, as the *SmartGrid* is not directly placed on the reference level. The distance between the *SmartGrid* and the reference level therefore consists of the sum of the *SmartGrid* material thickness and the height of the step.

We have chosen the top step for the calibration to avoid conflicts with the maximum height during the subsequent process.


16.6.3.2.4 Image processing job and robot program

In our example of grabbing individual steps of the winner's podium, an offset z is required for each individual step 1, 2, and 3.

The applicative trick now consists of the robot program itself or even a distance sensor setting this additional offset z to specified waypoint coordinates or image-based coordinates by incorporating both coordinates in the robot program calculations.

Specifically, offset z is used twice in the robot program:

- 1st height adjustment: waypoint before "Job Execution"
- 2nd height adjustment: waypoint after "Waypoint & Move"



1st height adjustment

The same "Job Execution" takes place for every platform. However, before the job is executed via the program-based movement of the robot, a fixed working distance between the top of the step and the Vision Sensor is determined for each of the three steps so that the displayed platform always has same size in the image and can be correctly measured.

2nd height adjustment

The coordinate z provided by the *Vision Sensor* or saved in the image processing job (under Coordinates / Z correction) is always the same. The stated value is the height of step 1 (top side) in relation to the reference level, as we have created one job for this.

This is why a script-based calculation is required in the robot, as both sensors or values are only combined in the robot, or an additional, fixed offset value is only added to the image-based waypoint there.

For this purpose, the script must first acquire the coordinates of the approached image-based waypoint for further calculation, which takes place by moving to a position with a fixed offset from the node "Waypoint & Move".

The waypoint to be approached for the grabbing task of the UR is then calculated from these stored coordinates and the above-mentioned additional value for the height adjustment of the respective step.

For grabbing tasks, which typically require a position underneath the surface of the object, an object-based offset from the robot program continues to be used.

16.6.3.3 Programming example 1 – winner’s podium

16.6.3.3.1 Description of the application

We now look at the winner’s podium and shows how the different object heights z are handled: the robot program itself maintains the distance between the Vision Sensor and the object surface that is specified in the image processing job.

16.6.3.3.2 Creating the variables

The following variables are used by the program and must therefore be created in advance. The initially determined values are adjusted while the program is running.

`offs_exec_z`

Vertical shift of the image capturing position in relation to the height during the coordinate calibration (installation).


`offs_move_z`

Vertical shift that was set manually in the waypoint.

`pos_WP`

Calculated position of a waypoint that is to be approached in the program.

Syntax: `p[x, y, z, rotX, rotY, rotZ]`




The screenshot shows the 'Installation Variables' window in the Baumer VeriSens software. The window has a sidebar on the left with a tree view containing 'General', 'TCP', 'Mounting', 'I/O Setup', 'Variables', 'Startup', 'Smooth Transition', 'Conveyor Tracking', 'Screwdriving', 'Home', 'Tool I/O', 'Safety', 'Features', 'Fieldbus', and 'URCaps'. The 'Variables' section is currently selected. The main area displays a table with the following data:

Variable	Value
<code>offs_exec_z</code>	0
<code>offs_move_z</code>	0
<code>pos_WP</code>	<code>p[0, 0, 0, 0, 0, 0]</code>

At the bottom of the table, there are three buttons: 'Create New', 'Edit Value', and 'Delete'. The bottom status bar shows a 'Normal' mode indicator, a 'Speed' slider set to 100%, and a 'Simulation' toggle switch.

16.6.3.3.3 Creating the program

Robot programming can now commence.



Program description

Line	Explanation
4	→ Basic → Waypoint Move to a waypoint that either corresponds to the pose of the vision sensor during installation or a pose with the same height <i>z</i> only as during the installation.
6	→ Advanced → Assignment Set the variable <code>offs_exec_z</code> to a <i>z</i> offset by which the job execution pose is to be shifted. Example: The current inspection level is 100 mm lower than the pose during calibration (neg. <i>z</i> direction) => -0.1 meter Alternatively, the result of an external distance sensor can also be used here.
8	→ Advanced → Assignment 1st height adjustment: Set variable <code>pos_WP</code> to a calculated value. This is calculated with <code>pose_add()</code> as the sum of the following two values: <code>p[0, 0, offs_exec_z, 0, 0, 0]</code> ... a relative shift created in the <i>Z</i> direction <code>get_actual_tcp_pose()</code> ... the current position of the robot <u>Note:</u>

- For use in a formula, a pose can be created with the following syntax: $p[x, y, z, \text{rotX}, \text{rotY}, \text{rotZ}]$. In this formula x, y, z indicate the coordinates (e.g. metric in "meters") and $\text{rotX}, \text{rotY}, \text{rotZ}$ the rotation values of the TCP (in radians).
- In this example, the last three components (rotation values) remain unaffected in the case of calculated poses.

NOTE

Depending on the application, we generally recommend only altering rotZ to prevent unintended side effects; *the Vision Sensor* also only provides this value.

- pos_WP serves as a temporarily used variable for storing a position






Figure 7

10

→ Basic → Waypoint

Move to the waypoint whose position corresponds to the value of the variable pos_WP .




12	→ URCap → VeriSens(R) Job Execution Execute the selected job on VeriSens®. NOTE In this example, VeriSens® is located 100 mm lower than normal. VeriSens® is not informed of this changed image capturing position and continues to provide the Z height set in the job in the <i>Application Suite</i> as the Z coordinate.
13	→ Advanced → If Execute the following subprogram only if at least one object has been found.
15	→ URCap → VeriSens(R) Waypoint & Move Move to the object position provided by VeriSens®, which is manually adjusted in the Z direction to prevent collisions.  In the example, this manual adjustment is 200 mm. This means that the robot moves 200 mm above the Z position specified in the job in the <i>Application Suite</i>. The value of this height adjustment must be selected so that the robot moves to a position above the object in all instances. Especially when <code>offs_exec_z</code> is > 0, this manual adjustment should be a little larger than the value of <code>offs_exec_z</code>.
17	→ Advanced → Assignment Set the variable <code>offs_move_z</code> to the same value which was previously manually set as the offset in the “VeriSens® Waypoint & Move” node (line 13) (in this example 0.2 m).
19	→ Advanced → Assignment 2nd height adjustment: Set variable <code>pos_WP</code> to a calculated value. This is calculated with <code>pose_add()</code> as the sum of the following two values: - <code>p[0, 0, offs_exec_z - offs_move_z - 0.05, 0, 0, 0]</code> ... a relative shift created in the Z direction, which is composed of three Z components: - o <code>offs_exec_z</code> ... takes into account the vertical shift during the job execution - o <code>offs_move_z</code> ... compensates the vertical shift of the approached waypoint above the

	object -0.05 ... manual adjustment: e.g. for a lower grabbing position (in this example shifted by 50 mm in the neg. Z direction) - <code>get_actual_tcp_pose()</code> ... the current position of the robot
21	→ Basic → Waypoint Move to the waypoint whose position corresponds to the value of the variable <code>pos_WP</code> .

16.6.3.4 Programming example 2 – four screws depending on a variable position

16.6.3.4.1 Description of the application

In the second example, four screws are to be tightened in fixed positions from the center based on the position detected in the middle by *VeriSens®*, using an electric screwdriver guided by a robot. In the captured image, Z is equivalent to the nominal height of the coordinate calibration. To “get” the position, the robot moves to a higher z. An adjustment is then made in z as well as x and y for the tightening position in each corner.



16.6.3.4.2 Creating the variables

The following variables are used by the program and must therefore be created in advance. The initially determined values are adjusted while the program is running.

`offs_corner_x`

X offset of the tightening position of a corner in relation to the center of the object

`offs_corner_y`

Y offset of the tightening position of a corner in relation to the center of the object


`offs_move_z`

Vertical shift that is set manually in the *VeriSens®* waypoint

`pos_WP`


Calculated position of a waypoint that is to be approached in the program.

Syntax: `p[x, y, z, rotX, rotY, rotZ]`





16.6.3.4.3 Creating the program

Robot programming can now commence.



Program description

Line	Explanation
4	→ Basic → Waypoint Move to a waypoint that either corresponds to the pose of the vision sensor during installation or a pose with the same height z only as during the installation.
6	→ URCap → VeriSens(R) Job Execution Execute the selected job on <i>VeriSens®</i>.
7	→ Advanced → If Execute the following subprogram only if one object has been found.
8	→ Advanced → Assignment Set the variable <code>offs_corner_x</code> to a fixed value. <u>Example:</u> <i>VeriSens®</i> provides the center of the object as the object position. The value <code>offs_corner_x</code> is set to half the distance between the tightening positions in the X direction, as a tightening position is found at this distance to the center of the object.
9	→ Advanced → Assignment Set the variable <code>offs_corner_y</code> to a fixed value. <u>Example:</u> <i>VeriSens®</i> provides the center of the object as the object position. The value <code>offs_corner_y</code> is set to half the distance between the tightening positions in the Y direction, as a tightening position is found at this distance to the center of the object.
10	→ Advanced → Loop Introduce a loop to move the robot to the 4 tightening positions in sequence. 
12	→ URCap → VeriSens(R) Waypoint & Move Move to the object position provided by <i>VeriSens®</i>, which is manually adjusted in the Z direction to prevent collisions.




In the example, this manual adjustment is 100 mm. This means that the robot moves 100 mm above the Z position set in the job in the *Application Suite*. The value of this height adjustment must be selected so that the robot moves to a position above the object in all instances.

14 → Advanced → Assignment

Set the variable `offs_move_z` to the same value that was previously set manually as the offset in the “VeriSens® Waypoint & Move” node (line 12) (in this example, 0.1 m).

15 → Advanced → SubProg


Execute the “MoveToCorner” subprogram (see from line 22), which will cause the robot to move to a position above one of the four tightening positions, depending on the loop index.




18 → Advanced → Assignment

Set variable `pos_WP` to a calculated value. This is calculated with `pose_add()` as the sum of the following two values:

- `p[0, 0, offs_exec_z - offs_move_z - 0.05, 0, 0, 0]` ... a relative shift

	created in the Z direction, which is composed of two Z components: - o -offs_move_z ... compensates the vertical shift of the approached waypoint above the object - o -0.05 ... manual adjustment: e.g. for a lower tightening position (in this example, shifted by 50 mm in the neg. Z direction) • get_actual_tcp_pose() ... the current position of the robot
19	→ Basic → Waypoint Move to the waypoint whose position corresponds to the value of the variable <code>pos_WP</code>. Note The tightening process could take place now.
20	→ Advanced → Assignment Set variable <code>pos_WP</code> to a calculated value. This reverses the vertical position change from line 18.
21	→ Basic → Waypoint Move to the waypoint whose position corresponds to the value of the variable <code>pos_WP</code>. Note Now the robot is at a distance above the object again.
22	Start of the description of the “MoveToCorner” subprogram
23	→ Advanced → Switch Addition of 4 cases within a switch command. This way, each tightening position can be treated separately within a case command. 
24,	Automatically inserted case command within which additional nodes can be added.

26, 28, 30	
25, 27, 29, 31	→ Advanced → Assignment Set variable <code>pos_WP</code> to a calculated value. This is calculated with <code>pose_add()</code> as the sum of the following two values: • <code>p[±offs_corner_x, ±offs_corner_y, 0, 0, 0, 0]</code> ... a relative offset created in the X and Y direction, to subsequently (line 33) move the robot correctly over a tightening position each time. • <code>get_actual_tcp_pose()</code> ... the current position of the robot
33	→ Basic → Waypoint Move to the waypoint whose position corresponds to the value of the variable <code>pos_WP</code>. Note The robot is now over a tightening position depending on the respective case. The program execution continues at the end of this subprogram in line 16.

17 Cleaning

Due to its compact design, the device is characterized by almost maintenance-free operation.

When used for the intended purpose, it is possible that the device may need to be cleaned from time to time. Very clean optical surfaces (cover glass) are required for the consistent and reproducible operation of the device.

For cleaning, use a soft, lint-free cloth to clean the surface of the cover glass with a gentle pressure, without scratching.

To clean stubborn dirt, commonly available window cleaning agent is recommended.



ATTENTION!

Ensure that no residues of the cleaning agent or scratches remain on the glass. These can permanently damage the reproducibility of the results from the device.



ATTENTION!

As so many cleaning agents are available, we hope you understand that we cannot test every single one. Resistance to cleaning agents and areas of use depends upon the specific application.

Cleaning agents must be tested on an discreet area of the device under application conditions to evaluate if they are suitable.

Materials within the device with protection class IP 69K

Component, part	Material	Classification
Housing	Stainless steel 1.4404 (316L)	
Seal (housing)	polymerized silicone rubber (CAF)	FDA, BfR
Seal bonding agent (primer)	Silquest VS-142 (Silquest is a trademark of Momentive Performance Materials Inc.)	
Cover glass	PMMA	FDA, UL
Seal / adhesive (cover glass)	Silicone adhesive	FDA
Seals (O-rings)	Fluororubber (FPM)	FDA
Press-fitted optical fibre	Polycarbonate	
Sealing collar optical fibre	Epoxy resin	
Screw cover (rear side)	Silicone	FDA
Connector M12 / 12 pin	Stainless steel 1.4404 (316L)	

18 Excess temperature behaviour (only devices with integral Industrial Ethernet)

An internal protection device intervenes when the device is operated outside of specification; this is intended to protect the components against destruction by heat.

The *Application Suite*, the web-interface and the process interfaces will output an overheating warning message. This notifies the user that the maximum permissible operating temperature has been reached prior to the device undergoing emergency shutdown.

Warning message

Subject to temperature situation, work can be briefly continued at this warning level; to save the project, for example.

Confirm the query to do this.




Emergency shutdown

Should the housing temperature continue to rise, the device will undergo emergency shutdown to protect it from damage.

After cooling, the supply voltage must be briefly interrupted and restored to be able to use the device again after shutdown.

A further warning message will provide information about the previous emergency shutdown of the device.



19 Technical data

19.1 Overview of feature checks

Feature checks	XC100 ¹	XC200	XC700	XC800 XC900	XF105 XF100 XF700	XF205 XF200 XF800 XF900	CS100	ID110 ID510	ID105 ID100
Part location									
Part location on contours	360°	360°	360°	360°	360°	360°	360°		
Part location on edges	•	•	•	•	•	•			
Part location on circle	•	•	•	•	•	•			
Part location on text lines	•	•	•	•	•	•		•	
Geometry									
Distance	•	•	•	•	•	•	•		
Circle	•	•	•	•	•	•	•		
Angle	•	•	•	•	•	•			
Count edges	•	•	•	•	•	•			
Point position	•	•	•	•	•	•			
Edge characteristics	• -	• -	• •	• •	• •	•			
Feature comparison									
Count contour points (monochrome) (colour)	• •	• •	• •	• •	• •	•	•		
Contour comparison (monochrome) (colour)	• •	• •	• •	• •	• •	•	•	•	
Brightness	• -	• -	• •	• •	• •	•	•		
Contrast	• -	• -	• •	• •	• •	•			
Colour identification	- •	- •	- •	- •	- •				
Area size (monochrome) (colour)	• •	• •	• •	• •	• •	•			
Count areas (monochrome) (colour)	• •	• •	• •	• •	• •	•			
Pattern comparison (monochrome) (colour)	• •	• •	• •	• •	• •	•			
Colour positioning	- •	- •	- •	- •	- •				
Finding object positions			• -	• -					
Identification									
Barcode (monochrome) (colour)		• •		• •		•		•	•
Matrix code (monochrome) (colour)		• •		• •		•		•	•
Text (monochrome) (colour)		• •		• •		•		•	

19.2 Overview Features


	XC100 XC700	XC200 XC800 XC900	XF105 XF100 XF700	XF205 XF200 XF800 XF900	CS100	ID110 ID510	ID105 ID100
Image acquisition							
Optics: 8 mm 10 mm 12 mm 16 mm C-mount	- - - ●	- - - ●	- ● ● ●	● ¹ ● ● ●	- ● ●	- - ●	- ● ●
Illumination: White Infra-red (daylight filter integrated) Integrated flash controller for external illumination	- - ●	- - ●	● ●	● ●	● ●	● ●	●
Configurable web interface (live image, job switching, retrieving defect images)	●	●	●	●	●	●	●
Save images via FTP	●	●	●	●	●	●	●
Configuration via Ethernet	●	●	●	●	●	●	●
Functions							
Process linkage: Digital I/Os	5 3-5	5 3-5	5 3-5	5 3-5	5 5	5 3-5	5 3
Produce partial results via digital I/Os at different times	●	●	●	●			
Process interface: Ethernet RS485 (device dependent)	●	●	●	●	-	●	● ●
Baumer FEX® Image processor	●	●	●	●	●	●	●
FEXLoc® (360° part location)	●	●	●	●	●		
User administration / Password protection	●	●	●	●		●	●
Coordinate conversion	●	●	●	●			
Distortion correction (monochrome only)	● ²	● ²	● ²	● ²			
Support: UR3e / UR5e / UR10e / UR16e (Z-teach)		● ³		● ³			
Process linkage							
Flexible result conjunction	●	●	●	●			
Integrate digital inputs into results conjunction	●	●	●	●			
Identification functions: Code Text	-	● ●	-	● ●	-	● ●	●
Job test function	●	●	●	●	●	●	●
High speed mode (monochrome only)	●	●	●	●			
Gamma correction	●	●	●	●			

¹⁾ only XF800 and XF900


²⁾ only XC700 / XC800 / XC900 or XF700 / XF800 / XF900

³⁾ only XC900 / XF900


19.3 Technical drawing (except XC series)



19.4 Technical drawing (XC series only)



19.5 Technical drawing (only devices with protection class IP 69K)





19.6 Fastening bracket, 90 degree (VS mounting adapter)



NOTE

For optimum heat dissipation use only this attachment bracket for Vision Sensors ID510 and XF700 / XF800 / XF900 / XC700 / XC800 / XC900!

- Colour: black
- Material: anodized aluminium






19.7 Fastening bracket, 90 degree



NOTE

This attachment bracket is not suitable for Vision sensors ID510 and XF700 / XF800 / XC700 / XC800 due to its low thermal conductivity.

- Colour: Black
- Material: powder coated steel




19.8 Fastening bracket, straight



NOTE

This attachment bracket is not suitable for Vision sensors ID510 and XF700 / XF800 / XF900 / XC700 / XC800 / XC900 due to its low thermal conductivity.

- Colour: Black
- Material: powder coated steel



19.9 Technical data

General data	XC series			XF series CS series ID series			
Resolution	640 × 480 px	1280 × 960 px	1600 × 1200 px	752 × 480 px			
Sensor (monochrome)	1/4" CCD (monochrome , colour)	1/3" CCD (monochrome, colour)	1/1.8" CCD (monochrome)	1/3" CMOS (monochrome, colour)			
LED illumination	Fully integrated flash controller for external illumination			White (LED class: Risk group 1 low risk, EN 62471:2008) Infra-red (LED class: free group risk free, EN 62471:2008) (860 nm)			
Lens	Replacement lens (C-mount)			f = 8 mm	f = 10 mm	f = 12 mm	f = 16 mm
Min. object distance	Depending on changeable lens			50 mm	50 mm	50 mm	70 mm / 100 mm ¹⁾
Max. object distance	Depending on changeable lens			450 mm	∞	450 mm	300 mm
Speed Full resolution Reduced, max. speed (reduced resolution, monochrome)	Max. Insp / s 50 116 ¹⁾ 100 144 ¹⁾	Max. Insp / s 12 31 ¹⁾ 25 54 ¹⁾	Max. Insp / s 7 21 ¹⁾ 15 35 ¹⁾	Max. Insp / s 50 100 (monochrome, only XF series) Reduced, max. brightness, (monochrome, XF series only)			
Defect image memory	32	8	4	32			
Number of jobs	Up to 255 on the device (can be exchanged via process interface)						
Features per job	32						

Electrical data		XC series	XF series CS series ID series
Nominal voltage power supply	Socket 2	⚡ 24 V ± 25% / Class 2 according to NEC / protection class III The device is intended for supply from an isolated limited power source according to UL61010-1, 3rd ed cl. 9.4 or a limited energy source according to UL60950-1 or Class 2 according to NEC.	
Power consumption		max. 42 W (with I/O and lighting)	max. 18 W (with I/O)
Inputs		8 ... 30 V (polarity protected)	
Outputs		PNP I _{peak} = 100 mA and I _{eff} = 50 mA (short-circuit proof)	
Digital input		Trigger, Job selection, External teach, Encoders (CH-A, CH-B) 500 kHz	
Digital output		Pass / Fail 1-5 ²⁾ , flash sync, alarm, image trigger permitted, result valid	
Communication initial set-up		Socket 1	Ethernet (10BASE-T / 100BASE-TX)
Process interface	PROFINET (CC-A) ¹⁾ / Ethernet/IP™ ¹⁾ , TCP / UDP (Ethernet) ³⁾		
	Socket 2	RS485 ⁴⁾	

¹⁾ only XC700 / XC800 / XC900 and ID510

²⁾ ID100: 1-3

³⁾ except CS100

⁴⁾ only ID100

Integr. Flash controller	XC series	XF series CS series ID series
Voltage (permanent) Voltage (pulsed)	 12 VDC or  24 VDC  24 VDC or  48 VDC	–
Current (permanent) Current (pulsed)	$I_{max} = 800 \text{ mA}$ at  24 VDC (+/-10 %, at least +/- 100 mA, at 25 °C) $I_{max} = 4 \text{ A}$ at  48 VDC (+10/-20 %, at least +/- 100 mA, at 25 °C)	–
Flash time	Max. 1 ms (Duty Cycle max. 1:10)	–

Operating conditions	XC series	XF series CS series ID series
Operating temperature	Operating temperature: +5 ... +55 °C @ measuring point	Operating temperature: +5 ... +60 °C @ measuring point
Storage temperature	-20 ... +70 °C	
Humidity	0 ... 90 % (non-condensing)	
Protection class	IP 67 (XC-Series: with tube)	IP 67, IP 69K (device dependent)
Vibration load	IEC 60068-2-6, IEC 60068-2-64	
Mech. shock resistance	EN 60068-2-27	

Mechanical data	XC series	XF series (XF series in IP 69K) CS series ID series
Width × Height × Depth	53 mm × 99.5 mm × 49.8 mm (without lens / tube)	53 mm × 99,5 mm (IP 69K: 107,5 mm) × 38 mm
Material	Housing: Aluminium, cover glass tube: PMMA	Housing: Aluminium (IP 69K: Stainless steel 1.4404) Cover glass: PMMA ⁵⁾
Weight	300 g (without lens / tube)	250 g (IP69K 700 g)


Code types / OCR	Model: XC800 / XC200	Models: XF200 / XF800 / XF205 ID110 ID100
Barcode ⁶⁾	2/5 Industrial, 2/5 Interleaved, Codabar, Code 39, Code 93, Code 128, PharmaCode EAN 8, EAN 13, UPC-A, UPC-E: Base code + versions Add-On 2, Add-On 5 GS1 DataBar (RSS): Limited, Expanded, Expanded Stacked GS1 DataBar (RSS-14): Base code + versions Truncated, Stacked, Stacked Omnidir GS1 128	
Matrix code ⁶⁾	DataMatrix (ECC 200), GS1-DataMatrix, QR, PDF417	
Font ⁷⁾	Optional fonts (recommended: sans serif, proportional), dot matrix, characters: A-Z a-z 0-9 + - . : / ()	


⁵⁾ for XF700 / XF105 / XF100 / XF800 / XF205 / CS100 / ID110 / ID510 with infra-red illumination: 780 nm daylight filter built-in


⁶⁾ incl. quality rating of all barcodes according to ISO / IEC 15416 as well as all matrix codes according to ISO / IEC 15415 or ISO/IEC TR 29158 (AIM DPM-1-2006)


⁷⁾ only XC800 / XC900 / XC200 / XF800 / XF900 / XF205 / ID110 / ID510

19.10 Electrical Connection (View on Device)




Socket ①	Ethernet interface (M12), D-coded	
	Pin	Pin Assignment
	1	TD+
	2	RD+
	3	TD-
	4	RD-

Socket ②	Power supply / Digital I/O (M12), A-coded	
	Pin	Pin Assignment
	1	Power ($\overline{\text{---}}$ 24 V $\pm$ 25 %)
	2	Ground
	3	IN1 (Trigger)
	4	OUT 1 (PTC-protected)
	5	IN 2
	6	OUT 2 (PTC-protected)
	7	OUT 3 (PTC-protected)
	8	IN 3
	9	OUT 4 / (RS 485+, ID100 only) (PTC-protected)
	10	IN 4
	11	IN 5
	12	OUT 5 / (RS 485-, ID100 only) (PTC-protected)

Socket ③	Illumination port (M8), (XC series only)	
	Pin	Pin Assignment
	1	$\overline{\text{---}}$ +24V or JL +48V Flash
	2	$\overline{\text{---}}$ +12V or JL +24V Flash
	3	Ground
	4	Flash Sync ¹⁾ , (100 mA PNP)
¹⁾ voltage according to power supply Voltage outputs configurable by software		

19.11 Power Cable M12 / 12-pin

Pin assignment of the connecting cable (M12)			
	Pin	Designation	Colour code
	1	Power ($\text{---}24\text{ V} \pm 25\%$)	brown
	2	Ground	blue
	3	IN1 (Trigger)	white
	4	OUT 1 (PTC-protected)	green
	5	IN 2	pink
	6	OUT 2 (PTC-protected)	yellow
	7	OUT 3 (PTC-protected)	black
	8	IN 3	grey
	9	OUT 4 / RS 485+ (PTC-protected)	red
	10	IN 4	violet
	11	IN 5	grey-pink
	12	OUT 5 / RS 485- (PTC-protected)	red blue

20 Conformity

20.1 CE



We declare under our sole responsibility that the devices described previously comply with the specifications of the CE guidelines.

20.2 RoHS (restriction of hazardous substances)



We declare under our sole responsibility that the devices described previously comply with the European Union RoHS recommendations.

20.3 UL



The vision sensor has been tested by UL (Underwriters Laboratories) and meets the requirements of the standards:

- UL 61010-1 Edition 3 - Revision Date: 2016/04/29
- UL 61010-2-201 Edition 2 - Published: 2018/05/14
- CSA C22.2 NO. 61010-1-12 Edition 3 - Update No. 2: 2016/04
- CSA C22.2 NO. 61010-2-201:18 Edition 2 - Published: 2018/02

20.4 UR



The vision sensor has been tested by UL (Underwriters Laboratories) and meets the requirements of the standards under specified installation conditions:

- UL 61010-1 Edition 3 - Revision Date: 2016/04/29
- UL 61010-2-201 Edition 2 - Published: 2018/05/14
- CSA C22.2 NO. 61010-1-12 Edition 3 - Update No. 2: 2016/04
- CSA C22.2 NO. 61010-2-201:18 Edition 2 - Published: 2018/02

20.5 KC (Korean Conformity)



Some of the described devices comply with the Korean Conformity guidelines (Registration of Broadcasting and Communication Equipment).

The table below contains a list of these devices:

Product	Item number	Registration number	Date of registration
VS XF200M03W10RP	11128423	R-REI-BkR-VeriSens-RP	14/12/2017
VS ID100M03W10RP	11048489	R-REI-BkR-VeriSens-RP	14/12/2017
VS XF100M03W16RP	11128422	R-REI-BkR-VeriSens-RP	14/12/2017
VS XF100M03W10RP	11128420	R-REI-BkR-VeriSens-RP	14/12/2017
VS ID100M03W16RP	11076263	R-REI-BkR-VeriSens-RP	14/12/2017
VS XF800M03W12IP	11162177	R-REI-BkR-VeriSens-IP	14/12/2017
VS ID510M03W12IP	11173082	R-REI-BkR-VeriSens-IP	14/12/2017
VS XF800M03W16IP	11162175	R-REI-BkR-VeriSens-IP	14/12/2017
VS XF700M03W16IP	11173090	R-REI-BkR-VeriSens-IP	14/12/2017
VS XF700M03W12IP	11173091	R-REI-BkR-VeriSens-IP	14/12/2017
VS XC100C03X00EP	11116656	R-R-Bkr-VeriSens-XC-EP	11/12/2018
VS XC100C12X00EP	11116724	R-R-Bkr-VeriSens-XC-EP	11/12/2018
VS XC100M03X00EP	11086398	R-R-Bkr-VeriSens-XC-EP	11/12/2018
VS XC100M12X00EP	11086399	R-R-Bkr-VeriSens-XC-EP	11/12/2018
VS XC100M20X00EP	11086410	R-R-Bkr-VeriSens-XC-EP	11/12/2018
VS XC200M03X00EP	11086175	R-R-Bkr-VeriSens-XC-EP	11/12/2018
VS XC200M12X00EP	11086176	R-R-Bkr-VeriSens-XC-EP	11/12/2018
VS XC200M20X00EP	11086177	R-R-Bkr-VeriSens-XC-EP	11/12/2018
VS XC700C03X00IP	11181282	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC700C12X00IP	11181283	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC700M03X00IP	11173085	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC700M12X00IP	11173084	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC700M20X00IP	11173083	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC800C03X00IP	11166809	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC800C12X00IP	11180704	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC800M03X00IP	11166806	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC800M12X00IP	11166807	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC800M20X00IP	11166808	R-R-BkR-VeriSens-XC-IP	11/12/2018
VS XC900M03X00IP	11700454	R-R-BkR-VeriSens-XC-IP	2020-03-25
VS XC900M12X00IP	11700456	R-R-BkR-VeriSens-XC-IP	2020-03-25
VS XC900M20X00IP	11700455	R-R-BkR-VeriSens-XC-IP	2020-03-25